



PLC Terminal


SUPERVISOR User manual

SERAD SA

271, route des crêtes
44440 TEILLE – France

 +33 (0)2 40 97 24 54

 +33 (0)2 40 97 27 04

 <http://www.serad.fr>


 info@serad.fr

Table of Contents

1- INTRODUCTION.....	9
1-1- Description of SUPERVISOR.....	9
Generality	9
Performance.....	9
Modularity.....	9
1-2- Description of SPL software.....	10
Generality	10
2- INSTALLATION/STARTING.....	11
2-1- Environnemental consideration.....	11
2-2- Safety	11
2-3- Connections	12
2-3-1- General explications	12
2-3-2- Supervisor.....	12
S640:.....	12
S80:.....	13
PC <-> SUPERVISOR cable :	13
2-4- Getting started	14
3- SPL SOFTWARE.....	15
3-1- Installation.....	15
3-1-1- System configuration.....	15
3-1-2- Installation procedure	15
3-1-3- Upgrade from previous versions.....	16
3-2- Architecture	16
3-2-1- Folders	16
3-2-2- Project contents	17
3-3- Description	17
3-3-1- Initial screen	17
3-4- Menus and icons	18
3-4-1- Project menu.....	18
3-4-2- Constants/Variables/Tasks menu.....	21
3-4-3- Debug menu.....	22
3-4-4- Communication menu.....	28
3-4-5- Options menu.....	31
3-4-6- Help menu	33
3-4-7- Configuration tab.....	33
A) Serial 1	34
B) Serial 2	34
C) Serial 3	35
D) Inputs.....	35
a) Card :	35
b) Bloc 1 :	36
c) Bloc 2 :	36
E) Outputs.....	37
F) Accessories.....	38
3-4-8- Global constants tab.....	38
3-4-9- Global variables tab	39
3-4-10- Tasks tab.....	40

3-5- Editors	42
3-5-1- Basic task editor	42
3-5-2- Ladder task editor	43
4- PROGRAMMATION LANGUAGE	45
4-1- Introduction	45
4-1-1- Description	45
4-1-2- Memory plan of SUPERVISOR	45
4-2- Data	46
4-2-1- Global constants	46
4-2-2- Global variables	46
4-2-3- Local variables	47
4-2-4- Convert data types	48
4-2-5- Numeric notations	49
4-3- Tasks	49
4-3-1- Multitask principles	49
4-3-2- Task priority	50
4-3-3- Management of task	50
4-3-4- Basic task structure	51
Main program	51
Subroutine	51
Branch to a label	52
Operators	52
a) Arithmetical operators	53
b) Binary operators	53
c) Unary operators	53
d) Logical operators	54
e) Bits operators	54
f) String operators	54
g) Relationship operators	54
B) Tests	54
a) Simple tests	54
b) Multiple tests	55
c) Loops	55
4-3-5- Event task structure	56
Events configuration	56
Reading the events detected	57
Clearing the events	57
Warnings	57
Example	57
4-3-6- Ladder task structure	58
5- PROGRAMMATION OF PLC	59
5-1- Basic task	59
5-1-1- Digital inputs/outputs	59
A) Inputs reading	59
B) Outputs writing	59
C) Outputs reading	59
D) Events handling	60
E) State test	60
5-1-2- Timings	60
A) Passive waiting	60
B) Active waiting	60
TIME	60
TIMER	61
5-1-3- Events	61
Signal or Diffuse and Wait Event	61

Wait	62
5-1-4- Counters.....	62
Configuration.....	62
Clear	63
Read.....	63
5-1-5- Enhanced PLC Function	63
Présentation.....	63
Utilisation du PLC	63
Exemple	64
5-2- Ladder task	65
5-2-1- Presentation	65
5-2-2- Contacts, coils, timers and counters	65
Contacts.....	65
Coils	65
Counters up or down	65
Timer	66
5-2-3- Free contact and coil.....	67
5-2-4- System bits.....	67
5-2-5- Task architecture.....	67
6- PROGRAMMATION OF SERIAL1/SERIAL2 COMMUNICATION PORTS	68
6-1- Introduction	68
6-2- Opening a communication port	68
6-3- Reading data.....	68
6-4- Writing data.....	69
6-5- Close a communication port.....	70
6-6- RS485 treatment	70
6-7- Example: RTU Modbus driver.....	70
7- PROGRAMMATION OF DISPLAY/KEYBOARD	73
7-1- Supervisor description.....	73
7-1-1- Supervisor 640	73
7-1-2- Supervisor 80	73
7-2- Operator functions.....	74
7-2-1- Screen	74
7-2-2- Keyboard	75
7-2-3- Edit	75
7-2-4- Buzzer.....	76
7-2-5- Backlight	76
7-2-6- Leds	76
7-3- Keys	76
7-3-1- SUPERVISOR keys	76
7-4- Internals menus.....	77
7-4-1- General explications	77
7-4-2- Main menu.....	77
7-4-3- Parameters sub-menu.....	78
7-4-4- Manual sub-menu	79
7-4-5- Variables sub-menu	79
7-4-6- Memory sub-menu.....	80
7-4-7- Clock sub-menu.....	80
7-4-8- Tasks sub-menu.....	81
8- OPERATOR AND INSTRUCTIONS LIST.....	82

8-1- Program.....	82
8-2- Arithmetical.....	82
8-3- Mathematical.....	82
8-4- Loops.....	83
8-5- Logical.....	83
8-6- Test.....	83
8-7- Char string.....	83
8-8- PLC.....	84
8-8-1- Logical inputs / outputs.....	84
8-8-2- Timing.....	84
8-8-3- Event handling.....	84
8-8-4- Counter.....	85
8-9- Display / Keyboard.....	85
8-9-1- Supervisor 80 and 640.....	85
8-9-2- Supervisor 640.....	85
8-10- Task handling.....	85
8-11- Communication.....	86
8-12- Flash, Security and other functions.....	86
8-13- Conversion.....	86
8-14- Alphabetic list.....	87
8-14-1- Addition (+).....	87
8-14-2- Subtraction (-).....	87
8-14-3- Multiplication (*).....	87
8-14-4- Division (/).....	87
8-14-5- Lower (<).....	88
8-14-6- Lower or equal (<=).....	88
8-14-7- Left shift (<<).....	88
8-14-8- Different (<>).....	88
8-14-9- Affect/Equal (=).....	89
8-14-10- Greater (>).....	89
8-14-11- Greater or equal (>=)Diff_rent.....	89
8-14-12- Right shift (>>).....	89
8-14-13- Exponent (^).....	90
8-14-14- ABS – Absolute value.....	90
8-14-15- AND – Operator AND.....	90
8-14-16- ARCCOS – Invert cosine.....	90
8-14-17- ARCSIN – Invert Sine.....	90
8-14-18- ASC – Convert char to ASCII.....	91
8-14-19- ARCTAN – Invert tangent.....	91
8-14-20- BACKLIGHT – S640 in stand by.....	91
8-14-21- BEEP – Brief sound.....	92
8-14-22- BOX – Draw box.....	92
8-14-23- BUZZER – Continuous sound.....	92
8-14-24- CALL – Subroutine call.....	93
8-14-25- CASE – Multiple tests.....	93
8-14-26- CARIN – Input buffer state.....	93
8-14-27- CAROUT – Output buffer state.....	93
8-14-28- CHR\$ - Convert ASCII to char.....	94
8-14-29- CLEARCOUNTER – Counter clear.....	94
8-14-30- CLEARIN – Clear input buffer.....	94
8-14-31- CLEAROUT – Clear output buffer.....	94
8-14-32- CLOSE – Close communication port.....	95
8-14-33- CLS – Clear screen.....	95
8-14-34- CLEARFLASH – Clear flash memory.....	95

8-14-35- COUNTER_S – Counter reading	95
8-14-36- CONTINUE – Continue task execution	95
8-14-37- COS - Cosine.....	96
8-14-38- CURSOR – Print or clear the cursor.....	96
8-14-39- CVL – Convert string to long integer	96
8-14-40- CVLR – Convert string to long reverse integer	96
8-14-41- CVI – Convert string to integer	97
8-14-42- CVIR – Convert string to reverse integer	97
8-14-43- CRC – CRC16	97
8-14-44- DATE\$ - Current Date.....	97
8-14-45- DELAY – Passive waiting.....	97
8-14-46- DIFFUSE – Event generation	98
8-14-47- DIV – Integer divide.....	98
8-14-48- EDIT – Editing on operator panel.....	98
8-14-49- EDIT\$	99
8-14-50- END – Block end.....	99
8-14-51- EXIT SUB – Subroutine exit.....	99
8-14-52- EXP - Exponential	99
8-14-53- FLASHOK – Test flash memory	100
8-14-54- FLASHTORAM – Restore saved variables.....	100
8-14-55- FOR – FOR ... NEXT loop.....	100
8-14-56- FONT – Font selected.....	100
8-14-57- FORMATS\$	101
8-14-58- FRAC – Fractional part	101
8-14-59- GETDATE – Current date	101
8-14-60- GETEVENT – Events reading.....	102
8-14-61- GETTIME – Current time	102
8-14-62- GOTO – Branch label.....	102
8-14-63- HALT – Stop a task.....	102
8-14-64- HLINE – Draw horizontal line	103
8-14-65- ICALL – Call a sub-routine.....	103
8-14-66- IF - IF... Then... Else.....	103
8-14-67- INKEY– Read a key on the operator panel	104
8-14-68- INP – Input reading	104
8-14-69- INPB – 8 digital inputs reading	104
8-14-70- INPUT – Data reading.....	104
8-14-71- INPUT\$ - Char string reading	105
8-14-72- INPW – 16 digital inputs reading	105
8-14-73- INSTR – Search a sub-string	105
8-14-74- INT – Integer part.....	106
8-14-75- JUMP – Branch to label.....	106
8-14-76- KEY – Last pressed key	106
8-14-77- KEYDELAY – Delay before key repeat	106
8-14-78- KEYREPEAT – Keyrepeat period	107
8-14-79- LCASE\$ - Lowercases	107
8-14-80- LED – Driving LEDs.....	107
8-14-81- LEFT\$ - String left part.....	107
8-14-82- LEN– String length.....	108
8-14-83- LOCATE – Cursor position.....	108
8-14-84- LOG - Logarithm.....	108
8-14-85- LONGTOINTEGER – Convert a long integer to integer	108
8-14-86- LTRIM\$ - Suppress the left spaces.....	108
8-14-87- MID\$ - String part	109
8-14-88- MOD - Modulus	109
8-14-89- MODIFYEVENT– Events configuration	109
8-14-90- MKL\$ - Convert long integer to string.....	110
8-14-91- MKLR\$ - Convert long integer reverse to a string.....	110
8-14-92- MKI\$ - Convert an integer to a string.....	110
8-14-93- MKIR\$ - Conversion Integer reverse / String.....	110
8-14-94- NOT – Complement operator	111

8-14-95- OPEN – Open a communication port	111
8-14-96- OR – OR operatorr	111
8-14-97- OUT – Output writing	112
8-14-98- OUTEMPTY – Communication output buffer empty	112
8-14-99- OUTB – 8 outputs writing	112
8-14-100- PIXEL – Draw point.....	112
8-14-101- PLCINIT – PLC function initialisation	112
8-14-102- PLCINP – Read TOR input	113
8-14-103- PLCINPB – Read a 8 inputs block	113
8-14-104- PLCINPNE – Read a negative edge on PLC TOR input.....	113
8-14-105- PLCINPPE – Read a positive edge on PLC TOR input	114
8-14-106- PLCINPW – Read a 16 inputs block	114
8-14-107- PLCOUT – Write a output.....	114
8-14-108- PLCOUTB – Write a 8 outputs block.....	115
8-14-109- PLCOUTW – Write a 16 outputs block.....	115
8-14-110- PLCREADINPUTS – Read the PLC inputs	115
8-14-111- PLCWRITEOUTPUTS – Write the PLC outputs	115
8-14-112- POWERFAIL – Power fail detect	115
8-14-113- PRINT – Writing on a communication port	116
8-14-114- PROG – Program start.....	116
8-14-115- RAMOK – Test ram status	116
8-14-116- RAMTOFLASH – Backup saved variables.....	116
8-14-117- READKEY– Return the state of terminal keyboard.....	117
8-14-118- REALTOLONG – Convert a real to a long integer.....	117
8-14-119- REALTOINTEGER – Convert a real to an integer.....	117
8-14-120- REALTOBYTE – Convert a real to a byte.....	117
8-14-121- REPEAT – Repeat...Until.....	117
8-14-122- RESTART – Restart system	118
8-14-123- RIGHT\$ - String right part	118
8-14-124- RTRIM\$ - Remove the right spaces	118
8-14-125- RUN – Launch a task.....	118
8-14-126- SEEK – Moving to a save file	119
8-14-127- SETDATE – Set the date	119
8-14-128- SETINP – Input filters and invert.....	119
8-14-129- SETOUT – Outputs invert.....	119
8-14-130- SETTIME – Set the hour	120
8-14-131- SETUPCOUNTER – Counter configuration	120
8-14-132- SGN - Sign	120
8-14-133- SIN - Sine	120
8-14-134- SIGNAL – Event generation	120
8-14-135- SQR – Square root.....	121
8-14-136- SPACE\$ - Space made string	121
8-14-137- STR\$ - Char characters convert.....	121
8-14-138- STATUS – Task state	121
8-14-139- SUB – Subroutine.....	122
8-14-140- SUSPEND – Suspend a task	122
8-14-141- STRING\$ - String creation	122
8-14-142- TAN - Tangent.....	123
8-14-143- TIME – Time base	123
8-14-144- TIMER – Wide time base	123
8-14-145- TIME\$ - Current hour.....	123
8-14-146- TX485 – Modify RS485 output state.....	124
8-14-147- UCASE\$ - Uppercase	124
8-14-148- VAL – Convert a string in numeric	124
8-14-149- VERSION – Operating system version	124
8-14-150- VLINE – Draw a vertical line.....	124
8-14-151- WAIT EVENT – Event waiting.....	125
8-14-152- WAIT KEY – Key waiting.....	125
8-14-153- WAIT – Condition waiting.....	125
8-14-154- WATCHDOG – Watchdog.....	126

8-14-155- WHILE – While...Do...End While.....	126
8-14-156- XOR – Exclusive OR operator	126
9- CANopen	127
9-1- Definition.....	127
9-1-1- Introduction	127
9-1-2- CANopen communication	127
9-1-3- Network configuration.....	129
9-1-4- Type of send messages	130
9-2- SUPERVISOR CANopen bus.....	130
9-2-1- Presentation - SCAN board	130
9-2-2- Characteristics	130
9-2-3- Connections	131
9-2-4- Test and diagnostic of the Can Open network	132
VIEW page	132
DEBUG page :.....	133
9-2-5- Dictionary.....	134
9-3- Instructions list.....	137
9-3-1- List of the CANopen instructions	137
A) Read and write the dictionary.....	137
B) Modification of local variables.....	137
C) Modification of remote variables	137
D) Instructions in mode PDO	137
E) Control instructions.....	137
F) Instructions in mode PDO	137
9-3-2- CAN – Read and write a message	138
9-3-3- CANERROR – Faults detection	138
9-3-4- CANERRORCOUNTER – Controls and erases the communication errors.....	138
9-3-5- CANEVENT – Test a message arrival.....	138
9-3-6- CANLOCAL – Read or write a local variable.....	138
9-3-7- CANSETUP – Read or write a parameter	139
9-3-8- CANREMOTE – Read or write a remote variable	139
9-3-9- PDO – Read or write data from a PDO	140
9-3-10- PDOEVENT – Test a PDO arrival	140
9-3-11- SDOEVENT – Event SDO.....	140
9-3-12- SDOINDEX – Index SDO.....	140
9-3-13- SDOSUBINDEX – Sub-index SDO.....	141
9-3-14- SETUPCAN – Configuration of a message.....	141
9-3-15- STARTCAN – Start a CANopen board.....	141
9-3-16- STOPCAN – Stop a CANopen board.....	141
9-4- Examples.....	141
9-4-1- CANopen link between two SUPERVISOR	141
9-4-2- CANopen linking between a SUPERVISOR and an I/Os module	143
10- REMOTE CONTROL	144
10-1- Connections	144
10-2- Link establishment	145
10-3- List of the validated modems	151
11- APPENDIX.....	152
11-1- Execution errors messages	152
11-2- Compiler error messages.....	153

1- INTRODUCTION

1-1- Description of SUPERVISOR

Generality

The SUPERVISOR is an intelligent operator terminal that is capable of completely managing the automated operation of a machine.

Using its communication ports it can communicate by serial link or fieldbus with the various elements of an automated system, such as intelligent drives, distributed I/O, PLC, PC, etc.

Easy to program, using the Windows® based application SPL, it has a true multi-tasking core, RAM and FLASH memory, a real-time clock and up to three serial ports (RS232 , RS485 , CANopen).

The SUPERVISOR is an open system that is adaptable for all applications that comprise an HMI, PLC, and serial communication.

Performance

- ↳ 32 bits Processor at 33 MHz
- ↳ 4Mbits of non-volatile RAM
- ↳ 8Mbits of Flash memory
- ↳ 2 serial communication ports - 1200 to 9600 b/s
- ↳ 20 inputs/outputs
- ↳ real-time clock
- ↳ watch dog
- ↳ backlight
- ↳ 8 character sets (S640 only)
- ↳ tactile effect keyboard

Modularity

SUPERVISOR have many choice of modules to adapt of your application.

- ↳ Digital I/O TOR module - 20 channels
- ↳ RS232, RS422 and RS485 communication board
- ↳ CANOpen communication board

1-2- Description of SPL software

Generality

Supervisor programming language is a user program development with SUPERVISOR running under MICRODOFT WINDOWS environment.

SPL can manage up to 28 basic or PLC tasks and 20 000 user variables.

- ↳ System configuration with graphic tools
- ↳ Easy access to advanced instructions with tool box giving
- ↳ Fastest programming with the PLC tool box
- ↳ On-line Help and full-screen editor
- ↳ Debug mode to test your application with a PC
- ↳ Software oscilloscope captured and displayed up to six simultaneous parameters

2- INSTALLATION/STARTING

2-1- Environnemental consideration

SUPERVISOR must be installed vertically to have a natural convection cooling. SUPERVISOR must be sheltered from humidity, liquid projection and dust.

Technical features :

- ↳ Power supply : 24 Vdc 15W
- ↳ Watchdog : NO Contact liberate from potential - 48Vac maxi 2A maxi
- ↳ Service temperature : 0 to 45°C
- ↳ Storage temperature : -20 to 70°C

2-2- Safety

- ↳ The security rules impose a manual restart after a default due to a power supply falling down, a watchdog default or an emergency stop.
- ↳ SUPERVISOR's watchdog must be connected in serial with the emergency stop loop
- ↳ The watchdog must be closed at the beginning of the program. When a fault is detected (Internal fault, power fail, ...), the watchdog is automatically open.
- ↳ Linked the « Power Electrical cupboard OK » to a PLC input and treated it in a safety basic task.

2-3- Connections


2-3-1- General explications

↳ SUPERVISOR/PC cable must be shielded with shield connected at each end. It will have to be disconnected from the SUPERVISOR when it is not used. All these cables, as well as the inputs/outputs cables will have to be separated and distant of the power modules.


↳ Inductive load must have an interference eliminator diode in DC and filter in AC. Diodes and filters must be placed as close to the charge as possible.

2-3-2- Supervisor

S640:




S80:



WATCHDOG is a NO contact - 48 VAC maxi - 2A maxi.

PC <-> SUPERVISOR cable :



2-4- Getting started

SUPERVISOR starting follows this approach :

- ↳ Define board placement in the setup screen.
- ↳ Setup each card.
- ↳ Send setup in SUPERVISOR using "Send setup" menu.
- ↳ Define the global variables.
- ↳ Send global variables value in SUPERVISOR.
- ↳ Write each task.
- ↳ Compile and transfer tasks in SUPERVISOR.
- ↳ If the setup is modified it must be sent one more time.

3- SPL SOFTWARE

3-1- Installation

3-1-1- System configuration

Minimal configuration :

- ↵ PC 486 DX2 66
- ↵ RAM 8 Mb
- ↵ Hard disk (35 Mb available)
- ↵ Microsoft® Windows™ 95 or Microsoft® Windows™NT 4.0 (service pack 3)
- ↵ CD-ROM (2X)
- ↵ SVGA colour display
- ↵ Mouse or other peripheral pointing system







Required configuration :

- ↵ PC Pentium® 75 or greater
- ↵ RAM 16 Mb
- ↵ Hard disk (35 Mb available)
- ↵ Microsoft® Windows™ 95 or Microsoft® Windows™NT 4.0 (service pack 3)
- ↵ CD-ROM (4X)
- ↵ SVGA colour display
- ↵ Mouse or other peripheral pointing system

This software run on Microsoft® Windows NT™. But, it doesn't run on Unix, Mac, MS-DOS and Microsoft® Windows 3.11.

3-1-2- Installation procedure

The Supervisor Programming Language software is provided in a CD-. The installation procedure is described below :

- ↵ Verify the **required configuration** before the software installation
- ↵ Insert the CD-ROM in the appropriate drive.
- ↵ In the menu , select  .
- ↵ In the « Execute » dialog box , select  .
- ↵ In the « Parcourir » dialog box, select the drive where the floppy disk or CD-ROM is.
- ↵ Select  Setup.exe then  in the « Parcourir » dialog box.
- ↵ Select  in the « Execute » dialog box.
- ↵ The installation software is running.

- ↳ In the beginning of the installation, there are some dialog box to drive the installation :
 - Destination folder
 - Installation type (Typical, compact or custom)
 - Select the program manager
- ' **Warning** : only one level of folder can be created.
- ⇒ **The file installation starts and is indicated by the evolution of a progress bar.**
- ⇒ **The installation finishes with the adding of icon in the program manager.**

3-1-3- Upgrade from previous versions

A program wrote with a previous version can work on a new version if a compilation is done. Spl software only works with operating system provided in the OS directory of the installation directory of the software. By default this directory is « **C:\Program Files\Serad\Spl** ».

Operation system installation is :

- ↳ Connect SUPERVISOR SERIAL1 communication port on COM1 or COM2 of the PC
 - ↳ Run SPL's application, go to OPEN PROJET in PROJECT then in OPTIONS -> OPERATING SYSTEM, click on UPDATE. If you want to update by DOS, follow the next instructions.
 - ↳ On Windows 95 or greater, open a DOS windows
 - ↳ With the DOS command, take place in the OS folder
 - ↳ Execute the command : `INSTALL < Serial port of PC>`
- For a serial plug on COM1 : `INSTALL COM1`
- ⇒ Installation starts with old operating system erasure. The « Waiting for erasure » message appears on PC screen.
 - ⇒ Then, programming is starting.
 - ⇒ When programming is done, SUPERVISOR restarts with Error n°23 because there is no user program.
 - ↳ Compile tasks and transfer in the SUPERVISOR.

3-2- Architecture

3-2-1- Folders

- ↳ Gfx: contains all the chart.
- ↳ Lib : contains all the file with DLL extensions for the running of the software
- ↳ Str : contains the language file
- ↳ OS : contains a copy of the SUPERVISOR operating system
- ↳ Help : contains all the help file for the SUPERVISOR and SPL.
- ↳ Project : contains all the **files and folders of the user's project**

3-2-2- Project contents


The « project » folder is a reserved folder for the user's project. Each project is composed on a « ProjectName.prj » file and a « ProjectName.rep » folder. This folder have the file below :

- ↪ a configuration file (ProjectName.cfg)
- ↪ a global variable definition file (ProjectName.var)
- ↪ a global constant definition file (ProjectName.cst)
- ↪ a file per basic task (ProjectName.tsk)
- ↪ an extra file per ladder task (ProjectName.lad)
- ↪ The result of compilation gives some binary file (ProjectName.bin and ProjectName.b00 to ProjectName.b07). The sum of the task length (b0*) gives the length of the compiled task.
- ↪ Other files (.map, .uti) for the SPL internal management

3-3- Description


3-3-1- Initial screen

SPL software is defined by a main window with a main menu, an icons bar and the multiwindows. The property of multiwindows provides to users the possibilities to go to another window without to changing it.



3-4- Menus and icons

3-4-1- Project menu




New Project

Icon:




Action:

This command defines a new project. The last running project is closed and a dialog box appear to choose the Supervisor model.



Then a new configuration window appears.



Open project

Icon:

Action: This command opens the « Open Project » dialog box. The users can indicate the path of the project, he wants to load. This command closes the last running project on the validation of this dialog box.

Save project

Icon:

Action: This command saves the complete running project.

Save as...

Action: This command opens the “Save as” dialog box that allows user to change the path and the name of the project. This command creates a file and a folder with the name of the project and for the first the “prj” extension and the second the “rep” extension.

Copy project


Action: This command has the same properties as Save as... . However, this command doesn't change the date of the project creation.

Close project

Action: This command closes the running project.

Search in tasks

Action: This command searches a text, a word or a part of a word in all the tasks of the project. A dialog box appears and gives all the functions to succeed. A double click on a result line of a search edits the basic task at the right line.



Sort variables

Action: This command sort globales variables. At first, we find saves globales variables in growing order of their address, then not saves globales variables in type order (bit, octet, string ...). Inside the same type, a alphabetical order is doing.

Compile project

Icon:



Action: This command compiles the project. A first phase verifies the syntax of each task, the configuration of variables, etc.... When a task has a syntax error, the basic task is edited and the error is highlighted with the position of the cursor. It is possible to compile only one task : choose a task in the task's list, right's click on your mouse and select VERIFY SYNTAX.

Informations

Action: This command give detailed informations on project, on programme's memory and memory of uses datas.

Printer setup

Action: This command allows the user to define its print type (printer, paper, etc...). The paper orientation can't be changed.

Impression

Icon:



Action: This command print all of a custom project. The SUPERVISOR configuration , all the basic's task and the ladder are printed.


Quit

Action: This command quit the SPL software.

Projects list

Action : A click on a project of this list opens it.

3-4-2- Constants/Variables/Tasks menu



The four commands of this submenus act on the main windows of the project. The actions of each one are different with the selected tab of the windows.

↳ An adding, suppression or modification of an elements needs the project to be compiled again.

↳ A modification of a parameter value needs the configuration to be sent to the SUPERVISOR.

↳ A modification on a global stored variable value needs the variables to be sent to the SUPERVISOR.

Add

Icon:



Action : This command adds a board, a global constant, a global variable or a task according to the tab selected.

Modify

Icon:



Action : This command modifies the parameters of a board, a global constant, a global variable or a task according to the tab selected.

Delete

Icon:




Action : This command deletes a board, a global constant, a global variable or a task according to the tab selected.

Show

Icon: 

Action : This command shows the parameters of a board, a global constant, a global variable or runs the ladder or basic editor according to the tab selected.

3-4-3- Debug menu



Debug mode

Action: This command allows the working of debug mode. On activate, all the command of this sub-menus are valid.

Configuration


Action : This sub-menu displays the SPL debug window or the debug window of the slot selected. According to the board in the slot, the dialog box is different :

↳ A dialog box with the state of the status display, the state of the watchdog and the time and date in SUPERVISOR appears. All of these parameters can be modified. If one of this parameters is driven by an executed task, the manual modification of its state may be transitory.




↳ The debug windows of I/O module boards shows with leds the state of each input or output of a board. A click on a led modifies the state of the input or output.

Tasks




Action : In this sub-menu, there are all the tasks defined in the tasks tab. The validation of one of the tasks launches the basic editor in a debug mode. The basic code can't be modified. This mode allows the user to show the **evolution of code trace** if it was validate.

StepByStep



Action : This command allow to run the programm in step by step mode and control the good functioning of each basic in the task.

Breakpoint




Action : This command allow to choose a ligne in the task where you want that the programm stop for control some parameters..

Terminal

Icon: 

Action: This command launches the hyper terminal viewer. This tool allows to ask the state of SUPERVISOR or to read and write the local and global variables, parameters, inputs and outputs.



The terminal window has a main window and two other optional windows : the « observations » window and the « status » window.

⇒ The main window allows the reading and the writing in real-time of all the variables and parameters of SUPERVISOR. To access to these information, there are some functions :

- ↵ Print <Variable or Parameter Name> : display the value of a variable or a parameter.
- ↵ <Variable or Parameter Name>=<Value> : assign a value to a variable or a parameter
- ↵ STATUS : State of the tasks
- ↵ RUN <Task name> : execute a task
- ↵ HALT <Task name> : stop a task
- ↵ SUSPEND <TaskName> : suspend the execution of a task
- ↵ CONTINUE <TaskName> : continue the execution of a task
- ↵ CLS : Clear the dialog zone
- ↵ RESTART : restart SUPERVISOR
- ↵ EXIT : close the terminal

For an easy way to edit the name of variables or parameters, the terminal has a window of SUPERVISOR properties. In this window, we can find all the parameters of each board, global variables and local variables of each task. The parameter or variable name appears on the terminal window on a double click on one of this variable or parameter.

⇒ The « observations » window show the state of variables in a continuous mode. The maximum of variables or parameters to show is limited to 100. Two commands allow user to add or delete a variable. The adding command launches the execution of the SUPERVISOR

properties window. The variable or parameter must be choose among board, global variables or task. You can save or load this 40 variables as a file.

⇒ The « status » window shows the state of the SUPERVISOR and the state of the task in a continuous mode. SUPERVISOR can be remotely driven with a click on the play or stop icon displayed. A click change the icon displayed. The tasks can be remotely driven too separately. The state of each task may be : « Stop », « Start », « Suspend » or « Continue ». The modification of the state is obtained with a click on the state icon of the task. The « trace » row indicates the executed line of a task. Before, the code trace must be validate, the project compiled again and the task sent. You can also have a notion of the system's resources used for each task.

Scope


Icon:



Action:


This command launches the scope. This tool is able to capture all the information of axis board or input/output board. This tool is able to store six different variables.

The scope is configured in three parts: the visualization screen, the acquisition configuration zone and the channels configuration zone.




⇒ In the acquisition configuration zone, user can define the number of samples during an acquisition cycle. User can start and print an acquisition.


⇒ The channels configuration zone have 6 channels tabs and a time-base tab. For channels tabs, user can define the type of the board, the board, and the acquisition parameter. For example with an axis board, the following error can be chosen.




↵ The visualization screen displays the six channels. A double-click on this zone and the window is in full screen. This window gives the position in X and Y of the cursor. We can also define reference position on X and Y. A click on dX or dY shows a moved vertical or horizontal line. The position of the new click defines the reference position. The value indicates in dX or dY is the difference between the cursor position and the reference position.



3-4-4- Communication menu



Setup



Autodetect

Action: With a new project, this command create automatically the configuration if the PC and the SUPERVISOR are connected.

Send

Icon: 


Action: The configuration sending initializes SUPERVISOR with the parameters defined in the configuration screens of each board. At the beginning, there is a test between the configuration in the SUPERVISOR and the configuration on the PC. If an error is detected, the transfer is stopped and a message appears with the card where the contents is incorrect. This command is necessary after an adding, deleting or modification of a board...

Receive

Icon: 

Action: This command updates the parameters in the screens configuration of boards. The transfer begins with the test between the configuration in SUPERVISOR and the configuration on the PC. If an error is detected, the transfer is stopped and a message appears with the card where the contents is incorrect. If you want to stored this configuration in the project, you need to execute the « Save as... » command.

Variables



Send

Icon:


Action: the sending of stored variables initializes the value assigned to this variable in SUPERVISOR. So, you needn't to initialize them in a program.

Receive

Icon:

Action: This command provides a copy of the stored variables in SUPERVISOR in the PC. If you want to store these values of variables in the project, you need to execute the « Save as... » command.

Tasks



Send

Icon:


Action: This command sends all the compiled tasks in the SUPERVISOR. The execution of the tasks is automatically launched after the transfer. The transfer begins with the clearing of the memory. During this phase, the "c" symbol appears on the SUPERVISOR display status and a bar graph indicates the evolution of the transfer.

Clear

Icon:

Action: This command clears all the tasks in SUPERVISOR memory. After the execution of this command, SUPERVISOR indicates an error 23.

SUPERVISOR Flash



Copy data in flash memory

Action: This command creates a backup in flash memory of the setup parameters and of the first 10000 stored variables in the non-volatile RAM memory. At each SUPERVISOR power-on, a checksum is made to test the validity of the data in non-volatile RAM. If an error is detected, SUPERVISOR transfer the flash memory backup in the non-volatile RAM and launches tasks. If there is no backup, SUPERVISOR indicates an error 20.

Clear data in flash memory

Action: This command clear the data's copy in the flash's memory.

Run SUPERVISOR

Icon:



Action: This command launches the execution of the tasks in SUPERVISOR.

Stop SUPERVISOR

Icon:




Action: This command stops the execution of the tasks in SUPERVISOR. WatchDog becomes OFF. All the servo board are in an open loop state (analogue command=0). The **Security** instruction has no effect on SUPERVISOR.

Remote control


Action: With this command, you have access in mode Remote Control. You can drive the SUPERVISOR at distance with a modem and a telephone line (see chapter Remote Control).

3-4-5- Options menu




SPL

Language




This sub-menu allows the selection of language.

Editor




This sub-menu allows to customize the colour of the font and the background of text, key-words... in the editor of basic task.



To modify a colour, first you should select a type of text. Then, you choose one colour and you click on it with the left click to change the font colour or the right click to change the background colour. A screen shows the result of the modification.


Project

PC Com




This sub-menu allows the selection of the communication port of the PC which is in link with SUPERVISOR.

Model :



This sub-menu allows to change to Supervisor model.

Compiler



With trace code

Action: This command adds some information to the compiler to obtain the trace code in task. This command is interesting to test systems but the compiled file are biggest and the execution of task is ran slowly. When it is activate or disable, you need to compile the tasks again.

Force using brackets

Action : This command strengthens the test of brackets during the compilation.

Multitasking

Action : This command allows the modifications of multitasking parameters. A dialog box appears and allows the modification of the ageing time task and the normal slice time.

Operating system

Action : This command update or clear the operating system. Attention, this procedure is reserved to experienced user.

3-4-6- Help menu




Wizard

Action: This command allows the displaying of icon information.


About ...

Action: This command launches a dialog box which indicates the software version, etc...


3-4-7- Configuration tab



On the configuration window, there are two zones. The first zone is on the left with the front of SUPERVISOR. This zone allows the SUPERVISOR configuration. We can configure the display machine, the SERIAL1, SERIAL2, SERIAL3, INPUTS and OUTPUTS. The second zone is on the right with the name « Périphériques » give the affectation of the different connectors.



A) Serial 1



Action : Allow to configure the serial port com 1, with this parameters :


- the rate
- the number of data's bit
- the parity
- the bit's stop

B) Serial 2


Action : Allow to configure the serial port com 2, with this parameters :

- the rate
- the number of data's bit
- the parity
- the bit's stop

C) Serial 3




Action : Allow to configure the CANOpen communication between SUPERVISOR and MCS32EX



Action : Allow to supervise the CANOpen communication between SUPERVISOR and MCS32EX


D) Inputs

a) Card :



Action : Allow to give a name to inputs'bloc and set a filtering.


b) Bloc 1 :



Action : Allow to give a name to each input's bit and inverse them.


In debug mode, you can see their state and modify them.

c) Bloc 2 :



Action : Samethings for the four last inputs


E) Outputs



Action : Allow to give a name to each output'bit and inverse them.


In debug mode, you can see their state.

F) Accessories



Action : Allow to set the clock, modify the backlight (only for S640) and watchdog.

3-4-8- Global constants tab



In the « Global Constants » tab, all the constants with their features (name, type and value) are summarized. In this tab, we can add, modify or delete a global constants. The add, delete and modify commands need the compilation of the tasks again and the sending tasks.

The « Add » command create a new global constant to the project. A dialog box appears to configure the parameters of this new constant.



The « Add » (a constant) command can be obtained in two different ways :

- ↳ In the **Constants** menu
- ↳ A right click open a menu with the « Add » command

The « Modify » or « Show » command allows the modification of the global constant parameters, except its type. This command can be obtained in three different ways :

- ↳ In the **Constants** menu (select the constant to modify before)
- ↳ A double click on the constant to modify
- ↳ A right click opens a menu with the « Modify » or « Show » command (select the constant to modify before).

The « Delete » command allows to suppress a global constant to the project. This command can be obtained in two different ways :

- ↳ In the **Constants** menu (select the constant to suppress before)
- ↳ A right click opens a menu with the « Modify » or « Show » command (select the constant to modify before)

3-4-9- Global variables tab

Name	Type	Number	Adress	Value
Velocity	Bit(s)	1		
NbError	Byte(s)	1	1007	0
AutoVel	Real(s)	1		
CamTable1	Cam table	37	400	
Message1	String(s)	20		

In the « Global variables » tab, all the variables with their features (name, type, number, address and value) are summarized. The number parameter defines the number of elements in this array. The address parameter must be fixed if the variable is a stored variable (address 1 to 20000). In this tab, we can add, modify, delete or show a variable. The « Add », « Modify » or « Delete » command need the compilation of the tasks again and the sending tasks. In the case of a stored variable, you should send the variables too.

The « Add » command defines a new global variable in the project.

Variable

Name : Length

Type : Real(s)

Number : 1

Address : 100 Save

OK Cancel Help

Variable name

Variable type

Number of elements
=1 for a variable
>1 for an array

Address for stored variable
(from 1 to 20 000)

This command can be obtained in two different ways :

- ↳ In the **Variables** menu
- ↳ A right click opens a menu with the « Add » command

The « modify » command allows the modification of the global variables parameters, except its type. This command can be obtained in two different ways :

- ↳ In the **Variables** menu (select the variable to modify before)
- ↳ A right click opens a menu with the « Modify » command (select the variable to modify before)

The « Delete » command suppresses a variable of the project. This command can be obtained in two different ways :


- ↳ In the **Variables** menu (select the variable to delete before)
- ↳ A right click opens a menu with the « Delete » command (select the variable to delete before)

The « Show » command allows the visualization of a variable state. This command shows all the value of an array. It can be obtained in three different ways :

- ↳ In the **Variables** menu (select the variable to show before)
- ↳ A double-click on the variable to show
- ↳ A right click opens a menu with the « Show » command (select the variable to show before)

When you want to show a camtable variable, **the cam editor is launched**. In this editor, we can define the profile of a cam.


3-4-10- Tasks tab



Name	Date	Startup	Priorité	Comments
INIT_T	01/12/98 10:42:42	Auto	Normal	Initialisation axes, sor
HELP_T	13/10/98 18:17:24	Manual	Normal	
NAVIG_T	20/10/98 14:04:12	Manual	Normal	
DIALOG_T	20/10/98 14:04:12	Manual	Normal	
POLICE_T	14/10/98 07:24:34	Manual	Normal	
AF_ORIG	13/10/98 17:48:02	Manual	Normal	
AF_CYCLE	13/10/98 16:30:10	Manual	Normal	
ARBRE_T	14/10/98 08:28:06	Manual	Normal	
CAME	09/12/98 14:29:16	Manual	Normal	
CYCLE_T	14/10/98 08:28:06	Manual	Normal	
ENTSORT	13/10/98 17:41:02	Manual	Normal	
LEDS_T	13/10/98 17:41:02	Manual	Normal	
ORIG_T	28/10/98 19:56:10	Manual	Normal	
SYNC_T	14/10/98 08:31:34	Manual	Normal	
AF_SYNC	14/10/98 08:10:34	Manual	Normal	

In the « Tasks » tab, all the tasks with their features (name, date of creation, type of startup and comments) are summarized. In this tab, we can add, modify, delete or show a task. The « Add », « Modify », « Delete » or « Show » command need the compilation of the tasks again and a sending tasks to be done.

The « Add » command defines a new task in the project. A task have different features : priority (normal or high), type (basic or ladder), startup type (manual, automatic, event) and an optional comments. The type of the task defines the editor type of the task.



The « Add » (a task) command can be obtained in two different ways :

- ↳ In the Tasks menu
- ↳ A right click opens a menu with the « Add » command

The « modify » command allows the modification of the tasks parameters. The « Modify » (a task) command can be obtained in two different ways :

- ↳ In the Tasks menu (select the task to modify before)
- ↳ A right click opens a menu with the « Modify » command (select the task to modify before)

The « Show » command launches the editor of task according to the type choose (basic or ladder). This command can be obtained in three different ways :

- ↳ In the Tasks menu (select the task to show before)
- ↳ A double-click on the task to show
- ↳ A right click opens a menu with the « Show » command (select the task to show before)

The « Delete » command suppress a task in the project. This command can be obtained in two different ways :


- ↳ In the Tasks menu (select the task to delete before)
- ↳ A right click opens a menu with the « Delete » command (select the task to delete before)

Attention : A ladder task is automatically traduct in basic. It's advise to not write a long or complex ladder task, in order to avoid time cycle deteriorations and basic traduction limit.

3-5- Editors





3-5-1- Basic task editor

The basic editor has a zone to edit the program, a toolbox to help the user and another optional zone with all the parameters and variables of SUPERVISOR. In this last zone, there are all the parameters of each card of the project, all the constants and global variables.






The toolbox helps the user to use movement and other instructions. Tools are in subgroup :

⇒ Editor tools


- ↵ A tool to search a word or a group of word . This search is made in the task in confusing or dissociate the upper and lower case.
- ↵ The replace command  search and replace an occurrence in a task.
- ↵ The print command 
- ↵ The next icon display a quick syntax of the check instruction of task editor. 
- ↵ Copy (CTRL+C), paste (CTRL+V) and cut (CTRL+X).

⇒ Communication tools

- ↵ the terminal panel command  helps to define the text on it. The dialog box is defined with the front of the terminal panel selected in the Option menu. To generate the code corresponding with the text on the terminal panel display, you should choose the Write command. To show the result of a part of code, you should select some text and the Read command. The clear command clears the screen of the terminal panel.

- ↪ The edit command  helps to define an numeric or alphanumeric edit on a terminal panel.
- ↪ The format command  helps to define the code to format a variable.

3-5-2- Ladder task editor



The ladder editor is composed with an editor zone of the ladder program (the grid), a toolbar of chart that can be inserted and a toolbox. A ladder program have lot of rungs limited to 50 in a task. Each rungs have an optional comment, an expression and 1 to 5 outputs.

- ↪ The tool bar can define the type of chart that can be put on the ladder grid. To select a chart, you just have to click on the button with the wanted chart.
- ↪ The ladder grid allows to put different chart and so to define the program.

A selected case of the ladder grid is indicated with a black background.

To put a chart on the ladder grid, you just have to click with the left button of the mouse on the ladder grid. The parallel link goes on the top and left corner to the bottom and left corner of the case.


A double-click on a case of a ladder grid where there is a chart allows user to configure it :

- ⇒ For coils and contacts, a SUPERVISOR configuration screen appears on the toolbar. In this zone, there are all the bits variables like inputs, outputs and system bits. We can also find 64 bits. By default, there names are like :<bit>+ n)of bit. The name of this bits can be changed by a click or with the menu which appears on a right click. There are three system bits : an init bit which is equal to one during the first cycle of the program and two blink bits. One have a semi period equal to 500 ms and the second to 1s.
- ⇒ For blocs, there is a specific dialog box. For timer, the name and the delay is configured. For counter, the name, the type and the preset value is configured.




⇒ For free blocs, a dialog box allows to edit the basic code. For free contact, the code will be a condition and for free coil, it will be an action. An error in the code edited will be only detected by the basic compiler.




The selected rungs is the rungs with the background of the comments in blue. To edit a comments, you just have to make a double click on it.




↳ Commands

⇒ A command to quit the ladder editor .

⇒ A command to print .

⇒ Commands to add a rung , to insert a rung before the selected one  and to delete the selected rung .

⇒ Commands to cut , copy  and paste a chart . The cut or copied chart is the selected one. The paste chart is inserted on the free selected case.

⇒ Commands to cut , copy  and paste a rung . The cut or copied rung is the selected one. The paste rung is inserted before the selected one.

⇒ The SUPPR key clears the chart on the selected case. To delete a parallel link, you need to select this chart in the toolbar and to click in the case of the link.

⇒ The «Go at rung» function allows to go to a particular rung.

4- PROGRAMMATION LANGUAGE

4-1- Introduction

4-1-1- Description

Supervisor Programming Language is a complete programming language and easy to use with its structured programming constructions as found in most other modern programming languages. This language is built around a multitask kernel and the basic language to ensure flexible and powerful programming. The basic language also contains all PLC function.

The language manages the constants and variables like global, local or stored variables...

A project developed with SPL software can contain up to 28 tasks working in parallel. Each task have a priority level and can be describe by the basic or ladder editor. An extra task treats the fastest events.

4-1-2- Memory plan of SUPERVISOR

Flash memory (1 Mb)

64 Kbytes area data RAM backup : - parameters - first 10 000 non volatile variables
448 Kbytes area 28 user tasks
512 Kbytes area reserved system - boot - operating system

non-volatile ram memory (512 Kb)

128 Kbytes non volatile user file
8 Kbytes area non volatile users parameters for the configuration
120 Kbytes area 20 000 non-volatile global users variables
64 Kbytes area non volatile global or local users variables
192 Kbytes area System reserved - Interrupt vectors - Stack - Heap

4-2- Data

4-2-1- Global constants

The global constants are defined with the global constant tab of the SPL software. The types accepted are : bit, byte, integer, long integer, real, string char.

Constants are read only data defined in a project. They are stored in the flash memory with the code of the task compiled. A global constant can be used by all the tasks.

4-2-2- Global variables

The global variables are defined with the global variable tab of the SPL software.

A global variable and a constant variable can't have the same name in a project because the compiler can't do the distinction. The global variable types and the global constant types are the same.

A global variable can be used by all the tasks and accessed at every time.

This variable is an array if at its creation, the field « number » is greater than one. The first index of an array is 1. The index can be an immediate value, a byte variable or integer variable.

Example :

```
Position = PositionArray[5]
```

' **Warning** : A writing at the 0 index in an array is forbidden : this error can make trouble in the operating cycle.

The variable can be a stored variables.

On a power cut, the variable value is preserved. There are 20 000 stored variables at address 1 to 20 000. Then, a stored variable must be assigned to an address.

' **Warning** : The user must beware of the crossing of variables when he assigns them. For example, an array with 50 elements is assigned at the address 100, the next variables must be assigned at an address greater than 150.

The crossing of variables can be used in one case : to allows the address access with multiple variables.

Example :

TableModbus : array of 50 integer assigned at address 100

DecompteurPiece : integer variable assigned at address 100

```
If TableModbus[1]=0 Then Goto EndProduction  
If DecompteurPiece=0 Then Goto EndProduction
```

This two last program lines are the same but the last one is the most explicit.

Unlike the local variables, you need to define the global variable before you use it. A non-stored variable will be used as a link between tasks. Whereas the stored variable are used to preserve adjust parameters etc....

Defined types are :

Type	Valeur	Occupation mémoire	Exemple
Bit	1/0, On/Off ou True/False	Variable non sauvegardée : 1 octet Variable sauvegardée : 6 octets	Etat=On
Octet	0 à 255	Variable non sauvegardée : 1 octet Variable sauvegardée : 6 octets	Milieu=128
Entier	0 à 65535	Variable non sauvegardée : 2 octets Variable sauvegardée : 6 octets	NumBoucle=1000
Entier long	0 à +/- 2 147 483 647	Variable non sauvegardée : 4 octets Variable sauvegardée : 6 octets	VitMax=100 000
Réel	+/- 2.9×10^{-39} à +/- $1.7 \times 10^{+38}$	Variable non sauvegardée : 6 octets Variable sauvegardée : 6 octets	PositionMax=1256.152
Chaîne de caractères	0 à 255	Longueur chaîne+1	Erreur1=« Butée atteinte »

4-2-3- Local variables

These variables are accessible only in the task where they are declared (main program and sub-programs). The accepted types are : bit, byte, integer, long integer, real, char string. Their values are not preserved between each power on and are cleared to zero.

You often need to store values temporarily when performing calculations with Basic. You need to preserve the values to compare them but without stocking them in a global variable.

The local variables don't need to be defined before being used. They have an identification character at the end of the name to indicate the data type. The local variables of a task can't be used by an other task. Two variables with the same name, used in two tasks, are two different variables. In a task, the variable can be used in the main program and the subprograms.

The treatment of a local variable is fastest than the global variable. A local array can't be defined.

Warning : Don't use so much local string variables because each local string variable takes 256 bytes in memory !

Example :

```

a%=10                                \ integer variable
If Position !>1000 Then Position !=0  \ real variable
Compteur%=Compteur+1                 \ long integer variable
FormFeed$=Chr$(10)+Chr$(13)         \ string char variable

```

The local variables can have the following types :

Type	Valeur	Occupation mémoire	Déclaration	Exemple
Bit	1/0, On/Off ou True/False	1 octet	~	Capteur~=On
Octet	0 à 255	1 octet	#	Donnée#=128
Entier	0 à 65535	2 octets	%	Nb%=2000
Entier long	0 à +/- 2 147 483 647	4 octets	&	Vitesse&=120 000
Réel	+/- 2.9×10^{-39} à +/- $1.7 \times 10^{+38}$	6 octets	!	Post!=122.245
Chaîne de caractères	0 à 255	256 octets	\$	Mes\$='Erreur'

4-2-4- Convert data types

To convert a data type to an other data type, use the functions below:

Destination Source	Bit	Byte	Integer	Long integer	Real	String
Bit	×	Auto	Auto	Auto		Str\$ or Format\$
Byte	‘.1’ to ‘.8’		Auto	Auto	Auto	Str\$ or Format\$
Integer	‘.1’ to ‘.16’	‘.L’ or ‘.H’	×	Auto	Auto	Str\$, Mki\$, Mkrl\$ or Format\$
Long integer	‘.1’ to ‘.32’	×	LongToInteger	×	Auto	Str\$, Mki\$, Mkrl\$ or Format\$
Real	×	RealToByte	RealToInteger	RealToLong	×	Str\$ or Format\$
String	×	×	Cvi, Cvir	Cvl, Cvlr	VAL	×

To extract a bit from a byte or integer, the function « .BitNum » can be used.

For a byte, BitNum is between 1 and 8, 1 is the least significant bit.

For an integer, BitNum is between 1 and 16, 1 is the least significant bit.

BitNum maybe a value or a byte variable.

To extract a byte from an integer, the function « .L » or « .H » can be used.

The « .L » function extract the least significant byte and « .H » the most significant byte.

Examples :

```

VarOctet=4
VarBit=VarOctet.3           ' VarBit=1
VarOctet=16
Index=5
VarBit=VarOctet.Index     ' VarBit=1
VarBit=1
VarOctet=VarBit           ' VarOctet=1
VarEntier=259
VarOctet=VarEntier.L      ' VarOctet=3
VarOctet=VarEntier.H     ' VarOctet=1
VarLong=261
VarReel=38.15
VarOctet=RealToByte (VarReel) ' VarOctet=38
VarBit=1
VarEntier=VarBit         ' VarEntier=1
VarOctet=128
VarEntier=VarOctet      ' VarEntier=128
VarLong=45200
VarEntier=LongToInteger (VarLong) ' VarEntier=45200
VarReel=54200.65
VarEntier=RealToInteger (VarReel) ' VarEntier=54200
VarBit=1
VarLong=VarBit          ' VarLong=1
VarOctet=128
VarLong=VarOctet        ' VarLong=128
VarEntier=45200
VarLong=VarEntier       ' VarLong=45200
VarReel=154200.65
VarLong=RealToLong (VarReel) ' VarLong=154200
VarOctet=128
VarReel=VarOctet       ' VarReel=128
    
```



```
VarEntier=45200
VarReel=VarEntier           ' VarReel=45200
VarEntier=154200
VarReel=VarEntier           ' VarReel=154200
VarChaîne= « -125.45 »
VarReel=Val (VarChaîne)     ' VarReel=-125 .45
VarReel=1510.55
VarChaîne=Str$(VarReel)     ' VarChaîne= « 1510.55 »
```

4-2-5- Numeric notations

Numeric values can be expressed in decimal, hexadecimal or binary.

Example :

```
VarOctet=254                ' decimal notation
VarOctet=0FEh               ' hexadecimal notation
VarOctet=11111110b         ' binary notation
```

4-3- Tasks

4-3-1- Multitask principles

The real time and multitask kernel can manage 32 tasks in parallel :

- ↳ 4 internal tasks reserved to the system
- ↳ 27 users tasks defines in pseudo-basic or ladder
- ↳ 1 extra task for the management of events

The multitask launches the next task if :

↳ the executed time of the task is longer than the task ageing time. This time is defined in the Options menu. All the task must be compiled after a modification.

↳ execute a lock instruction :

- ⇒ Wait, Delay
- ⇒ Beep, Edit
- ⇒ ClearFlash, FlashToRam, RamToFlash

↳ execute a loop or jump instruction :

- ⇒ Call
- ⇒ Goto, Case
- ⇒ For...Next
- ⇒ Repeat...Until
- ⇒ While...End While
- ⇒ End Prog

The Jump instruction make a jump without launching the next task.

In general, a short task will treat events faster than a big task.

4-3-2- Task priority

Each users task have a priority level : high priority, normal priority.

The multi-task kernel allocates two slices of execution : the high priority slice for the tasks with high priority, a normal priority slice for the tasks with normal priority.

The slice chain during execution is :

| high priority slice | normal priority slice | high priority slice | normal priority slice | ...

↳ High priority slice :

All the tasks with a high priority are executed one after one in this slice. Each task executes its instructions up to the ending condition (executes a locked task, ageing time reached ...).

Maximal execution time of a high priority slice = number of high priority task * ageing time

The ageing time is defined in the Options menus and is the same for the high and normal priority task. All the task must be compiled after a modification.

↳ Normal priority slice:

All the tasks with a normal priority are executed one after one in this slice. Each task executes its instructions up to the ending condition (executes a locked task, ageing time reached ...).

Normal slice execution time = Normal slice time

Maximal execution time of a normal priority slice = normal slice time + ageing time

The normal slice time is defined in the Options menus. All the task must be compiled after a modification.

If the execution time of all the normal priority tasks are lower than the normal slice time, all the tasks are executed one times and the high priority slice is executed.

In the opposite case, the system gives the hand at the high priority slice even if all the normal priority tasks aren't executed. These tasks will be executed in the next normal priority task.

Example :

T1, T2 : high priority tasks

T3, T4, T5, T6 : normal priority tasks

Ageing time = 2 ms

Normal slice time = 6 ms

The execution cycle will be | T1,T2 | T3,T4,T5 | T1,T2 | T6,T3,T4 | T1,T2 | T5,T6,T3 | ...

4-3-3- Management of task

Each task can have a starting mode defined at its creation :

↳ Automatic start : At each power on of SUPERVISOR, the task is launched automatically.

↳ Manual start : The task is not launched automatically.

A project must contain at least a task with automatic starting mode. You should have a task which have the initialization part and the launching task part.

There are 5 types of instructions to manage the tasks :

↳ Run : launch a task which is stopped.

↳ Suspend : suspend (pause) a task in execution

↳ Continue : continue the execution of a suspended task

↳ Halt : Stop an executed task

↳ Status : indicates the state of the task

```

Example :
Menus1 task           Menus2 task
Prog                 Prog
.....
Run Menus2           If Key = @ESC Then Halt Menus2
Wait Status(Menus2)=0
.....
.....               End Prog
End Prog
    
```


To synchronize the tasks each other, the Signal and Wait Event instructions or global variables can be used.

```

Example :
ProcessEnable : global bit variable
Process1 task   Process2 task
Prog           Prog
.....
ProcessEnable=1
Wait ProcessEnable=0
.....
.....
End Prog     ProcessEnable=0
.....
End Prog
    
```

4-3-4- Basic task structure

Each task is constituted with a main program defined with the key-word PROG and END PROG and with subroutine defined with the key-word SUB .. END SUB. For example :



Main program

The main program of a task can call all its subroutine but it can't call the subroutine of others tasks. A task is a file. In the last example, the task 1 can call the subroutine 1 and 2 but it can't call the subroutine 3 and 4. A subroutine of a task can call a subroutine of the same task.

One and only one PROG ... END PROG structure must be used by a program and may appear at any place in the program.

During the execution of the task, the execution of the key-word END PROG makes a branch on the key-word PROG.

Subroutine

A subprogram must be declared by a procedure SUB...END SUB. This procedure may be before or after the main program.

To call a subroutine, you should use the CALL function. The subroutine called must be in the same task.

After a subprogram call, the execution continues automatically with the instruction that follows the subprogram call. You can stop subprogram executions by using the EXIT SUB instruction.

For example :

```
SUB Calcul
Result%=0
IF b%=0 THEN EXIT SUB ' If b% is equal to zero , the division is impossible
Result%=a% DIV b%      ' Division
END SUB
```

A subroutine can be called anywhere in the program but it can't call itself. If datas are used in program and subroutine, you should use some specific variables. In fact, all the variable can be modified by a subroutine, you can assign the specific variables of a subroutine before it was called. For example :

```
...
Diviseur%=a%
Dividende%=b%
CALL Divise
IF Result!>10 THEN ...
...

SUB Divise
Resultat!=0
IF Diviseur%= 0 THEN EXIT SUB
  Resultat!= Dividende% / Diviseur%
END SUB
```

The branch to a subroutine launches the next task.

The instruction ICALL allow also to branch to a subroutine but without automatic tipping to next task.

Branch to a label

The GOTO instruction makes a branch to a label. A label is a name with at the end « : ». If the GOTO instruction is in a subroutine SUB...END SUB, the label must be in this subroutine.

A branch to a label with the GOTO instruction can be realized before or after the program. For example :

```
GOTO Label1
...
Label1:
...
```

With the GOTO instruction, the multitask kernel launches the next task.

The JUMP instruction have the same features as GOTO but the multitask kernel stays in this task.

Operators

The expressions are composed of operators and operands. In Basic, almost operators are binary, this means that they use two operands. Operators that use only one operand are called unary operands. Binary operators use common algebraic form, for example $A + B$. Unary operators come always before their operand, for example NOT A. In complex expressions precedence rules can suppress all ambiguity in operator order.

Operators	Priority	Type
NOT	First (High)	Unary
*, /, DIV, MOD, AND, <<, >>	Second	Multiplication
+, -, OR, XOR	Third	Addition
=, <>, <, >, <=, >=	Fourth (Low)	Comparison

The three fundamental rules concerning operators priority are :

↳ An operand placed between two operators whose one has priority will be linked to the higher priority operator.

↳ An operand placed between two operators whose priority are equal will be linked to the left operator.

↳ Expressions between brackets are evaluated separately, so results are used as operand.

Operators with same priority are usually used from left to right.

You should used brackets to separate each expression in order to highlight the priority.

```
IF ((INP(E1)=1) AND (FlagRun=1)) OR (InitOk=0) Then ...
```

a) Arithmetical operators

'NOT' operator is an unary operator. + and - operators are used as unary and binary operators. Other operators are only binary operators.

An unary operator has only one parameter. For example :

NOT <Expression>

A binary operator has two parameters. For example :

<Expression1> * <Expression2>

b) Binary operators

Operator	Operation	Operand type	Type
+	Addition	Byte, Integer, Long integer or real	Operand type
-	Substraction	Byte, Integer, Long integer or real	Operand type
*	Multiplication	Byte, Integer, Long integer or real	Operand type
/	Division	Byte, Integer, Long integer or real	Operand type
DIV	Integer division	Byte, Integer, Long integer or real	Operand type
MOD	Modulus	Byte, Integer, Long integer or real	Operand type

c) Unary operators

Operator	Operation	Operand type	Type
+	Same sign	Byte, Integer, Long integer or real	Operand type
-	Invert sign	Byte, Integer, Long integer or real	Operand type

d) Logical operators

Operator	Operation	Operand type	Type
NOT	Binary negation	Byte, Integer	Operand type
AND	Binary AND	Byte, Integer	Operand type
OR	Binary OR	Byte, Integer	Operand type
XOR	Exclusive OR	Byte, Integer	Operand type
>>	Right shift	Byte, Integer	Operand type
<<	Left shift	Byte, Integer	Operand type

e) Bits operators

Operator	Operation	Operand type	Result type
NOT	Binary negation	Bit	Bit
AND	Logical AND	Bit	Bit
OR	Logical OR	Bit	Bit
XOR	Exclusive OR	Bit	Bit

f) String operators

Operator	Operation	Operand type	Result type
+	Concatenation	Char string	Char string

g) Relationship operators

Operator	Operation	Operand type	Result type
=	Equal	Byte, Integer, Long integer, real, string	Bit
<>	Different	Byte, Integer, Long integer, real, string	Bit
<	Lower	Byte, Integer, Long integer, real, string	Bit
>	Greater	Byte, Integer, Long integer, real, string	Bit
<=	Lower or equal	Byte, Integer, Long integer, real, string	Bit
>=	Greater or equal	Byte, Integer, Long integer, real, string	Bit

B) Tests**a) Simple tests**

Conditional instructions provide a simple way to choose which part of code will be executed in accordance to a condition. There are two syntax. IF instruction syntax are :

```
IF <Expression> THEN
  <Instruction1>
  ...
[ELSE
  <Instruction2>
  ...]
END IF
```

or

```
IF <Expression> THEN <Instruction1> [ELSE <Instruction2>]
```

<Expression> must be a bit type value. If <Expression> is true then <Instruction1> and following instructions are executed. If <Expression> is false then <Instruction2> and following instructions are executed. In the second syntax form, only one instruction is executed for each condition, all instructions are in the same line and END IF statement is omitted. Nesting if instructions are possible but an ELSE always refers to the nearest IF instruction.

b) Multiple tests

Multiple tests are performed with CASE instruction.

CASE instruction syntax is described below :

```
CASE <Expression> [ GOTO | CALL ] <Subrout1. Identif. > [ { , <Subrout2. Identif.> } ]
```

<Expression> type must be byte, integer or long integer. With this instruction, subroutines will be called in accordance to <Expression> value. For <Expression>=1 the first subroutine is called, for <Expression>=2 the second subroutine is called ... For example :

```
REPEAT
INPUT #1,Choice%      'Read choice from serial peripheral device
ON Choice% CALL FirstChoice, SecondChoice, ThirdChoice
UNTIL Choice%=0
GOTO FIN
SUB First Choice      ' Called if the first choice is selected
END SUB

SUB SecondChoice     ' Called if the second choice is selected
END SUB

SUB ThirdChoice      ' Called if the third choice is selected
END SUB
FIN :
```

c) Loops

If the loop number is already known when writing your program, it is recommended to use the FOR loop structure, in other case WHILE or REPEAT structures can be used.

FOR instruction

FOR instruction allows the repeated execution of one or more instructions in accordance to a control variable increment or decrement .

FOR instruction syntax is described below :

```
FOR <Counter>=<Start> TO <End> [STEP <Increment>]
    <Instructions>
NEXT <Counter>
```

<Counter> must be a local byte, integer or long integer variable. <Start>, <End> and <Step> are <counter> type compatible expressions. <Start>, <End> and <Step> expressions are computed only one time before starting loop.

<Counter> is affected to <Start> value at the beginning. At each loop <Step> value is added to <Counter> and if <Counter> is greater than <End> then loop is stopped.

For example

```
FOR a%=0 TO 15
OUT (IO1)=1<<a%
NEXT a%
```

At each execution of NEXT instruction, the multitask kernel launches the next task.

WHILE instruction

WHILE instruction allows the repeated execution of one or more instructions in accordance to an expression value.

WHILE instruction syntax is described below:

```
WHILE <Expression> DO
    <Instructions>
END WHILE
```

In this instruction, if <Expression> is false before the WHILE structure beginning there is no loop. While <Expression> is true <Instructions> are executed.

At each execution of END WHILE instruction, the multitask kernel launches the next task.

REPEAT instruction

REPEAT instruction allows the repeated execution of one or more instructions in accordance to an expression value.

REPEAT instruction syntax is described below :

```
REPEAT
<Instructions>
UNTIL <Expression>
```

In this instruction, if <Expression> is right before the REPEAT structure beginning, there is one loop. <Instructions> are executed until <Expression> is right.

At each execution of UNTIL instruction, the multitask kernel launches the next task.

4-3-5- Event task structure

Each extra task can manage about 16 events : 7 PLC inputs, 8 capture input and 1 timer.

Extensive events , tie to standard axis's board, are also free (see chapter [Enhanced Event Function](#)).

This task is defined once times in a project. When you want to create one, you must chose the event start mode.

Events configuration

At each power on of SUPERVISOR, no events are configured. This configuration is realized in a normal basic task (initialization task) with the MODIFYEVENT instruction.

Syntax : MODIFYEVENT– Events configuration

Syntax : MODIFYEVENT (<Mask>,<Counter 1 trigger>,<Counter 2 trigger>,<Delay>)

Limits : <Delay> : 10ms to 30.000ms

Accepted types : <Mask> : Integer

<Counter 1 Trigger> : Integer

<Counter 2 Trigger> : Integer

<Delay> : Integer

Description : This instruction allows to configure events.

Remarks : <Mask> :

↳ Bits 0...7 : Activate the inputs 1 to 8 of the input card. A positive edge will generate the event. The input take account of the invert and filter parameters entered during the board configuration.

↳ Bit 8 : Trigger of the counter 1 reached

- ↳ Bit 9 : Trigger of the counter 2 reached
- ↳ Bit 10 : SDOEvent
- ↳ Bit 11 : PDOEvent
- ↳ Bits 12 : Time base.

<Delay> :

Delay of the time base between 10 ms and 30000 ms. If the time base is unused, the value of delay will be not treated.

When the event configuration register is affected, the event task is executed when at least one event is detected. The maxi time between the event detected and its treatment is equal to the task ageing time.

If you want to modify the event configuration register, you'll be treated this instruction in a normal basic task or an event task before the execution of GETEVENT instruction.

Reading the events detected

The GETEVENT instruction is consumed and read the events detected.

Syntax : <Variable>=GETEVENT

<Variable> is an integer type with the same configuration of bits like the <Mask> parameter of MODIFYEVENT instruction.

Each bit assign to an event is set when the event is detected.

If an event appears during the execution of the event task, it is stored and treated as possible.

Clearing the events

The clearing of events is obtained with MODIFYEVENT(0,0) instruction.

Warnings

The RUN, HALT, SUSPEND, CONTINUE, STATUS instructions didn't have any effects on event task.

This task don't give the hand to the other task. So, it must be a short task with no locked instructions (ex : WAIT, ...).

This task mustn't have branch. The END PROG instruction must appear at the end of the task to launch the event detection again.

If the MODIFYEVENT instruction is used in an event task, a new detected event can be changed.

Example

```
Init Task
  PROG
  ....
  MODIFYEVENT(0183H,1000)      'events E1, E2, 1s time base,
  ....                          'Capture1 on axis board 1
  END PROG

Tâche EVENEM
  PROG
  Event%=GETEVENT
  IF Event%.1=1 THEN          'événement E1
  .
  .
  END IF
  IF Event%.2=1 THEN          'événement E2
  .
```

```
.
END IF
IF Event%.8=1 THEN    `événement base de temps
.
.
END IF
IF Event%.9=1 THEN    `événement capture 1
.
.
capture1(...)        `relance la capture
END IF
END PROG
```

4-3-6- Ladder task structure

It's a chart form which is composed with rungs. Each rungs can contain contacts, coils, counters and timers.

Free contact or free coil can also be added to the ladder task.

At the compile phase, the ladder task is translated in a basic task. This basic task can be displayed on a windows editor : file « LadderTaskName.tsk ».

5- PROGRAMMATION OF PLC

5-1- Basic task

5-1-1- Digital inputs/outputs

A) Inputs reading

The INP function is used to read 1 bit , INPB a 8 bits bloc and INPW a 16 bits bloc.

The syntax are : INP(<Digital inputs>), INPB(<Digital inputs>), INPW(<Digital inputs>).

<Digital inputs> must represent a valid digital input identifier of 1,8 or 16 bits. This identifier can be either a symbolic name used in the setup module or the hardware name of the bloc. The return data type is :

- Bit for 1 input bloc
- Byte for 8 inputs bloc
- Integer for 16 inputs bloc

For example :

```
A~ = INP(Sensor)           'input reading
B1# = INPB(Bloc1)         'First bloc of eight input reading
B2# = INPB(Bloc2)         'Second bloc of eight input reading
C%= INPW(A)               'Bloc of sixteen input reading
```

B) Outputs writing

The OUT function is used to write 1 bit , OUTB is used to write a 8 bits bloc and OUTW is used to write a 16 bits bloc .

The syntax are : OUT(<Digital outputs>), OUTB(<Digital outputs>), OUTW(<Digital outputs>)

<Digital outputs> must represent a valid digital output identifier of 1, 8, 16 bits. This identifier can be either a symbolic name used in the setup module or the hardware name of the bloc. The return data type is :

- Bit for 1 output bloc
- Byte for 8 inputs bloc
- Integer for 16 inputs bloc

For example :

```
OUT(Jack)=On              'Output writing
OUT(LAMP)=Defaut.5
OUTB(Data)=00110000b      'Bloc of eight inputs writing
OUTW(B)=0FFFFh           'Bloc of sixteen inputs writing
```

C) Outputs reading

All outputs can also be read. The reading value is the last written value. This feature is very useful when more than one program are using the same output bloc. So, it is possible to write only desired outputs in one operation without changing the others.

For example :

To put 1 on the fourth lower bit of a 8 bits output bloc named IO1, use the following program :

```
OUTB(Bloc1)=OUTB(Bloc1) OR 00001000b      'set of the fourth bit of a eight
                                             'inputs bloc
```

D) Events handling

We can wait for a state change on an input with the function WAIT.

The syntax is : WAIT <Condition>

The WAIT function is used to handle a special state condition during a normal execution. The execution is stopped as long as condition is false. When the state condition is true, the execution continues. This function is very useful to wait for end of movement or mechanical thrusts sensor...

Example :

```
WAIT Lim_S(Cutter)=On      'Waiting for a soft thrust error
Stop(Cutter)               'Axis stop
WAIT Inp(StartButton)=On  'waiting for StartButton pressed
```

E) State test

We can test the input state with the structure IF...THEN...ELSE.

The syntax is : IF (<Condition>) THEN <Action1> ELSE <Action2>

The IF...THEN...ELSE structure is used to test a condition at a given time. If <Condition> is true then the <Action1> is executed otherwise the <Action2> is executed.

Example :

```
IF (Inp(Start)=On) THEN      'Input state test
    Out(StartLed)=On
    RUN Cycle
ELSE
    Out(StartLed)=Off
    HALT Cycle
ENDIF
```

5-1-2- Timings

A) Passive waiting

The DELAY function is designed to make a passive waiting.

Its syntax is : DELAY <Duration>

<Duration> is a long integer expressed in millisecond. It is recommended using this function for a long passive waiting because the waiting program doesn't spend any processor time.

With this function, the program is waiting the indicated duration.

For example:

```
Debut:
WAIT Inp(Start)=ON
...
DELAY 5000          ' 5 seconds delay
...
GOTO Debut
```

B) Active waiting

TIME

The internal global variable TIME is designed to make active waiting of time. This variable is a long integer that represents the number of milliseconds passed since power-on. This variable can then be used as time base for machines which are powered on less than 24 days. At the power on, the variable is equal to zero. Up to 24 days, the variable is at its maximum value 2^31

and passed to its minimal value 2^{-31} . This overflow can make some timer errors. In that case, you must use the global variable `TIMER`.

For example :

```
EndDelay& = TIME+5000      'timer of 5s is loaded
WHILE TIME<EndDelay& DO
  ...                    'Loop during 5s
END WHILE
EndTimeOut& = TIME+200
WAIT (Inp(Sensor)=On) Or (Time>EndTimeOut&)      'Waiting for sensor or
                                                    '200ms time-out
```

TIMER

The internal global variable `TIMER` is designed to make active waiting of time. This variable is a real that represents the number of milliseconds passed since power-on. This variable can then be used as time base for machines which are always powered on. The integer part of the global variable is the seconds and the decimal part (3 figures after the point) is the milliseconds.

Par example :

```
EndDelay! = TIMER+5.250   'timer of 5.25s is loaded
WHILE TIMER<EndDelay! DO
  ...                    'Loop during 5.25s
END WHILE
EndTimeOut! = TIMER+0.200
WAIT (Inp(Sensor)=On) Or (TIMER>EndTimeOut&)      'Waiting for sensor or
                                                    '200ms time-out.
```

5-1-3- Events

In a multi-tasking system, events mechanism are very useful for inter-process communication. Event handling may also provide process control functions. Event handling instruction allows sending, waiting and receiving events. Programs can wait for or sent the same event. In the programming language, there are two mechanisms for events functions.

Signal or Diffuse and Wait Event

↳ To send an event to only one task, there is the `SIGNAL` function. To send an event to all the tasks, there is the `DIFFUSE` function.

Syntax : `SIGNAL <EventName>` or `DIFFUSE <EventName>`

The `<Eventname>` can be any non-keyword name but must be used at least once in an event waiting or receiving function.

`SIGNAL` sends the event to the first task which is waiting it. But, `DIFFUSE` sends the event to all the tasks which are waiting it.

↳ The `WAIT EVENT` instruction is used to wait an event.

The syntax of the `WAIT EVENT` instruction is :

`WAIT EVENT <EventName>`

After `WAIT EVENT` instruction, program execution is paused and will be resumed when event is received.

Example with `SIGNAL` and `WAIT EVENT`:

```
'Master task          'Slave task
PROG                  PROG
...
RUN SlaveTask        Beginning:
...                  ...
WAIT Inp(StartCycle)=On  ...
...                  ...
```

```

SIGNAL Start
...
...
WAIT Inp(StopCycle)=On
HALT SlaveTask
...
END PROG

```

```

WAIT EVENT Start
GOTO Beginning
END PROG

```

In this example, there is a master task that controls slave task execution. Master task is waiting for start button pressed state. When this state is reached, the master task starts slave task by sending start event. If stop button is pressed, master task handles this state and stops slave task. Slave task is idle and waiting for the start event. When this event is received, slave task executes a loop.

Example with DIFFUSE and WAIT EVENT:

```

'Master Task
PROG
...
RUN SlaveTask
...
WAIT Inp(StartCycle)=On
...
DIFFUSE Start
...
...
WAIT Inp(StopCycle)=On
HALT SlaveTask
...
END PROG

```

```

'Slave task
PROG
Beginning:
...
...
...
WAIT EVENT Start
GOTO Beginning
END PROG

```

This example is the same like the last example but used the DIFFUSE instruction.

Wait

The second mechanism which waits an event is the WAIT instruction. This instruction doesn't allow the execution of the task if the expression is not valid. The Wait instruction used a global variable or an input. To send an event, you must assign a value to the global variable in another task.

The example below is the same like the SIGNAL and WAIT EVENT example but with the mechanism of WAIT :

```

'Master Task
WAIT Inp(StartCycle)=On
...
SignalVariable=1
...

```

```

'Slave Task
...
...
WAIT SignalVariable=1
SignalVariable=0

```

This mechanism has an execution time longer than the other mechanism. The initialization of the global variable is an extra time in the execution.

5-1-4- Counters

The SUPERVISOR has two 16 bits counters. Each inputs card SIO can be assign to a counter.

' Warning :

- When the counter is at its maximum value, the counter is initialized to zero at the next edge.(maximum value : 65535)

Configuration

SETUPCOUNTER instruction allows the counter configuration.

Syntax : **SETUPCOUNTER**(<Counter>,<Input>,<Invert>,<DesactivateFilter>)

Accepted types : <Counter> : 1 or 2

<Input> : Byte

<Invert>, <Filter> : bit

Description : This instruction defines the counter configuration

Remarks : <Counter> : Counter number (1 or 2)

<Input> : Input number of the input card

<Inversion> : edge choice : 0 for a positive edge, 1 for a negative edge

<DesactivateFilter> : 1 without filter, 0 for a 2ms filter.

If the filter isn't activating, the maximum frequency is 1.5 KHz. Else, the maximum frequency is 200 Hz.

Clear

CLEARCOUNTER instruction initializes the counter to zero.

Syntax : **CLEARCOUNTER**(<Counter>)

Accepted types : <Counter> : Byte

Description : This instruction initialise the counter to zero.

Remarks : <Counter> : Counter number (1 or 2)

Read

COUNTER_S allows the reading of the counter.

Syntax : <Variable>=**COUNTER_S**(<Counter>)

Accepted types : <Variable> : Integer

<Counter> : Byte

Description : This instruction reads the counter

Remarks : <Counter> : Counter number (1 or 2)

5-1-5- Enhanced PLC Function

Présentation

The PLC functions (Enhanced PLC) allow to integrate the functioning of a PLC in a multitasks basic program. Like this, we warrant that the I/O used in this tasks are handle as a PLC. The inputs are memorised in bit's copy before to be treated, the ouputs to modify are memorised before to be update.

Utilisation du PLC

The PLC use tables to memorize the status of I/O. Two tables of long integer for inputs and two tables of integer for outputs.

The function PlcReadInputs read the status of inputs, after to have memorized theirs old status, to allow detection of edge.

The function PlcInp, PlcInpb, PlcInpw, PlcInpPe and PlcInpNe allow to read the status of inputs and detect edges.

The functions PlcOut, PlcOutB and PlcOutW modify bit's copy of outputs.

The function PlcWriteOutputs write the status of bit's copy on physical outputs.

Exemple

In this exemple, the outputs's blocks are used to count positive and negative edge of a input.

PROG

‘ on utilise toutes les sorties

Masque[1]=0FFFFh

Masque[2]=0FFFFh

‘ on initialise le PLC

PlcInit(Entrees,EntreesOld,Sorties,Masque)

Repeat

‘ lecture des entrées

PlcReadInputs

‘ détection des fronts montants

If PlcInpPe(I1) Then

PlcOutB(JL)=PlcOutB(JL)+1

End If

‘ détection des fronts descendants

If PlcInpNe(I1) Then

PlcOutB(JH)=PlcOutB(JH)+1

End If

‘ écriture des sorties

PlcWriteOutputs

Until False

END PROG

5-2- Ladder task


5-2-1- Presentation

Each ladder task is defined with rungs. The number of rungs is limited to 50 for a task. A rung is defined by one or more coils and only one expression. Then, coils of a same rung have the same expression. A rung can have a maximum of 5 coils or contact in parallel and 10 contact in serial.

Attention : A ladder task is automatically traduct in basic. It's advise to not write a long or complex ladder task, in order to avoid time cycle deteriorations and basic traduction limit.

5-2-2- Contacts, coils, timers and counters


Contacts



An input name, output name or bit name can be assigned to a contact. A system bit name can be assigned only to a normal or invert contact.

- ↳ Normal contact : The state of the contact is the state of the variable assigned.
- ↳ Invert contact : The state of the contact is the invert state of the variable assigned.
- ↳ Contact with positive edge detection : The state of the contact is true when the assigned variable is in the transition state : false to true.
- ↳ Contact with negative edge detection: The state of the contact is true when the assigned variable is in the transition state : true to false.


Coils



An output name or a bit name can be assigned to a coil. An input name or a system bit can't be assigned to it.

- ↳ Normal coil : The state of the coil is the state of the expression assigned.
- ↳ Invert coil : The state of the coil is the invert state of the expression assigned.
- ↳ Coil with SET action : The state of the coil is true when the expression is true. The state of the coil is false when the Reset coil is activated.
- ↳ Coil with RESET action: The state of the coil is false when the expression is false. The state of the coil is true when the Set coil is activated.

Counters up or down



The counters up or down have two inputs and an output. Each counters up or down is defined with a name and a pre-selected value. This pre-selected value may be a fixed value or a global variable. With a global variable, you can modify it at any time during the execution. When you used a counter up or down, you must link the counter output to a coil even if the coil is not used.

↳ Up counter : CUP is the counter up input. On a positive edge detected on this input, the counter up variable is incremented. When the value of the counter up variable is greater or equal to the pre-selected value, the counter up output is true. The RST input has priority. When this input is true, the counter up variable is initialize to zero. At the power on, the counter up value is equal to zero.

↳ Down counter : CDN is the counter down input. On a negative edge detected on this input, the counter down variable is decrements. When the value of the counter down variable is lower or equal to zero, the counter down output is true. The RST input has priority. When this input is true, the counter down variable is initialize to the pre-selected value. At the power on, the counter up value is equal to the pre-selected value.

The counter up or counter down variable can be treated and modify in another basic task : `<CounterName> + <&>`.

Example : Counter name : Counter1
Counter up Local Variable : Counter1&

Timer


The timers are all on delay timing (TON). The delay may be a fixed value or a global variable. All the timers uses the TIMER instruction. When you used a timer, you must link the timer output to a coil even if the coil is not used.

The variable used with the timer can be treated in another basic task. Its syntax is : `<Bloc Name> + <TVAL!>`. This variable represents the remaining delay since the activation of timer.

Example : Timer name : Timer1
Variable : Timer1Val!

↳ On delay timing (TON) :


Example :



↳ Off delay timing (TOFF) :

To make this type of timer, you must use an invert coil with the triggering expression in a first rung. In the second rung, you use the contact with the same variable as the coil in the last rung and a timer and another invert coil.

Example :



5-2-3- Free contact and coil



This type of contact and coil provides more capabilities for the ladder. This type of contact and coil are : the free contact and the free coil.

↪ Free contact : With this type of contact, you can test all type of variables (Ex :byte, Integer, long integer, real or string). We can make test with movement instructions (Ex : MOVE_S(X),...). In this contact, you must only edit your expression to test with the bracket. (Ex : (MOVE_S(X)=1) And (POS(X)>2000))

↪ Free coil : This type of coil allows you to execute any sort of instruction like movement instruction... With this coil, you can assign all types of variables. (Ex :byte, Integer, long integer, real or string). In this coil, you must only edit the instruction. (Ex : STTA(X=100,Y=150))


' **Warning** : Don 't use passive wait instruction. This type of instructions stops and affects the ladder task evolution (Ex : MOVA, WAIT,...).

5-2-4- System bits

- ↪ Initialization bit : This bit is true on the first cycle of the ladder task.
- ↪ Blink 0.5s : The state of this system bit changes between 0 and 1 every 0.5s.
- ↪ Blink 1s : The state of this system bit changes between 0 and 1 every 1s.

5-2-5- Task architecture

This is the architecture of the ladder task :



With this architecture, the state of inputs is loaded before the treatment of equations. The outputs are updated only once times per cycle.

The multitask allows the ladder task to be suspended at any times of the execution cycle.

6- PROGRAMMATION OF SERIAL1/SERIAL2 COMMUNICATION PORTS

6-1- Introduction

SUPERVISOR have an RS232 communication port on Serial1. This communication port is used to send or receive the configuration, variables, tasks... between PC and SUPERVISOR.

A second optional serial port RS232 or RS485 can be installed on Serial2.

These 2 ports can be treated in basic tasks. With the port, we can open or close it or reading or writing data.

The function of conversion like MKI\$, CVI, MKL\$, CVL... can be used to optimize the coded and decoded of message.

6-2- Opening a communication port

To open a communication port Motion Control Basic provides the OPEN instruction. OPEN instruction has the following syntax :

```
OPEN <Communication port> AS # <CommNumber>
```

<Communication port> is a string that identifies physical communication port name and setup. <CommNumber> is the number used to identify the opened communication port . This number will be used by READ, WRITE and CLOSE functions.

<Communication port>string can be decomposed in five parts :

```
"SERIAL2:[Speed[, Data[, Parity [, Stop ] ] ]]"
```

↳ Speed : Communication speed (150, 300, 600, 1200, 2400, 4800 or 9600 b/s)

↳ Data : Number of data bits (7 or 8)

↳ Parity : Parity checking mode (E for Event, O for Odd, M for Mask, S for Space or N for None)

↳ Stop : Number of stop bits (1 or 2)

The string must respect the parameters order. Speed, data, parity and stop parameters are optionals. When the task is compiled and if the parameters are not defined, the system takes the default parameter defined in the configuration screen. (double-click on the SUBD of the Serial communication port).

Example :

```
OPEN «SERIAL2 :9600,8,N,1" AS #1 ' SERIAL2 is opened to communicate
```

When a port is open by a task, this port can't be opened again by another task. But a communication port open can be read or written by any other task.

A communication port must be open before the reading or writing of data.

You should reserve the Serial1 to the downloading between SUPERVISOR and PC. Otherwise, you need to manipulate the plugs.

If Serial1 is used in a task, you should execute the « Stop task » command before the downloading.

6-3- Reading data

⇒ Received buffer

Each serial port have a received buffer with 500 bytes length

If the buffer is full (500 characters are received and unread), the new received characters clear the first one.

The CLEARIN instruction clears this buffer.

The CARIN instruction returns the number of characters in the buffer.

To read data, there are two instructions : INPUT and INPUT\$.

The INPUT instruction waits the data and assigns the received data to variables.

The syntax is : INPUT #<ComNumber>, <Variable> [{, <Variable> }]

<ComNumber> is the number specified in the OPEN instruction. The reading data must come in the order of the variable list and with the same type.

For example :

```
OPEN "SERIAL1:" AS #1      ' Open the serial port 1 affected to canal 1
INPUT #1, B$, C%          ' Read a string and an integer
CLOSE #1                  ' Close the serial port
```

For all the numeric variables of the list, the beginning of the number is detected when the first character is not a space character. The end of the character is detected with a space, a comma or a carriage return character. An underscore character is a zero. If the numeric variable is not valid, the variable takes the zero value.

For all the string variables of the list, the beginning of the string is detected when the first character is not a space character. The end of the character is detected with a space, a comma or a carriage return character. An underscore character is a string with a string length equal to zero.

The INPUT\$ instruction reads some characters on the communication port and stores them in a string char. The syntax is :

<StringcharVariable> = INPUT\$ (#<ComNumber>, <LengthOfCharacters>)

This two instructions stop the task as long as the number of received characters is not valid.

6-4- Writing data

⇒ Transmit buffer

Each serial port have a transmit buffer with 500 bytes length

The characters, which are sent by a task with the PRINT instruction, are send to the transmit buffer. These characters are transmitted one after one on the serial link.

If the transmit buffer is full (500 characters in the buffer), the task, which wants to send data, is suspended as long as the transmit buffer is full.

The CLEAROUT instruction clears the buffer.

The CAROUT instruction returns the number of characters in the transmit buffer.

The OUTEMPTY instruction indicates if the buffer is empty and the last character is sent.

The PRINT instruction converts data and send them. The syntax is :

PRINT #<ComNumber>, <Expression> [{ [; | ,] <Expression> }] [; | ,]

<ComNumber> is the number specified in the OPEN instruction.

For example :

```
OPEN "SERIAL1:" AS #1      ' Open the communication port 1
...
PRINT #1, A$, B%;          ' Send a string of char and an integer
PRINT #1, C$,
```

```
PRINT #1,CHR$(10) ;MESSAGE1$ ; ` ASCII 13D is not sent after MESSAGE1$
PRINT #1,CHR$(10) ;MESSAGE2$ ` ASCII 13D is sent after MESSAGE2$
...
```

A semicolon between two expressions signifies that the next character is sent immediately after the last character. A semicolon at an end line signifies that the extra ASCII character 13D is not sent.

A comma signifies that the character is sent at the beginning of the next line. If there is no expressions list after the PRINT expression, the ASCII Character 13D is sent.

If the parameter #1 or #2 is not specified, the system send the data on #1.

6-5- Close a communication port

To close a communication port, there is the CLOSE instruction. The syntax is :

```
CLOSE #<CommNumber>
```

6-6- RS485 treatment

With a RS232 communication port, SUPERVISOR can communicate with only one peripheral system. But, with the RS485 communication port, SUPERVISOR can communicate with more than one peripheral system.

To send a message with a RS485 communication port, SUPERVISOR must drive the communication line.

The TX485 instruction permits SUPERVISOR to take the line during a given number of character. When a character is sent, the TX485 value is decrements. When this value reaches zero, the line is automatically given back.

Warning : Each character sent is received by the SUPERVISOR as the TX485 value is different to zero.

Example :

```
.....
Message$= « Motion Control System »
TX485(#1)=Len(Message$)
PRINT #1,Message$ ; ` Take the line during the sending of Message$
CLEARIN #1 ` Clear the echo characters
```

6-7- Example: RTU Modbus driver

```
SLAVE232 Task
Prog
` ***
` *** DRIVER MODBUS ESCLAVE RS232 ***
` ***
`-----
` *
` * INITIALISATION *
` *
`
` WARNING!!! =>Defined in global stored variables :
` TableModbus type:integer number:255
`
NumeroSUPERVISOR#=1 'number of the SUPERVISOR
TimeOut&=10 '10ms maximum delay between 2 received characters
`
AdressModBus%=600 'Start address of the table
NumberModbus%=300 'Number of words in the table
` init maintenance counters
CmtMessage&=0
ErrLiaison&=0
```

```

ErrAdresse&=0
ErrData&=0
'Open serial2
Open "Serial2:9600,8,N,1" As #2
Clearin #2 'Clear the rxd buffer
TempoRxd&=Time
'-----
' *
' * RECEIVE *
' *
InitRxd:
PtrRxd#=0
Rxd$=""
'
WaitRxd:
If Carin(#2)<>0 Then Jump ReadRxd
If PtrRxd#=0 Then Goto WaitRxd
If Time>TempoRxd& Then Goto InitRxd
Goto WaitRxd
'
ReadRxd:
TempoRxd&=Time+TimeOut&
If PtrRxd#>=2 Then Jump MessageRxd
If PtrRxd#=1 Then Jump Car2Rxd
Car1Rxd:
CarRxd$=Input$ #2,1
Car1tRxd:
NumSUPERVISOR#=Asc(CarRxd$)
If (NumSUPERVISOR#<>NumeroSUPERVISOR#) And (NumSUPERVISOR#<>0) Then Jump
InitRxd
PtrRxd#=1
Rxd$=CarRxd$
Jump WaitRxd
Car2Rxd:
CarRxd$=Input$ #2,1
NumFonction#=Asc(CarRxd$)
If (NumFonction#<>3) And (NumFonction#<>4) And (NumFonction#<>16) Then Jump
Car1tRxd
PtrRxd#=2
Rxd$=Rxd$+CarRxd$
Jump WaitRxd
MessageRxd:
CarRxd$=Input$ #2,Carin(#2)
PtrRxd#=PtrRxd#+len(CarRxd$)
If PtrRxd#>240 Then Jump InitRxd
Rxd$=Rxd$+CarRxd$
If NumFonction#=16 Then
If PtrRxd#<7 Then Jump WaitRxd
If PtrRxd#<(Asc(Rxd$,7)+9) Then Jump WaitRxd
Rxd$=Left$(Rxd$,Asc(Rxd$,7)+9)
Else
If PtrRxd#<8 Then Jump WaitRxd
Rxd$=Left$(Rxd$,8)
End If
'
TraitementMessage:
Sum$=Left$(Rxd$,Len(Rxd$)-2)
Sum%=Crc(Sum$)
Sum$=Mki$(Sum%)
If Sum$<>Right$(Rxd$,2) Then Jump ErreurLiaison
AdrBus%=Cvir(Mid$(Rxd$,3,2))
NbrBus#=Asc(Rxd$,6)
If (NbrBus#=0) Or (NbrBus#>100) Then Jump ErreurAdresse
If AdrBus%<AdresseModbus% Then Jump ErreurAdresse
A1%=AdrBus%+NbBus#
A2%=AdresseModbus%+NombreModbus%
If A1%>A2% Then Jump ErreurAdresse
If NumFonction#=16 Then Jump WriteWord

```

```

'-----
'
' reading words
'
ReadWord:
  If NumSUPERVISOR#<>NumeroSUPERVISOR# Then Jump ErreurLiaison
  Txd$=""
  I#=1
  A%=(AdrBus%-AdresseModbus%)+1
ReadWordBcl:
  Txd$=Txd$+Mki$(TableModbus[A%])
  A%=A%+1
  I#=I#+1
  If I#<=NbrBus# Then Jump ReadWordBcl
  Txd$=Chr$(Len(Txd$))+Txd$
  CmtMessage&=CmtMessage&+1
  Jump MessageTxd
'-----
'
' Write Words
'
WriteWord:
  I#=1
  J#=0
  A%=(AdrBus%-AdresseModbus%)+1
WriteWordBcl:
  TableModbus[A%]=Cvir(Mid$(Rxd$,8+J#,2))
  A%=A%+1
  I#=I#+1
  J#=J#+2
  If I#<=NbrBus# Then Jump WriteWordBcl
  Txd$=Mid$(Rxd$,3,4)
  CmtMessage&=CmtMessage&+1
  Jump MessageTxd
'-----
' *
' * TRANSMIT *
' *
' Erreurs
ErreurLiaison:
  ErrLiaison&=ErrLiaison&+1
  Jump InitRxd
ErreurAdresse:
  NumFonction#=NumFonction#+128
  Txd$=Chr$(2)
  ErrAdresse&=ErrAdresse&+1
  Jump MessageTxd
ErreurData:
  NumFonction#=NumFonction#+128
  Txd$=Chr$(3)
  ErrData&=ErrData&+1
  ' Send message
MessageTxd:
  Clearin #2 'clear rxd buffer
  If NumSUPERVISOR#=0 Then Jump InitRxd
  Txd$=Chr$(NumSUPERVISOR#)+Chr$(NumFonction#)+Txd$
  Sum%=Crc(Txd$)
  Print #2,Txd$+Mki$(Sum%);
  Jump InitRxd
'
End Prog

```


7- PROGRAMMATION OF DISPLAY/KEYBOARD

7-1- Supervisor description

7-1-1- Supervisor 640 :

Screen

- ↪ LCD display with CFL backlight
- ↪ Display area 122×66 mm
- ↪ Characters attributes : normal, reverse, blinking
- ↪ ASCII protocol
- ↪ Resolution in graphic mode : 240×128 pixels
- ↪ 4 simultaneous sizes of characters in text mode :
 - ⇒ 3×4 mm 16 lines × 40 characters
 - ⇒ 4×7 mm 9 lines × 30 characters
 - ⇒ 5×8 mm 8 lines × 26 characters
 - ⇒ 7×10 mm 6 lines × 17 characters

Keypad

- ↪ 33 keys with tactile feedback
- ↪ 6 dynamic function keys
- ↪ 6 rewriteable function keys with integrated leds
- ↪ Control and scrolling keys
- ↪ Help and alarm keys
- ↪ Numeric and alphanumeric keys
- ↪ Buzzer

7-1-2- Supervisor 80 :

Screen

- ↪ 4×20 Characters LCD display with backlight
- ↪ Display area 74×23 mm
- ↪ Characters attributes : normal, blinking
- ↪ ASCII protocolKeyboard
- ↪ 28 keys with tactile feedback
- ↪ 4 dynamic function keys
- ↪ 6 rewriteable function keys with integrated leds
- ↪ Control and scrolling keys

7-2-2- Keyboard

We have two functions and a system variable to use the keyboard.

↳ The function `Inkey` allows to read a key and to stock its code in a type byte variable. If no key is pressed before the function call, this one returns 0.

The syntax is the following : `<Variable>=INKEY`

Example :

```
Waiting:
K#=INKEY
IF K#=0 Then Goto Waiting
IF K#=@F1 Then Goto MenuF1
IF Inp(StartButton)=On Then Goto Start
Goto Waiting
```

↳ The `WAIT KEY` function allows to wait for pressing a key and stocking then the key code in the system variable `KEY`. Contrary to the previous function, this function is locking the task as long as any other key is pressed. The syntax is : `WAIT KEY`

↳ Endly, the system variable `KEY` contains the code of the last key pressed in the functions `WAIT KEY` or `EDIT`. This variable is local to the task and can't be written.

Example :

```
WAIT KEY ' Key waiting
IF KEY=@F1 THEN GOTO ...
IF KEY=@F2 THEN GOTO ...
...
```

7-2-3- Edit

The `SUPERVISOR` allow, via the `EDIT` function, to type a real with or without sign and point, displaying it on an exact place on the screen. In the instruction's line, we choose the number of characters in the real variable, the line and row number of the first character. we can as well say if yes or no (0 or 1) we use the sign and/or the point.

The syntax is : `<Variable> = EDIT(<Line>,<Row>,<Length>,<Sign>,<Point>)`.

To edit the value, we use the numerical keys, the `DEL` keys to clear, `ENTER` to valid and `ESC` to stop the editing.

Example :

```
EditRes!=EDIT(1,5,4,0,0) 'Real four numbers edition without point
                        'no sign in line 1 and row 5
If Key=@ESC Then Goto MainMenu
If (EditRes!<10) Or (EditRes!>50) Then
    Beep
    Goto MainMenu
End If
Length=EditRes!
Goto MainMenu
```

The `EDIT` function have a second syntax. This second syntax allows to type access code with an asterisk displaying (*) on a key pressed. This mode is indicated by the `<Code>` bit. The syntax is :

```
<Variable> = EDIT(<Line>,<Row>,<Length>,<Sign>,<Point>,<AccessCode>).
EditCode!=EDIT(1,5,4,0,0,1) 'Real four numbers edition without point
                            'no sign in line 1 and row 5 with the access
                            'code mode
If Key=@ESC Then Goto MainMenu
If (EditCode!=AdjustCode) Then
    Goto AdjustMenu
Else
    Beep
```

```
Goto MainMenu
End If
```

To edit a string char displaying it on an exact place on the screen, the SUPERVISOR had the **EDIT\$** instruction. In this instruction, you must define the string char variable (<Variable>), the line (<Line>) and row (<Row>) of the first editing character and the maximum length of this editing (<Length>).

the syntax is : <Variable>=EDIT\$(<Line>,<Row>,<Length>). To edit a character on an operator panel, the numeric and alphanumeric key are used, the DEL key to erase, ENTER key to validate and ESC key to escape. To display an alphanumeric character, you need to press the key one or more times..

```
A$=Edit$(2,9,5)      'Edit in line 2, row 9 of 5 characters
```

7-2-4- Buzzer

Two possibilities are offered to use the buzzer of the SUPERVISOR :

↳ To produce or to stop a continuous sound - **BUZZER** instruction

Syntax : BUZZER= <ON/OFF>

↳ To make a brief sound - **BEEP** instruction - Syntax : BEEP

Example :

```
IF KEY<>@ENTER THEN BEEP      'emit a beep on « enter » key press
...
Alarm:
BUZZER=ON                      ' emit a continuous sound during
DELAY 1000                     ' a 1s delay
BUZZER=OFF                    ' Stop the buzzer
DELAY 1000
GOTO Alarm
```

7-2-5- Backlight

The S640 had a function to control the backlight : **BACKLIGHT**. The backlight will become inactive after a delay if user don't push on a key panel. The backlight becomes active when a key pane is pushed. The syntax is : BACKLIGHT= <Delay>. <Delay> defines the active time of the backlight after the last key press. This value is an integer which represents the minutes. The zero value allows the backlight to be always inactive and 1 always active. By default, <Delay> is equal to 15mn.

' **Warning** : le Backlight have a 10000h life duration.


7-2-6- Leds





To drive the leds of the SUPERVISOR, you can use the **LED (number)=State** instruction. The number parameter is the key name where the led is (@F1 ... @F6) or for the specific leds its name (@ALARM or @HELP). The State parameter defines the state of the led : switch off (0), switch on (1) or blink (2).

' **Warning** : The leds of keys F7...F12 on the SUPERVISOR are driven by the LED(@F1)...LED(@F6) instruction.

7-3- Keys

7-3-1- SUPERVISOR keys

 à  @F1 à @F12  @POINT

0	à	9	@0 à @9		@UP
Help			@HELP		@DOWN
Alarm			@ALARM		@RIGHT
Esc			@ESC		@LEFT
Mod			@MOD	Enter	@RETURN
+/-			@SIGN		

7-4- Internals menus

7-4-1- General explications

This menus allow :


- ↵ Test inputs / outputs in a manual mode
- ↵ Read and write the global stored variables
- ↵ Control the storage and restoration of the data in flash
- ↵ Adjust the date and the time
- ↵ Modify the state of the watchdog

This internal menus are executed with the CALL instruction. These menus are used like a sub-routine. The name of the menus begins with the character '_'. The syntax is : CALL <Name of menu>.

7-4-2- Main menu

Main Menu : MENUMCS


Syntax : CALL _MENUMCS



Function : Gives the access of all the sub-menus.

Keys :

- F1 : parameters sub-menu
- F2 : manual sub-menu
- F3 : variables sub-menu
- F4 : memory sub-menu
- F5 : clock sub-menu
- F6 : Next page
- ESC : quit menu



Function : Gives the access of all the sub-menus.


Keys :

- F1 : Previous page
- F2 : taks sub-menu
- F3 : watchdog sub-menu
- ESC : quit menu

7-4-3- Parameters sub-menu

Parameter sub-menu : PARAMMCS

Syntax : CALL _PARAMMCS




Keys :

- F1 : Set
- F2 : RESET

F1 : LEFT F2 : RIGHT
 ESC : Exit menu or return in main menu

7-4-4- Manual sub-menu


Main menu : MANUMCS
 Syntax : CALL _MANUMCS



Keys :
 F1 : Set F2 : RESET
 F1 : LEFT F2 : RIGHT
 ESC : Exit menu or return in main menu

7-4-5- Variables sub-menu

Main menu : VARIABMCS
 Syntax : CALL _VARIABMCS




Keys :
 F1 : Variable number F2 : Variable type
 F3 : Read F4 : Write
 F5 : Real time read F6 : Stop to read

↑ : Next variable ↓ : Previous Variable
 ESC : Exit menu or return in main menu

7-4-6- Memory sub-menu

Main menu : MEMMCS

Syntax : CALL _MEMMCS




Keys :

F1 : Backup data in flash F2 : Restore data from flash
 F3 : Clear data in flash F4 : Restart SUPERVISOR
 F6 : Valid data in memory
 ESC : Exit menu or return in main menu

7-4-7- Clock sub-menu

Main menu : TASKMCS

Syntax : CALL _TASKMCS



Keys :

F1 : Next page F2 : Previous page
 ESC : Exit menu or return in main menu

7-4-8- Tasks sub-menu

Main menu : TASKMCS

Syntax : CALL _TASKMCS

System Menu		Tasks	
Task	0	0	Stopped
Task	1	0	Stopped
Task	2	0	Stopped
Task	3	0	Stopped
Task	4	0	Stopped
Task	5	0	Stopped
Task	6	0	Stopped
Task	7	0	Stopped

PAGE- PAGE+

Keys :

F1 : Previous page

F2 : Next page

ESC : Exit menu or return in main menu

8- OPERATOR AND INSTRUCTIONS LIST

8-1- Program

CALL	Call a subroutine
ICALL	Call a subroutine
END	bloc end
EXIT SUB	Exit subroutine
GOTO	Branch to label
JUMP	Branch to label
PROG ... END PROG	Program
SUB ... END SUB	Subroutine

8-2- Arithmetical

+	Addition
-	Subtraction
*	Multiplication
/	Division

8-3- Mathematical

ABS	Absolute value
ARCCOS	Cosine invert
ARCSIN	Sine invert
ARCTAN	Tangent invert
COS	Cosine
DIV	Integer divide
EXP	Exponential
FRAC	Fractional part
INT	Integer part
LOG	Logarithm
MOD	Modulus
<u>SGN</u>	Sign
SIN	Sine
SQR	Square root
TAN	Tangent
^	Exponent

8-4- Loops

FOR ... TO ... STEP ... NEXT
 REPEAT ... UNTIL
 WHILE ... DO ... END WHILE

8-5- Logical

<<	Left shift
>>	Right shift
AND	AND operator
NOT	Complement Operator
OR	OR operator
XOR	Exclusive OR operator

8-6- Test

<	Lower
<=	Lower or equal
<>	Different
=	Equal / affect
>	Greater
>=	Greater or equal
CASE ...	Multiple tests
IF ... THEN ... ELSE ... END IF	Test structure

8-7- Char string

ASC	Convert char to ASCII
CHR\$	Convert ASCII to char
FORMAT\$	Created a formatted string
INSTR	Search a sub-string
LCASE\$	Lowercase
LEFT\$	Left part of string
LEN	String length
LTRIM\$	Suppress left spaces
MID\$	String part
RIGHT\$	Right part of string
RTRIM\$	Suppress right spaces
SPACE\$	Spaces made string
STR\$	Convert numeric to string

STRINGS	Create a string
UCASE\$	Uppercase
VAL	Convert string to numeric

8-8- PLC

8-8-1- Logical inputs / outputs

INP	1 digital input reading
INPB	8 digital inputs reading
INPW	16 digital inputs reading
OUT	1 digital output writing
OUTB	8 digital outputs writing
PLCINIT	PLC function initialisation
PLCINP	Read TOR input
PLCINPB	Read a 8 inputs block
PLCINPNE	Read a negative edge on PLC TOR input
PLCINPPE	Read a positive edge on PLC TOR input
PLCINPW	Read a 16 inputs block
PLCOUT	Write a output
PLCOUTB	Write a 8 outputs block
PLCOUTW	Write a 16 outputs block
PLCREADINPUTS	Read the PLC inputs
PLCWRITEOUTPUTS	Write the PLC outputs
SETINP	Inputs filter and invert
SETOUT	Outputs invert
WAIT	Condition waiting

8-8-2- Timing

DATE\$	Current date in string
DELAY	Passive wait
GETDATE	Current date
GETTIME	Current time
SETDATE	Set date
SETTIME	Set time
TIME	Global time base
TIMER	Global wide time base
TIME\$	Current time in string

8-8-3- Event handling

DIFFUSE	Send event
GETEVENT	Read event
MODIFYEVENT	Event configuration

SIGNAL	Send event
WAIT EVENT	Passive event wait

8-8-4- Counter

CLEARCOUNTER	RAZ counter
COUNTER_S	Counter read
SETUPCOUNTER	Counter configuration

8-9- Display / Keyboard

8-9-1- Supervisor 80 and 640

BEEP	Brief sound
BUZZER	Continuous sound
CLS	Clear screen
CURSOR	Clear or display cursor
EDIT	Editing
EDIT\$	alphanumeric data capture
KEY	Last key
KEYDELAY	Delay before repeat key
KEYREPEAT	Repeat key period
LED	driving leds
LOCATE	Cursor position
PRINT	Print a text
READKEY	Pressed key
WAIT KEY	Key waiting

8-9-2- Supervisor 640

BACKLIGHT	Screen saver control
BOX	Draw box
FONT	Font selection
HLINE	Draw horizontal line
PIXEL	Draw point
VLINE	Draw vertical line

8-10- Task handling

CONTINUE	Continue task execution
HALT	Stop task
RUN	Start task
SUSPEND	Suspend a task
STATUS	Task state

8-11- Communication

CARIN	Input buffer state
CAROUT	Output buffer state
CLEARIN	Clear input buffer
CLEAROUT	Clear output buffer
CLOSE	Close communication port
INPUT	Data reading
INPUT\$	Char string reading
OPEN...AS...	Open a communication port
OUTEMPTY	Output buffer status
PRINT	Write on the communication port
TX485	Modify RS485 output state

8-12- Flash, Security and other functions

CRC	Return a checksum value
CLEARFLASH	Clear flash memory
FLASHOK	Test data in flash memory
FLASHTORAM	Restore from flash memory
POWERFAIL	Power failure detect
RAMTOFLASH	Backup to flash memory
RAMOK	Test ram memory
RESTART	Restart system
VERSION	Operating system version
WATCHDOG	Watchdog

8-13- Conversion

CVL	Convert string to long integer
CVLR	Convert string to reverse long integer
CVI	Convert string to integer
CVIR	Convert string to reverse integer
LONGTOINTEGER	Convert long integer to integer
MKL\$	Convert long integer to string
MKLR\$	Convert reverse long integer to string
MKI\$	Convert integer to string
MKIR\$	Convert reverse integer to string
REALTOLONG	Convert real to long integer
REALTOINTEGER	Conversion real to integer
REALTOBYTE	Conversion real to byte

8-14- Alphabetic list

8-14-1- Addition (+)

Syntax : `<Expression1> + <Expression2>`

Accepted types : Byte, Integer, Long integer, real or string

Description : This operator adds two numeric expressions and return a value type identical as its operand.

Remarks : `<Expression1>` and `<Expression2>` must be numerical valid expressions.
`<Expression1>` et `<Expression2>` must have the same type.

Example :
`a%=10`
`b%=5`
`c%=a%+b%` *'Result : c%=15*

See also : `'-', '*'` and `'/'`.

8-14-2- Subtraction (-)

Syntax : `<Expression1> - <Expression2>`

Accepted types : Byte, Integer, Long integer or real

Description : this operator subtract `<Expression2>` from `<Expression1>` and return a value type identical as its operand.

Remarks : `<Expression1>` and `<Expression2>` must be numerical valid expressions.
`<Expression1>` and `<Expression2>` must have the same type.

Example :
`a%=10`
`b%=5`
`c%=a%-b%` *'Result : c%=5*

See also : `'+', '*'` et `'/'`.

8-14-3- Multiplication (*)

Syntax : `<Expression1> * <Expression2>`

Accepted types : Byte, Integer, Long integer or real

Description : This operator multiply `<Expression1>` by `<Expression2>` and return a value type identical as its operand.

Remarks : `<Expression1>` and `<Expression2>` must be numerical valid expressions.
`<Expression1>` et `<Expression2>` must have the same type.

Example :
`a%=10`
`b%=5`
`c%=a%*b%` *'Result : c%=50*

See also : `'+', '-'` and `'/'`.

8-14-4- Division (/)

Syntax : `<Expression1> / <Expression2>`

Accepted types : Byte, Integer, Long integer or real

Description : This operator divide `<Expression1>` by `<Expression2>`

Remarks : <Expression1> and <Expression2> must be numerical valid expressions. <Expression1> et <Expression2> must have the same type. <Expression2> must be different of zero. This operator always return a real value.

Example :
a%=10
b%=5
c!=a%/b% 'Result : c!=2.0

See also : ['+'](#), ['-'](#), ['*'](#) and [DIV](#).

8-14-5- Lower (<)

Syntax : <Expression1> < <Expression2>

Accepted types : Byte, Integer, Long integer, real or Char string

Description : This operator tests if <Expression1> is lower than <Expression2>.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions. <Expression1> and <Expression2> must have the same type.

Example :
a%=10
IF b%<a% THEN ...

See also : ['='](#), ['>'](#), ['>='](#), ['<='](#), ['<'](#).

8-14-6- Lower or equal (<=)

Syntax : <Expression1> <= <Expression2>

Accepted types : Byte, Integer, Long integer, real or Char string

Description : This operator tests if <Expression1> is lower or equal than <Expression2>.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions. <Expression1> and <Expression2> must have the same type.

Example :
a%=10
IF b%<=a% THEN ...

See also : ['='](#), ['>'](#), ['>='](#), ['<='](#), ['<'](#).

8-14-7- Left shift (<<)

Syntax : <Expression1> << <Expression2>

Accepted types : Byte or Integer

Description : This operator shifts <Expression2> bits from <Expression1> from right to left.

Remarks : <Expression2> is the number of bits to shift. The shifting is not circular.

Example :
a%=100b
b% =a%<<2 'Result b%=10000b

See also : ['>>'](#)

8-14-8- Different (<>)

Syntax : <Expression1> <> <Expression2>

Accepted types : Byte, Integer, Long integer, real or Char string

Description : This operator tests if <Expression1> and <Expression2> are different.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions.
<Expression1> and <Expression2> must have the same type.

Example : a%=10
IF b%<a% THEN ...

See also : '=', '>', '>=', '<', '<='

8-14-9- Affect/Equal (=)

Syntax : <Expression1> = <Expression2> Or <Variable>=<Expression2>

Accepted types : Bit, Byte, Integer, Long integer, real or Char string

Description : this operator affects <Variable> to <Expression2> or tests if <Expression1> is equal to <Expression2>.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions.
<Expression1> and <Expression2> must have the same type.

Example : a%=10
IF b%=5 THEN ...

See also : '>', '>=', '<', '<=', '<>'

8-14-10- Greater (>)

Syntax : <Expression1> > <Expression2>

Accepted types : Byte, Integer, Long integer, real or Char string

Description : this operator tests if <Expression1> is greater than <Expression2>.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions.
<Expression1> and <Expression2> must have the same type.

Example : IF b%>a% THEN ...

See also : '=', '>=', '<', '<=', '<>'

8-14-11- Greater or equal (>=)Diff_rent

Syntax : <Expression1> >= <Expression2>

Accepted types : Byte, Integer, Long integer, real or Char string

Description : This operator tests if <Expression1> is greater or equal than <Expression2>.

Remarks : <Expression1> and <Expression2> must be numerical valid expressions.
<Expression1> and <Expression2> must have the same type.

Example : IF b%>=a% THEN ...

See also : '=', '>', '<', '<=', '<>'

8-14-12- Right shift (>>)

Syntax : <Expression1> >> <Expression2>

Accepted types : Byte or Integer

Description : This operator shifts <Expression2> bits from <Expression1> from left to right.

Remarks : <Expression2> is the number of bits to shift. The shifting is not circular.

Example : a%=11010b

```
b% =a%>>2 'Result b%=110b
```

See also : ['<<'](#)

8-14-13- Exponent (^)

Syntax : <Expression1> ^ <Expression2>

Accepted types : Byte, Integer, Long integer or real

Description : this operator raises <Expression1> to the <Expression2> power.

Example :

```
a!=b!^2 ' a=b^2
```

8-14-14- ABS – Absolute value

Syntax : **ABS** (<Expression>)

Accepted types : Byte or Integer

Description : This function provide the absolute value of <Expression>. A negative number is then converted in a positive number.

Remarks : <Expression> must be a valid numerical expression. The absolute value of a number is its no-signed value.

Example :

```
a%=ABS (-100) 'Result : a%=100
a%=ABS (25) 'Result : a%=25
```

8-14-15- AND – Operator AND

Syntax : <Expression1> **AND** <Expression2>

Accepted types : Bit, Byte or integer

Description : This function makes a binary AND between two expressions and return a value type identical as its operands.

Remarks : <Expression1> and <Expression2> must have the same type.

Example :

```
IF (A% AND 0FF00h) <>0 THEN ...
```

See also : [OR](#), [NOT](#), [XOR](#) and [IF](#)

8-14-16- ARCCOS – Invert cosine

Syntax : **ARCCOS** (<Expression>)

Limits : -1 to +1

Accepted types : Byte, Integer, Long integer, real

Description : This function returns the arccosine of <Expression>.

Remarks : <Expression> must be a numerical valid expression. This function returns an angle expressed in radians.

Example :

```
pi!=2*ARCCOS (0)
```

See also : [SIN](#), [COS](#) and [TAN](#)

8-14-17- ARCSIN – Invert Sine

Syntax : **ARCSIN** (<Expression>)

Limits : -1 to +1

Accepted types : Byte, Integer, Long integer, real
Description : This function returns the arcsine of <Expression>.
Remarks : <Expression> must be a numerical valid expression. This function returns an angle expressed in radians.
Example : `pi!=2*ARCSIN(1)`
See also : [SIN](#), [COS](#) and [TAN](#)

8-14-18- ASC – Convert char to ASCII

Syntax : `ASC(<String>)`
Accepted types : Char string
Description : This function returns a numeric value which is the ASCII code for the first character of a string expression.
Remarks : If the string length <String> is zero, the zero value is returned.
Example : `a$="A"`
`b#=ASC(a$) 'Result : b#=65`
See also : [CHR\\$](#).

8-14-19- ARCTAN – Invert tangent

Syntax : `ARCTAN (<Expression>)`
Accepted types : Byte, Integer, Long integer, real
Description : This function returns the arctangent of <Expression>.
Remarks : <Expression> must be a numerical valid expression. the function ARCTAN takes the ratio of two sides of a right triangle and returns the corresponding angle. The ratio is the length of the side opposite the angle divides by the length of the side adjacent to the angle.
Example : `a!=ARCTAN(3)`
`pi!=4*ARCTAN(1)`
See also : [SIN](#), [COS](#) and [TAN](#)

8-14-20- BACKLIGHT – S640 in stand by

Syntax : `BACKLIGHT=<duration>`
Units : duration : minutes
Accepted types : duration : Integer
Description : this function defines the duration in minute during the backlight of S640 will stay active if any of the key panel are pressed.
Remarks : When backlight is switched off, if a key panel is pressed, the backlight is switched on. The default duration is equal to 15 minutes.
Duration : 0 → backlight switch off
 1 → backlight always switch-on.
 (Duration>1) → delay in minutes.
' Warning : The backlight life duration is about 10 000 hours.
Example : `BACKLIGHT=120` *'the backlight S640 will be switch off*


*'if a key panel is not pressed by the users
' in the two hours last*

8-14-21- BEEP – Brief sound

Syntax : **BEEP**
 Description : this instruction emits a brief sound on the SUPERVISOR.
 Example : `IF KEY<>@ENTER THEN BEEP`
 Voir aussi : **BUZZER**

8-14-22- BOX – Draw box

Syntax : **BOX(X1,Y1,X2,Y2,BorderColour, FillColour)**
 Units : X1, Y1, X2, Y2 : pixel
 Limits : X1, X2 : 1 to 240
 Y1, Y2 : 1 to 128
 Accepted types : X1, Y1, X2, Y2, FillColour : Byte
 BorderColour : Bit
 Description : This instruction draws a box with the coordinates X1,Y1 (top left corner) and X2,Y2 (down right corner) on the operator panel S640.
 Remarks : The BorderColour parameter defines the colour of the border : black (0) or white (1). The FillColour defines the colour of the filling : black (0), white (1) or transparent (2).
 Example : `BOX(10,50,85,15,0,1)` *'Black border with white fil colour*



8-14-23- BUZZER – Continuous sound

Syntax : **BUZZER = <ON|OFF>**
 Description : This function activates or deactivates the buzzer of SUPERVISOR.
 Example : `Alarme:
 BUZZER=ON
 DELAY 1000
 BUZZER=OFF
 DELAY 1000
 GOTO Alarme`
 See also : **BEEP**

8-14-24- CALL – Subroutine call

- Syntax : **CALL** <Name>
- Description : This instruction calls a subroutine define by SUB block. <Name> is the block name of the subroutine.
- Remarks : A subroutine can't call itself. System contains some predefined subs : `_MENU MCS`, `_PARAM MCS`, `_MANU MCS`, `_VARIAB MCS`, `_MEMORY MCS` and `_CLOCK MCS`. The execution of this instruction launches the execution of the next task.
- Example : **CALL** Move
- See also : **SUB**, **ICALL**

8-14-25- CASE – Multiple tests

- Syntax 1 : **CASE** <Expression> **CALL** <Label 1> [{ , <Label2> }]
- Syntax 2 : **CASE** <Expression> **GOTO** <Label 1> [{ , <Label2> }]
- Accepted types : Expression : Integer
- Description : This function allows to make jumps to labels in function of <Expression> values.
- Remarks : <Expression> must be an integer valid value. If the Expression value is equal to zero or greater than the number of labels, the task goes on at the next line. The execution of this instruction launches the execution of the next task.
- Example : Case a% **GOTO** Move1, Move2
 Goto Fin 'a%=0 or a%>2
 ...
 Move1: 'a% = 1
 ...
 Move2: 'a% = 2
 ...
 Fin:

8-14-26- CARIN – Input buffer state

- Syntax : **CARIN** (<Number>)
- Description : This function returns the number of characters in the input buffer of the communication port.
- Remarks : <Number> is the number used to open the communication port with OPEN instruction. This function returns an integer.
- Example : **WAIT** **CARIN**(#1)>=3 ' Wait for at least 3 received characters
 A\$=Input\$ #1,3 ' Read 3 characters
- See also : **CAROUT**, **CLEARIN**

8-14-27- CAROUT – Output buffer state

- Syntax : <Expression>=**CAROUT** (<Number>)
- Accepted types : <Expression> : integer
- Description : This function returns the number of characters in the output buffer of the communication port.

Remarks : <Number> is the number used to open the communication port with OPEN instruction.

Example : WAIT CAROUT(#1)<10 'Waits for place in the buffer
 Print A\$; 'Characters writing

See also : [CARIN](#), [CLEAROUT](#)

8-14-28- CHR\$ - Convert ASCII to char

Syntax : **CHR\$**(<Code>)

Accepted types : Code : Byte

Description : This function returns a one character-string whose ASCII code is the argument.

Example : a#=97
 b\$=CHR\$(a#) '*Result : b\$="a"*

See also : [ASASC_C](#)

8-14-29- CLEARCOUNTER – Counter clear

Syntax : **CLEARCOUNTER**(<Counter>)

Accepted types : <Counter> : Byte

Description : This instruction initialise the counter to zero.

Remarks : <Counter> : Counter number (1 or 2)

See also : [COUNTER_S](#), [SETUPCOUNTER](#)

8-14-30- CLEARIN – Clear input buffer

Syntax : **CLEARIN** <Number>

Description : This instruction suppresses all the characters in the input buffer of the communication port.

Remarks : <Number> is the number used to open the communication port with OPEN instruction.

Example : CLEARIN #1
 Wait CARIN (#1)>=3 '*Wait for at least 3 characters*
 A\$=Input\$ #1,3 '*Read 3 characters*

See also : [CARIN](#)

8-14-31- CLEAROUT – Clear output buffer

Syntax : **CLEAROUT** <Number>

Description : This instruction suppresses all the characters in the output buffer of the communication port.

Remarks : <Number> is the number used to open the communication port with OPEN instruction.

Example : CLEAROUT #1
 Print A\$; '*Write the characters*

See also : [CAROUT](#)

8-14-32- CLOSE – Close communication port

Syntax : **CLOSE #Number**

Description : The number argument is the number used in the OPEN instruction to open the communication port.

Remarks : If you want to change the communication mode, you must close and open once again the communication port.

Example : CLOSE #1

See also : **OPEN, INPUT** and **PRINT**.

8-14-33- CLS – Clear screen

Syntax : **CLS**
 CLS 1, CLS 2, CLS 3 or CLS 4 (only with Supervisor 80)
 CLS B, CLS W (only with Supervisor 640)

Description : CLS clears the four lines of the operator panel screen. CLS 1, CLS 2, CLS 3, CLS 4 clears respectively the first, second, third and fourth line of the operator panel Supervisor 80 screen. The function CLS B clears the screen of the Supervisor 640 with a black background. The function CLS W clears the screen of the Supervisor 640 with a white background

8-14-34- CLEARFLASH – Clear flash memory

Syntax : **CLEARFLASH**

Description : This function clears parameters and the first 10000 safe variables in the flash memory.

See also : **RAMOK, FLASHOK, FLASHTORAM**

8-14-35- COUNTER_S – Counter reading

Syntax : <Variable>=**COUNTER_S**(<Counter>)

Accepted types : <Variable> : Integer
 <Counter> : Byte

Description : This instruction reads the counter

Remarks : <Counter> : Counter number (1 or 2)

See also : **SETUPCOUNTER, CLEARCOUNTER**

8-14-36- CONTINUE – Continue task execution

Syntax : **CONTINUE** <Name>

Description : This instruction is used to continue the execution of a suspended task.

Remarks : <Name> must be the name of a suspended task. This function has no effect on the stopped or executed task.

Example : Wait Inp(Start)
 RUN Coupe
 Begin:

Wait Inp (Stop)
 SUSPEND Coupe
 Wait Inp (Start)
 CONTINUE Coupe
 Goto Begin

See also : [RUN](#), [HALT](#), [SUSPEND](#)

8-14-37- COS - Cosine

Syntax : **COS**(<Expression>)

Accepted types : Expression : real

Description : This instruction returns the cosine of the <Expression>.

Remarks : The argument <Expression> must be a valid numerical expression expressed in radians. The function COS takes an angle and returns the two sides ratio of a rectangle triangle. The ratio is the length of the adjacent side divided by the length of the hypotenuse. The result is between -1 et 1.

Example : a!=COS(3.14159)

See also : [SIN](#), [ARCTAN](#) et [TAN](#)

8-14-38- CURSOR – Print or clear the cursor

Syntax : **CURSOR** = <ON | OFF>

Description : This function prints or not the cursor on the operator panel.

Remarks : This function uses the communication port #1. By default, the communication port SERIAL1 will be used. If an operator panel is connected to the SERIAL2 port, please refer to the OPEN function to affect #1 to the port SERIAL2.

8-14-39- CVL – Convert string to long integer

Syntax : <Variable>=**CVL**(<Expression>)

Accepted types : Variable : Long integer
 Expression : string of 4 bytes

Description : The CVL function converts a string of 4 bytes, created with the MKL\$ instruction, in a long integer value. The least significant word then the most significant word

Example : A&=CVL(A\$) 'If A\$=chr\$(2)+chr\$(3)+chr\$(1)+chr\$(0)
 'then A&=2+(3*256)+(1*65536)+(0*16777216)=66306

See also : [CVLR](#), [MKL\\$](#), [MKLR\\$](#)

8-14-40- CVLR – Convert string to long reverse integer

Syntax : <Variable>=**CVLR**(<Expression>)

Accepted types : Variable : Long integer
 Expression : string of 4 bytes

Description : The CVL function converts a string of 4 bytes, created with the MKL\$ instruction, in a long integer value. The most significant word then the least significant word

Example : A&=CVLR(A\$) 'If A\$=chr\$(0)+chr\$(1)+chr\$(3)+chr\$(2) then

'A&=(0*16777216)+(1*65536)+(3*256)+(2*1)=66306

See also : [CVL](#), [MKL\\$](#), [MKLR\\$](#)

8-14-41- CVI – Convert string to integer

Syntax : <Variable>=**CVI**(<Expression>)

Accepted types : Variable : Integer

Expression : string of 2 bytes

Description : The CVL function converts a string of 2 bytes, created with the MKI\$ instruction, in an integer value. The most significant byte then the least significant byte

Example : `A&=CVI(A$) 'If A$=chr$(0)+chr$(1) then A&=0+(1*256)=256`

See also : [CVIR](#), [MKI\\$](#), [MKIR\\$](#)

8-14-42- CVIR – Convert string to reverse integer

Syntax : <Variable>=**CVIR**(<Expression>)

Accepted types : Variable : Integer

Expression : string of 2 bytes

Description : The CVL function converts a string of 2 bytes, created with the MKI\$ instruction, in an integer value. The least significant byte then the most significant byte

Example : `A%=CVIR(A$) 'If A$=chr$(3)+chr$(2) then A&=(3*256)+(2*1)=770`

See also : [CVI](#), [MKI\\$](#), [MKIR\\$](#)

8-14-43- CRC – CRC16

Syntax : CRC Value %=**CRC**(<Expression >)

Accepted types : Expression : Char string

Description : This function return the checksum value in a char string with the modbus RTU format (CRC 16).

Example : `A%=CRC(message$)`

8-14-44- DATE\$ - Current Date

Syntax : **DATE\$**

Description : This instruction returns a 10 characters string under the form dd/mm/yyyy, where dd is the day (01-31), mm is the month (01-12) et yyyy is the year.

Example : `a$=DATE$ 'Result : a$="01/01/1996"`

See also : [TIMES\\$](#), [TIME](#), [TIMER](#)

8-14-45- DELAY – Passive waiting

Syntax : **DELAY** <Duration>

Units : Duration : milliseconds

Accepted types : Duration : Integer

Description : This instruction allows to the system to wait for the time <Duration>. The task continue its execution when the duration is finished. The execution of this instruction launches to the execution of the next task.

Example :

```
DELAY 500 '0.5 s. Delay
DELAY Timer1
```

8-14-46- DIFFUSE – Event generation

Syntax : **SIGNAL** <Name>

Description : This instruction generates an event.

Remarks : <Name> must be the same name used by WAIT EVENT instruction. Each program which was waiting for this event can then go on.

Example :

```
Program1           Program2
...
WAIT EVENT Ready   DIFFUSE Ready
...
...                ...
```

See also : [WAIT EVENT](#), [SIGNAL](#)

8-14-47- DIV – Integer divide

Syntax : <Expression1> **DIV** <Expression2>

Accepted types : Expression1, Expression2 : Integer

Description : This operator returns the integer divide result.

Remarks : This operator returns an integer.

Example :

```
a%=7
a%=a% DIV 2      'Result : a%=3
```

See also : [MOD](#)

8-14-48- EDIT – Editing on operator panel

Syntax 1: <Variable>=**EDIT**(<Line>,<Row>,<Length>,<Sign>,<Point>)

Syntax 2: <Variable>=**EDIT**(<Line>,<Row>,<Length>,<Sign>,<Point>,
<Code>)

Limits : Line : 1 to 4 for Supervisor 80 or 1 to 16 for Supervisor 640.

Row : 1 to 20 for Supervisor 80 or 1 to 40 for Supervisor 640.

Accepted types : Variable : real

Line, Row, Length : Integer

Sign, Point, Code : bit

Description : This function allows to edit a real number with the operator panel by using the numerical keys, the DEL key to suppress, the ENTER key to valid and ESC to escape. The second syntax defines the access code mode of editing (Code=1). In this case, all the key press display a star on the operator (*) panel. The execution of this instruction launches the execution of the next task.

Remarks : <Line> et <Row> are the first character position. <Length> is the maximum number of characters. <Sign> is a boolean value which indicates if the sign can be changed. <Point> is a boolean value which indicates if the point is permitted. The

system variable KEY contains the last pressed key. If the edition is aborted then KEY=@ESC and otherwise KEY=@RETURN.

Example : A!=EDIT(1,10,4,0,0) ' Capture in line 1 row 10
 ' on 4 characters, the sign and the
 ' point are not autorised..
 A!=EDIT(1,10,4,0,0,1) ' Same capture with access code mode

8-14-49- EDITS

Syntax : <Variable>=EDITS(<Line>,<Row>,<Length>)

Limits : Line : 1 to 4 for Supervisor 80 or 1 to 16 for Supervisor 640.

 Row : 1 to 20 for Supervisor 80 or 1 to 40 for Supervisor 640.

Accepted types : Variable : Char string

 Line, Row, Length : Integer

Description : This function allows to edit a by using the alphanumeric keys, the DEL key to suppress, the ENTER key to valid and ESC key to escape. For writing an alphanumeric character, push several times on the associated numeric key, to change the character. The record of the character makes itself automatically when you don't push on the associated numeric touch or you push on other touch.

Remarks : <Line> and <Row> are the first character position. <Length> is the maximum number of characters. The system variable KEY contains the last pressed key. If the edition is aborted then KEY=@ESC and otherwise KEY=@RETURN.

Example : A\$=EDIT\$(2,9,5) 'capture in line 2, row 9
 'on 5 characters maxi.

8-14-50- END – Block end

Syntax : **END** {PROG | SUB |IF | WHILE}

Description : Bloc end.

Remarks : You must specify a keyword after END

Examples : SUB Manuel
 ...
 END SUB

See also : **PROG, SUB, IF, WHILE**

8-14-51- EXIT SUB – Subroutine exit

Syntax : **EXIT SUB**

Description : This instruction allows to exit of a subprogram.

See also : **SUB**

8-14-52- EXP - Exponential

Syntax : **EXP** (<Expression>)

Accepted types : Expression : real

Description : This function returns e (natural logarithms base) raised to <Expression> power.

Remarks : The argument <Expression> must be a valid numerical expression.
Example : a!=EXP (2)
See also : **LOG**

8-14-53- FLASHOK – Test flash memory

Syntax : FLASHOK
Description : This function indicates if parameters and the first 10000 saved variables are backed up in flash memory
See also : **RAMOK, RAMTOFLASH, FLASHTORAM**

8-14-54- FLASHTORAM – Restore saved variables

Syntax : FLASHTORAM
Description : This function restore parameters and the first 10000 saved variables from flash memory. This function is automatically called by system if variables are corrupted on start-up.
Voir aussi : **RAMOK, RAMTOFLASH, FLASHOK**

8-14-55- FOR – FOR ... NEXT loop

Syntax : FOR <Counter>=<Begin> TO <End> [STEP <step>]
...
NEXT <Counter>
Accepted types : Counter : Byte, Integer, Long integer
Description : Repeats an instruction a specified number of time.
Remarks : FOR starts the FOR ... NEXT loop structure. FOR must appear before all the other parts of the structure. <Counter> is a local integer variable used as loop counter. <Counter> is equal to <End>+1 at the end of the loop. <step> must be a positive value. The execution of this instruction NEXT passed to the execution of the next task.
Example : FOR i%=1 TO 10
...
NEXT i%
See also : **WHILE**

8-14-56- FONT – Font selected

Syntax : **FONT**=<Value>
Accepted types : <Value> : byte.
Description : This function defines the font of the operator panel.
Remarks : <Value> :
Font 1 : 16 lines x 40 characters with text and black background, 3x4mm
Font 2 : 9 l x 30 c with text and black background, 4x7mm
Font 3 : 6 l x 20 c with text and black background, 12x20mm

Font 4 : 4 l x 15 c with text and black background, 16x22mm

Font 5 : 16 l x 40 c with text and white background, 3x4mm

Font 6 : 9 l x 30 c with text and white background, 4x7mm

Font 7 : 6 l x 20 c with text and white background, 12x20mm

Font 8 : 4 l x 15 c with text and white background, 16x22mm

Example :
FONT=1
Locate 2,15
Print "MODE AUTO"

8-14-57- FORMATS

Syntax : **FORMATS**(<Expression>,<Number>,<Precision>,'<Car>',
 <Sign>,<LeftAlign>)

Accepted types : Expression : real
 Number, Precision : Byte
 Car : string char
 Sign, LeftAlign : Bit

Description : This function creates a formatted string.

Remarks : The argument <Expression> must be a valid numerical expression. <Number> is the minimum number of characters of the string. <Precision> is the number of character after the decimal point. <Car> is the substitution character used to reach this minimum number if it is necessary. <Sign> indicates if the character "+" or "-" must be added at the beginning of the string. <LeftAlign> indicates if the string is left aligned.

Example : a!=1.2562
 b\$=FORMAT\$(a!,5,2," ",0,1) ' a\$="1.25 "

8-14-58- FRAC – Fractional part

Syntax : **FRAC**(<Expression>)

Accepted types : <Expression> : real

Description : This function provides the fractional part of the <Expression>.

Remarks : This fonction returns a real value.

Example : b!=3.0214
 a!=FRAC(b!) 'Result a!=0.0214

See also : **INT**

8-14-59- GETDATE – Current date

Syntax : **GETDATE**(<Year>,<Month>,<Day>,<DayInTheWeek>)

Accepted types : <Year>, <Month>, <Day>, <DayInTheWeek> : Integer.

Description : This instruction reads the current date.

See also : **GETTIME**

8-14-60- GETEVENT – Events reading

Syntax : <Variable> = **GETEVENT**

Accepted types : <Variable> : Integer

Description : This instruction consumes and reads detected events.

Remarks : All the event bit are setting if the event is detected. If a new event appears during the execution of the event task, event is stored and is treated as soon as it is possible.

See also : **MODIFYEVENT**

8-14-61- GETTIME – Current time

Syntax : **GETTIME**(<Hour>,<Minute>,<Second>)

Accepted types : <Hour>, <Minute>, <Second> : Integer.

Description : This instruction reads the current time.

See also : **GETDATE**

8-14-62- GOTO – Branch label

Syntax : **GOTO** <Label>

Description : Jumps to a label

Remarks : The programs with lots of GOTO instructions can become hard to read and to perfect. Use the control structures (FOR...NEXT, REPEAT...UNTIL, WHILE...END WHILE, IF...THEN...ELSE...END IF) each time it is possible. A label is a name following by character ":". The execution of this instruction passed to the execution of the next task.

Example : GOTO Begin

...

Begin :

See also : **JUMP, FOR, REPEAT, WHILE, IF, END**

8-14-63- HALT – Stop a task

Syntax : **HALT** <Name>

Description : This instruction is used to stop a task which is going to be executed or suspended.

Remarks : This function has no effect on the stopped task, on the movements running and on the buffer of movements.

Example : Begin :

Wait Inp(Power)=On

RUN Cutter

Wait Inp(Power)=Off

HALT Cutter

Goto Begin

See also : **RUN, SUSPEND, CONTINUE**

8-14-64- HLINE – Draw horizontal line

Syntax : **HLINE**(X1,Y1,X2,colour)

Units : X1, Y1, X2 : pixel


Limits : X1, X2 : de 1 à 240
Y1 : de 1 à 128

Accepted types : X1, Y1, X2 : byte.
Colour : Bit

Description : This instruction draws a line with its starting point in X1, Y1 and its final point in X2, Y1 on the S640.

Remarks : Colour changes the colour of the line : black (0) or white (1)

Example : `HLINE(10,15,70,0)`

**8-14-65- ICALL – Call a sub-routine**

Syntax : **ICALL** <Name>

Description : This instruction is used to call a sub-routine define by a block SUB. <Name> is the name of the sub-routine's block.

Remarks : A sub-routine can not call himself. The system had predefine sub-routines : `_MENU MCS`, `_PARAM MCS`, `_MANU MCS`, `_VARIAB MCS`, `_MEMORY MCS` and `_CLOCK MCS`. The execution of this instruction don't launches the execution of the next task..

Exemple : `ICALL Move`

Voir aussi : [SUB](#), [CALL](#)

8-14-66- IF - IF...Then...Else

Syntax 1 : **IF** <Condition> **THEN**
{<Instruction1>}

...

ELSE

{<Instruction2>}

...

END IF

Syntax 2 : **IF** <Condition> **THEN** <Instruction1> **ELSE** <Instruction2>

Description : Allows the conditional execution based on the expression evaluation.

Remarks : The keyword **IF** begins a control structure. **IF...THEN...ELSE...END IF** . It must appear before all other part of the structure. <Condition> must be a boolean expression.

If <Condition> is right then <Instructions1> are executed.

If <Condition> is false then <Instructions2> are executed.

Example :
IF (a%>1) AND (a%<10) THEN
 Locate 1,1
 Print "Length 1"
Else
 Locate 2,1
 Print "Width 1"
END IF

See also : [END](#)

8-14-67- INKEY– Read a key on the operator panel

Syntax : <Variable>=INKEY

Accepted types : Variable : Byte

Description : This function reads a key from the keyboard of the operator panel and returns its code.

Remarks : This function does not stop the task. Cette fonction est non bloquante pour la tâche. If the input buffer is empty (no key has been pressed) this function returns 0.

Example :
REPEAT
A#=INKEY
UNTIL A#<>0

8-14-68- INP – Input reading

Syntax : INP (<Input>)

Accepted types : <Input> : Bit

Description : This function gives the state of a digital input.

Remarks : <Input> must represent an input name TOR. The returned data type is Bit.

Example : C~=INP(HighCutter)

See also : [INPB](#), [INPW](#), [OUT](#), [OUTB](#), [OUTW](#)

8-14-69- INPB – 8 digital inputs reading

Syntax : INPB (<Input>)

Accepted types : <Input> : Byte

Description : This function gives the state of 8 digital inputs TOR..

Remarks : <Input> must represent the 8 inputs name. The returned data type is Byte.

Example : B#=INPB(Data)

See also : [INP](#), [INPW](#), [OUT](#), [OUTB](#), [OUTW](#)

8-14-70- INPUT – Data reading

Syntax : INPUT #<Number>, <Variable> [{,<Variable>}]

Accepted types : Variable : Bit, Byte, Integer, Long integer, real and Char string

Number : #1 or #2

Description : Reads data from the communication port and assigns the data to the variables. The execution of this instruction passed to the execution of the next task.

Remarks : <Number> is the number used to open a communication port with OPEN function. The read data must appear in the same order that the variables list.

Example :
OPEN "SERIAL1:" AS #1
INPUT #1,A\$,B%
CLOSE #1

See also : [OPEN](#), [PRINT](#), [CLOSE](#)

8-14-71- INPUT\$ - Char string reading

Syntax : <Variable> =INPUT\$ <CommNumber>, <NumberOfChar>

Accepted types : Variable : Char string
CommNumber : #1 or #2
NumberOfChar : Byte

Description : Reads <NumberOfChar> characters from the communication port and stores them in a char string. The execution of this instruction launches the execution of the next task.

Remarks : <CommNumber> is the number used to open the communication port with OPEN instruction.<Variable> must be a variable char string type. The task is blocked on this instruction when the number of character received is different than this specified in the instruction.

Example :
OPEN "SERIAL1:" AS #1
A\$=INPUT\$ #1,5 'Read 5 characters from the communication port
CLOSE #1

See also : [OPEN](#), [PRINT](#), [CLOSE](#)

8-14-72- INPW – 16 digital inputs reading

Syntax : INPW (<Input>)

Accepted types : <Input> : Integer

Description : This function gives the state of the 16 digital inputs.

Remarks : <Inputs> must represent the name of a 16 digital inputs board. Data type returns is integer.

Example : A%=INP (Bloc)

See also : [INP](#), [INPB](#), [OUT](#), [OUTB](#), [OUTW](#)

8-14-73- INSTR – Search a sub-string

Syntax : INSTR(<string1>,<string2>)

Accepted types : string1, string2 : Char string

Description : This function searches a sub-string in a char string and returns the position of the first occurrence of the sub-string.

Remarks : <String1> is the researched string <String2>.

Example :
a\$="Press ENTER to start"
EnterPos%=INSTR("ENTER",a\$) 'Result : EnterPos%=7

See also : [LEN](#)

8-14-74- INT – Integer part

Syntax : **INT** (<Expression>)

Accepted types : Expression : real

Description : This function returns the <Expression> integer part.

Remarks : The argument <Expression> must be a valid numerical expression

Example : `b!=25.36`
`a!=INT(b!) 'Result : a!=25`

See also : [FRAC](#)

8-14-75- JUMP – Branch to label

Syntax : **JUMP** <Label>

Description : Jumps to a label

Remarks : The programs with lots of GOTO instructions can become hard to read and to perfect. Use the control structures (FOR...NEXT, REPEAT...UNTIL, WHILE...END WHILE, IF...THEN...ELSE...END IF) each time it is possible. A label is a name following by character ":". The execution of this instruction doesn't launch the execution of the next task.

Example : `JUMP Begin`
`...`
`Begin :`

See also : [GOTO](#), [FOR](#), [REPEAT](#), [WHILE](#), [IF](#), [END](#)

8-14-76- KEY – Last pressed key

Syntax : **KEY**

Description : This system variable contains the last pressed key.

Remarks : This variable must be used after EDIT et WAIT KEY instructions. The key variable is local for a task.

Example : `WAIT KEY`
`IF KEY=@F1 THEN CALL ...`
`IF KEY=@F2 THEN CALL ...`
`IF KEY=@F3 THEN CALL ...`

See also : [EDIT](#), [WAIT KEY](#)

8-14-77- KEYDELAY – Delay before key repeat

Syntax : **KEYDELAY** = <Expression>

Units : Expression : 1/32 of second.

Accepted types : Expression : Byte

Description : This instruction defines the delay before the automatic repetition of a key when this is pressed.

Remarks : The default value is 1 second (32).

Example : KEYDELAY = 10

See also : **KEYREPEAT**

8-14-78- KEYREPEAT – Keyrepeat period

Syntax : **KEYREPEAT**=<Expression>

Units : Expression : 1/32 of second.

Accepted types : Expression : Byte

Description : This instruction defines the delay which separates each automatic key repetition when this is pressed..

Remarks : The default value is 0.3 second (10).

Example : KEYREPEAT = 5

See also : **KEYDELAY**

8-14-79- LCASE\$ - Lowercases

Syntax : <Expression> = **LCASE\$**(<String>)

Accepted types : String : Char string

Description : This function returns a string in all the letters of the argument have been converted in lowercases.

Remarks : The argument <Expression> must be a char string. Only the uppercases are converted in lowercases, the other letters are not modified.

Example : a\$="Sensor1"
 b\$=LCASE\$(a\$) 'Result : b\$="sensor1"

See also : **UCASE\$**

8-14-80- LED – Driving LEDs

Syntax : **LED**(Number)=State

Accepted types : State : bit.

Description : This function allows to drive the LEDs of SUPERVISOR.

Remarks : Definition of the LED : de @F1 to @F6 or @ALARM or @HELP
 Definition of their state: switch off (0), light (1), blink (2).

Example : LED(@ALARM)=2 '*blink alarm DEL*

8-14-81- LEFT\$ - String left part

Syntax : **LEFT\$**(<String>,<Number>)

Accepted types : String : Char string

 Number : Integer

Description : This function returns the first <Number> left characters of a string.

Remarks : To find the character numbers in the string <String>, use LEN(<String>).

Example : a\$="Sensor1"
 b\$=LEFT\$(a\$,6) 'Result : b\$="Sensor"

See also : [RIGHT\\$, LEN](#)

8-14-82- LEN– String length

Syntax : **LEN**(<String>)

Description : This function returns the number of characters of a string.

Example : `a$="Sensor1"`
`b%=LEN(a$) 'Result : b%=7`

See also : [INSTR](#)

8-14-83- LOCATE – Cursor position

Syntax : **LOCATE** <Line>,<Row>

Limits : Line : 1 to 4 for Supervisor 80 or 1 to 16 for Supervisor 640.

Row : 1 to 20 for Supervisor 80 or 1 to 40 for Supervisor 640.

Accepted types : Line, Row : Byte

Description : This function is used to select the cursor position.

Example : `LOCATE 1,1`
`PRINT "<MAIN MENU>"`

8-14-84- LOG - Logarithm

Syntax : **LOG** (<Expression>)

Accepted types : Expression : real

Description : Returns the natural logarithm of <Expression>

Remarks : <Expression> must be a numerical expression.

Example : `a!=LOG(1.2)`

See also : [EXP](#)

8-14-85- LONGTOINTEGER – Convert a long integer to integer

Syntax : **LONGTOINTEGER**(<Expression>)

Accepted types : Expression : Long integer

Description : This function converts a long integer type data in integer type data.

Example : `A&=Time`
`B%=LongToInteger(A&)`

8-14-86- LTRIMS\$ - Suppress the left spaces

Syntax : **LTRIMS**(<Expression>)

Description : Returns a string copy without the left spaces.

Remarks : <Expression> must be a char string.

Exemples : `a$=" Menu "`
`b$=LTRIMS$(a$) ' Result b$="Menu "`

See also : [RTRIMS](#)

8-14-87- MIDS - String part

Syntax : **MIDS**(<String>, <Begin>, <Length>)

Accepted types : String : Char string

Begin, Length : Byte

Description : This function returns a string part.

Remarks : <Begin> defines the beginning of the substring extracted and <Length> the number of characters to extract.

Example : `a$="MAIN MENU "`
`b$=MIDS(a$,6,4) ' Result : b$="MENU"`

See also : [LEFTS](#), [RIGHTS](#)

8-14-88- MOD - Modulus

Syntax : <Expression1> **MOD** <Expression2>

Accepted types : Expression1, Expression2 : Byte, Integer, Long integer

Description : This operator returns an integer division rest.

Example : `a%=5`
`a%=a% MOD 2 'Result : a%=1`

See also : [DIV](#)

8-14-89- MODIFYEVENT– Events configuration

Syntax : **MODIFYEVENT** (<Mask>, <Counter 1 trigger>, <Counter 2 trigger>, <Delay>)

Limits : <Delay> : 10ms to 30.000ms

Accepted types : <Mask> : Integer

<Counter 1 Trigger> : Integer

<Counter 2 Trigger> : Integer

<Delay> : Integer

Description : This instruction allows to configure events.

Remarks : <Mask> :

↳ Bits 0...7 : Activate the inputs 1 to 8 of the input card. A positive edge will generate the event. The input take account of the invert and filter parameters entered during the board configuration.

↳ Bit 8 : Trigger of the counter 1 reached

↳ Bit 9 : Trigger of the counter 2 reached

↳ Bit 10 : SDOEvent

↳ Bit 11 : PDOEvent

↳ Bits 12 : Time base.

<Delay> : Delay of the time base between 10 ms and 30000 ms. If the time base is unused, the value of delay will be not treated.

When the event configuration register is affected, the event task is executed when at least one event is detected. The maxi time between the event detected and its treatment is equal to the task ageing time.

If you want to modify the event configuration register, you'll be treated this instruction in a normal basic task or an event task before the execution of GETEVENT instruction.

See also : [GETEVENT](#)

8-14-90- MKL\$ - Convert long integer to string

Syntax : `<string>=MKL$(<Expression>)`

Accepted types : `<string>` : string char of 4 bytes

Expression : Long integer

Description : This function MKL\$ convert long integer value in a string of 4 bytes. Least significant byte and then most significant byte

Example : `A$=MKL$(A&) 'if A&=66306 then A$=2310`

See also : [MKLR\\$, CVL, CVLR](#)

8-14-91- MKLR\$ - Convert long integer reverse to a string

Syntax : `<string>=MKLR$(<Expression>)`

Accepted types : `<string>` : string char of 4 bytes

Expression : Long integer

Description : This function MKLR\$ convert long integer value in a string of 4 bytes. The most significant word and the least significant word

Example : `A$=MKL$(A&) 'if A&=66305 then A$=0132`

See also : [MKL\\$, CVL, CVLR](#)

8-14-92- MKI\$ - Convert an integer to a string

Syntax : `<string>=MKI$(<Variable>)`

Accepted types : `<string>` : string char of 2 bytes

Variable : Integer

Description : This function MKI\$ convert long integer value in a string of 2 bytes. Least significant byte and then most significant byte

Example : `A$=MKI$(A%) 'if A%=256 then A$=01`

See also : [MKIR\\$, CVI, CVIR](#)

8-14-93- MKIR\$ - Conversion Integer reverse / String

Syntax : `<string>=MKIR$(<Variable>)`

Accepted types : `<string>` : string char of 2 bytes

Variable : Integer

Description : This function MKI\$ convert long integer value in a string of 2 bytes. Most significant byte and then least significant byte

Example : A\$=MKI\$(A%) 'If A%=770 then A\$=32

See also : [MKI\\$, CVI, CVIR](#)

8-14-94- NOT – Complement operator

Syntax : **NOT**(<Expression>)

Accepted types : Expression : Bit, Byte, Integer

Description : This function returns the complement.

Remarks : <Expression> must be an integer valid expression.

Example : a%=0FF00h
 b%=NOT a% 'Result b%=00FFh

See also : [AND, OR, XOR](#)

8-14-95- OPEN – Open a communication port

Syntax : **OPEN** <CommunicationPort> **AS** #<Number>

Description : Authorizes the reading/writing operations on a communication port.

Remarks : You must open a communication port before any input/output operation
<CommunicationPort> is a char string which defines the parameters with this following syntax :

"SERIALn:[speed [, data[, parity [, stop]]]]"

N: Physical number 1 or 2

Speed: 150, 300, 600, 1200, 2400, 4800 or 9600 bauds.

Data : 7 or 8 bits

Parity : E (even), O (odd), M (mark), S (space) or N (without).

Stop : 1 or 2 bits

<Number> defines the communication canal number used by the functions.

Example : *Dialog 80, 160 or 640 linked to SERIAL2 : SERIAL2 affected to the canal 1*
 OPEN "SERIAL2:9600,8,N,1" As #1
 PRINT "<MAIN MENU>";

See also : [INPUT, PRINT, CLOSE](#)

8-14-96- OR – OR operator

Syntax : <Expression1> **OR** <Expression2>

Accepted types : Expression1, Expression2 : Bit, Byte, Integer

Description : This function makes a binary OR between two expressions.

Remarks : <Expression1> and <Expression2> must have the same type. This function returns the same data type as its arguments.

Example : A%=A% OR 000FFh

See also : [AND, NOT, XOR and IF](#)

8-14-97- OUT – Output writing

Syntax : **OUT** (<Output>) = <Expression>
Accepted types : Expression : Bit
Description : This function sends a logical state to a digital output.
Remarks : <Output> must represent an output name.
Example : OUT(Cutter)=ON
See also : **INP, INPB, INPW, OUTB, OUTW**

8-14-98- OUEMPTY – Communication output buffer empty

Syntax : <Expression>=**OUEMPTY** (<Number>)
Accepted types : <Expression> : bit
Description : This function returns communication output buffer state
Remarks : <Number> is number used to open communication port with the OPEN function.
Example : WAIT OUEMPTY(#1)
See also : **CARIN, CAROUT**

8-14-99- OUTB – 8 outputs writing

Syntax : **OUTB** (<Outputs>) = <Expression>
Accepted types : Expression : Byte
Description : This function sends logical states to a 8 logical outputs block
Remarks : <Outputs> must represent the name of a 8 outputs bloc.
Example : OUTB(Bloc1)=0Fh
See also : **INP, INPB, INPW, OUT, OUTW**

8-14-100- PIXEL – Draw point

Syntax : **PIXEL**(X,Y,Color)
Units : X, Y : pixel
Limits : X : 1 to 240
 Y : 1 to 128
Accepted types : X,Y : byte.
 Color : Bit
Description : This function draws a point at coordinates X, Y.
Remarks : Colour define the colour of the point : black (0) or white (1)
Example : PIXEL(23,15,0) *'Draw a black pixel at coordinates 23,15*

8-14-101- PLCINIT – PLC function initialisation

Syntax : PLCINIT(<Input table>,< Previous input table>, <Output table>, <Masked output table>)
Description : This function indicate to the system, the variable table to use.

Remark : <Input table>, <Previous input table> : Long integer table with any elements as that the system contained the input cards.

<Output table>, <Masked output table> : Integer table with any elements as the system contained the output cards.

<Masked output table> contained the output masks use by the PLC (bit to 1 => output use by the PLC)

exemple : Masque[1]=0FFFFh
Masque[2]=0FFFFh
PlcInit(Entrees,EntreesOld,Sorties,Masque)

See also : PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-102- PLCINP – Read TOR input

Syntax : PLCINP (<Input>) or PLCINP (<Card number>, <Input number>)

Accepted types :<Input> : Bit

<Card number>, <Input number> : Byte

Description : This fonctionn give the state of PLC TOR input.

Remarks : <Input> must represent a TOR input name. The data type returned is a bit.

Exemple : C~=PLCINP(CouteauEnHaut)

See also : PLCINIT, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-103- PLCINPB – Read a 8 inputs block

Syntax : PLCINPB (<Inputs>)

Accepted types :Inputs : Byte

Description : This function return the state of a block of 8 TOR inputs.

Remarks : <Inputs> must represente the name of 8 inputs. The data's type returned is a byte.

Exemple : B#=PLCINPB(Data)

See also : PLCINIT, PLCINP, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-104- PLCINPNE – Read a negative edge on PLC TOR input

Syntax : PLCINPNE (<Input>) or PLCINPNE (<Card number>, <Input number>)

Accepted types :<Input> : Bit

<Card number>, <Input number> : Byte

Description : This function indicate if a negative edge is make on the PLC TOR input.

Remarks : <Input> must represente the name of a TOR input. The data's type returned is a Bit.

Exemple : If PLCINPNE(CouteauEnHaut) Then goto FrontDetecte

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCOUT, PLCOUTB, PLCOUTW

8-14-105- PLCINPPE – Read a positive edge on PLC TOR input

Syntax : PLCINPPE (<Input>) or PLCINPPE (<Card number>, <Input number>)

Accepted types :<Input> : Bit

<Card number>, <Input number> : Byte

Description : This function indicate if a positive edge is make on the PLC TOR input.

Remarks : <Input> must represente the name of a TOR input. The data's type returned is a Bit.

Exemple : If PLCINPPE(CouteauEnHaut) Then goto FrontDetecte

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-106- PLCINPW – Read a 16 inputs block

Syntaxe : PLCOUTW (<Output>) = <Expression>

Accepted types :Expression : Integer

Description : This function change the logic state of the 16 associates images outputs.

Remarks : <Outputs> must represente the name of 16 outputs blocks.

Exemple : PLCOUTW(Bloc1)=0FFFFh

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB

8-14-107- PLCOUT – Write a output

Syntax : PLCOUT (<Output>) = <Expression> or

PLCOUT (<Card number>, <Output number>) = <Expression>

Accepted types :Expression : Bit

<Card number>, <Output number> : Byte

Description : This function change the logic state of image bit.

Remarks : <Output> must represente the name of an output

Exemple : PLCOUT(Couteau)=ON

...

If PLCOUT(Voyant) Then goto Alarm

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUTB, PLCOUTW

8-14-108- PLCOUTB – Write a 8 outputs block

Syntaxe : PLCOUTB (<Output>) = <Expression>

Accepted types:Expression : Byte

Description : This function change the logic state of the 8 associates images outputs.

Remarks : <Outputs> must represente the name of 8 outputs blocks.

Exemple : PLCOUTB(Bloc1)=0Fh

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTW

8-14-109- PLCOUTW – Write a 16 outputs block

Syntaxe : PLCOUTW (<Output>) = <Expression>

Accepted types:Expression : Integer

Description : This function change the logic state of the 16 associates images outputs.

Remarks : <Outputs> must represente the name of 16 outputs blocks.

Exemple : PLCOUTW(Bloc1)=0FFFFh

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB

8-14-110- PLCREADINPUTS – Read the PLC inputs

Syntaxe : PLCREADINPUTS

Description : This function read the PLC inputs and memorize them into the images bits table.

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-111- PLCWRITEOUTPUTS – Write the PLC outputs

Syntax : PLCWRITEOUTPUTS

Description : This function write the PLC ouputs memorized into the images bits.

See also : PLCINIT, PLCINP, PLCINPB, PLCINPW, PLCINPPE, PLCINPNE, PLCOUT, PLCOUTB, PLCOUTW

8-14-112- POWERFAIL – Power fail detect

Syntax : **POWERFAIL**= <ON|OFF>

Description : This function activates or inhibits power fail detect.

Remarks : Power fail detect is activated at power-on.

8-14-113- PRINT – Writing on a communication port

- Syntax : **PRINT** [#<Number>], <Expression> [{ [; | ,] <Expression> }] [; | ,]
- Description : Writes data on a communication port.
- Remarks : <Number> is the number used to open the communication port with the `OPEN` instruction. A semicolon at the end of this instruction means that the previous character is printed immediately after the last character. A comma means that the next character is printed at the next line (by adding a line feed). Print is equal to `Print #1`. If a real expression is printed then decimal part is not printed and `Format$` function must be used. if the transmit buffer is full, the task is blocked and continues when a place in the transmit buffer is liberated.
- Example :

```
PRINT #1, A$, B%
PRINT "LENGTH"
```
- See also : [OPEN](#), [PRINT](#), [CLOSE](#)

8-14-114- PROG – Program start

- Syntax : **PROG**
- Description : This keyword begins a main program bloc. It is as well used to identify the end of the main program block when it is preceded by `END`. <Name> is optional.
- Remarks : One and only one `PROG - END PROG` bloc must be defined in a program.
- Example :

```
PROG
...
END PROG
```
- See also : [END](#)

8-14-115- RAMOK – Test ram status

- Syntax : **RAMOK**
- Description : This function indicates if at the last start-up of the SUPERVISOR, the RAM data checksum was valid.
- Remarks : If `RAMOK=1`, start-up valid
If `RAMOK=0` and data flash copy zone is not blank, the SUPERVISOR backups the data flash zone in the ram zone and starts the task. If `RAMOK=0` and data flash copy zone is blank, the SUPERVISOR doesn't start the task and indicates an error 20 on the status display.
- See also : [FLASHOK](#), [RAMTOFLASH](#), [FLASHTORAM](#)

8-14-116- RAMTOFLASH – Backup saved variables

- Syntax : **RAMTOFLASH**
- Description : This function backups parameters and the first 10000 saved variables in flash memory.
- See also : [RAMOK](#), [FLASHTORAM](#), [FLASHOK](#)

8-14-117- READKEY– Return the state of terminal keyboard

Syntax : <Variable>=**READKEY**

Accepted types : Variable : Byte

Description : This function reads the state of the keyboard of the operator panel and returns the code of the pressed key.

Remarks : This function does not stop the task. Cette fonction est non bloquante pour la tâche. If the input buffer is empty (no key has been pressed) this function returns 0. Use this function if you want to make movement (JOG+, JOG-) on an axe.

Example :
REPEAT
A#=READKEY
UNTIL a#<>0

8-14-118- REALTOLONG – Convert a real to a long integer

Syntax : **REALTOLONG**(<Expression>)

Accepted types : Expression : real

Description : This function converts a real type data in a long integer type data.

Example :
A!=Edit(1,1,4,0,0)
B&=RealToLong(A!)

8-14-119- REALTOINTEGER – Convert a real to an integer

Syntax : **REALTOINTEGER**(<Expression>)

Accepted types : Expression : real

Description : This function converts a real type data in an integer type data.

Example :
A!=Edit(1,1,4,0,0)
B%=RealToInteger(A!)

8-14-120- REALTOBYTE – Convert a real to a byte

Syntax : **REALTOBYTE**(<Expression>)

Accepted types : Expression : real

Description : This function converts a real type data in byte type data.

Example :
A!=Edit(1,1,4,0,0)
B#=RealToInteger(A!)

8-14-121- REPEAT – Repeat...Until

Syntax : **REPEAT**
 {<Instructions>}
UNTIL <Condition>

Description : This structure allows to the system to execute a list of instructions in a loop as long as the given condition is wrong.

Remarks : In the structure REPEAT ... UNTIL the <Instructions> are executed at least once even if the condition is true. The execution of this instruction launches the execution of the next task.

Example :
a%=0
REPEAT
 PRINT #1,a%
 a%=a%*2
UNTIL a%>100

See also : [WHILE](#)

8-14-122- RESTART – Restart system

Syntax : **RESTART**

Description : This function restarts system.

Remarks : This can be used to test system start type : If RESTART function result is false then the system start with power-on and if RESTART function result is true, the system has been restarted by RESTART function.

8-14-123- RIGHTS - String right part

Syntax : **RIGHTS**(<String>,<Number>)

Accepted types : String : Char string
Number : Integer

Description : This function returns the <Number> right characters of a string.

Remarks : To find the characters number in <String>, use LEN(<String>).

Example :
a\$="Sensor1"
b\$=RIGHT\$(a\$,1) 'Result : b\$="1"

See also : [LEFTS](#)

8-14-124- RTRIMS - Remove the right spaces

Syntax : **RTRIMS** (<Expression>)

Accepted types : Expression : Char string

Description : Returns a string copy without the right spaces.

Example :
a\$=" Menu "
b\$=LTRIMS(a\$) 'Result b\$=" Menu"

See also : [LTRIMS](#)

8-14-125- RUN – Launch a task

Syntax : **RUN** <Name>

Description : This instruction is used to launch a stopped task (ex : task declared with manual start).

Remarks : This function has no effects on a suspended, automatic running tasks or already launched task.

Example : Beginning:

```
Wait Inp(Power)=On
RUN Cutter
Wait Inp(Power)=Off
HALT Cutter
Goto Beginning
```

See also : [CONTINUE](#), [HALT](#), [SUSPEND](#)

8-14-126- SEEK – Moving to a save file

Syntax 1 : SEEK #3,<Long moving>

Syntax 2 : <Variable> = SEEK #3

Accepted types : <Long moving>, <Variable> : long integer

Description : The syntax 1 allow to moving in the save file of <Long moving> characters. The moving start at the current position. The syntax 2 allow to know the current position in the save file.

Remarks : The first character is at the position 0l.

Exemple : P&=Seek(#3) 'Rapport nominal : ratio 0.5
Seek #3, P&+100 'Déplacement sur le 100ème caractère à partir
'de la position courante

See also : [OPEN](#), [INPUT\\$](#), [PRINT](#)

8-14-127- SETDATE – Set the date

Syntax : SETDATE(<Year>,<Month>,<Day>,<DayInTheWeek>)

Accepted types : Year, Month, Day, DayInTheWeek : Integer

Description : This instruction set the current date.

See also : [GETDATE](#), [SETTIME](#)

8-14-128- SETINP – Input filters and invert

Syntax : SETINP (<Name>,<Inversion>,<Filtre>)

Units : Filter : milliseconds

Accepted types : Inversion : Long integer

Filter : Byte

Description : This function defines the inputs invert mask and the filter period.

Remarks : <Invert> is a long integer in which each bit represents the invert of each input. This parameter can be defined during the input card configuration.

Example : SETINP (INPUTS11,4,10) ' Second input card invert
' and 10 ms filter

8-14-129- SETOUT – Outputs invert

Syntax : SETOUT (<Name>,<Inversion>)

Accepted types : Inversion : Long integer

Description : This function defines the outputs invert mask.

Remarks : <Invert> is a long integer in which each bit represents the invert of each output. This parameter can be defined during the output card configuration.

Example : `SETOUT(OUTPUTS1,3) ' 2 first outputs card invert`

8-14-130- SETTIME – Set the hour

Syntax : **SETTIME**(<Hours>,<Minutes>,<Seconds>)

Accepted types : <Hours>, <Minutes> and <Seconds> : Integer.

Description : This instruction set the current hour.

See also : [GETTIME](#), [SETDATE](#)

8-14-131- SETUPCOUNTER – Counter configuration

Syntax : **SETUPCOUNTER**(<Counter>,<Input>,<Invert>,<Filter>)

Accepted types : <Counter> : 1 or 2

<Input> : Byte

<Invert>, <Filter> : bit

Description : This instruction defines the counter configuration

Remarks : <Counter> : Counter number (1 or 2)

<Input> : Input number of the input card

<Inversion> : edge choice : 0 for a positive edge, 1 for a negative edge

<Filter> : Filter validation : 0 without filter, 1 for a 2ms filter.

See also : [COUNTER_S](#) , [CLEARCOUNTER](#)

8-14-132- SGN - Sign

Syntax : **SGN** (<Expression>)

Accepted types : Expression : Long integer, real

Description : This function returns a real equal to -1 for the negative numbers, 1 for the positive numbers and 0 for the zero number.

Example : `a!=SGN(10) 'Result : a!=1`

8-14-133- SIN - Sine

Syntax : **SIN** (<Expression>)

Accepted types : Expression : real

Description : This instruction returns the sine of <Expression>. <Expression> is expressed in radians.

Example : <Expression> must be a numerical expression.

See also : [COS](#), [ARCTAN](#), [TAN](#)

8-14-134- SIGNAL – Event generation

Syntax : **SIGNAL** <Name>

Description : This instruction generates an event.

Remarks : <Name> must be the name used by WAIT EVENT instruction. The only first task which was waiting for this event can then continue.

Example : Program1 Program2

 WAIT EVENT Ready SIGNAL Ready

See also : [WAIT EVENT, DIFFUSE](#)

8-14-135- SQR – Square root

Syntax : **SQR** (<Expression>)

Accepted types : Expression : real

Description : This function returns the square root of <Expression>.

Example : a!=SQR(2)

8-14-136- SPACES\$ - Space made string

Syntax : **SPACES\$**(<Number>)

Limits : Number : 1 to 255

Accepted types : Number : Byte

Description : This function returns a space made string.

Example : a\$=SPACES\$(10) 'Result a\$=" "'

See also : [STR\\$, VAL](#)

8-14-137- STR\$ - Char characters convert

Syntax : **STR\$**(<Expression>)

Accepted types : Expression : Byte ... Real

Description : This function returns a string which represents a numerical expression value.

Remarks : When the numbers are converted in text, a head space is always reserved for the sign of <Expression>. If <Expression> is positive, the string returned by Str\$ contains a head space and the sign plus is insinuated.

Warning : This function can send back a value according to the notation of type with exponent. It's preferable to use the instruction FORMAT\$ with number=1

Example : a%=10
 b\$=STR\$(a%) 'Result b\$=" 10"

See also : [VAL](#)

8-14-138- STATUS – Task state

Syntax : **STATUS** (<Name>)

Description : This function returns a task state

Remarks : The possible values are :

 0 : The task is stopped

 1 : The task is suspended

2 : The task is running

Example : Run Cutter
 Wait Status(Cutter)=0

8-14-139- SUB – Subroutine

Syntax : **SUB**<Name>

Description : This keyword begins a subprogram block and is also used to define the end of a subprogram block when it is preceded by END.

Remarks : The blocs SUB - END SUB must be outside of a PROG -END PROG bloc .

Example : SUB Move
 ...
 END SUB

See also : **END**

8-14-140- SUSPEND – Suspend a task

Syntax : **SUSPEND** <Name>

Description : This instruction suspends a task in run

Remarks : This instruction has no effects on stopped tasks. All the movements in the buffer of movements are executed.

Example : Wait Inp(Start)
 RUN Cutter
 Begin:
 Wait Inp(Stop)
 SUSPEND Cutter
 Wait Inp(Start)
 CONTINUE Cutter
 Goto Begin

See also : **RUN, CONTINUE, HALT**

8-14-141- STRING\$ - String creation

Syntax : **STRING\$**(<Number>, <Code>)

Limits : Number, Byte : de 0 à 255

Accepted types : Number, Code : Byte

Description : This function returns a char string whose characters have the same ASCII code.

Remarks : We use **STRING\$** to create a string which is constituted of a repeated character. <Number> is a numerical expression which indicates the length of the returned string. <Code> is the ASCII code of the character used to build a string and a numerical integer expression between 0 and 255.

Example : a\$=STRING\$(10,"0") 'Result a\$="0000000000"

See also : **STR\$, VAL**

8-14-142- TAN - Tangent

Syntax : **TAN** (<Expression>)

Accepted types : Expression : real

Description : This instruction returns the tangent of <Expression>. <Expression> is an angle expressed in radians.

Remarks : This argument <Expression> must be a numerical valid expression. The function TAN takes an angle and returns the ratio of two sides rectangle triangle. The ratio is the length of the opposite side of an angle divided by the length of the adjacent side of the angle.

Example : `a!=TAN(PI)`

See also : [SIN](#), [ARCTAN](#), [TAN](#)

8-14-143- TIME – Time base

Syntax : **TIME**

Description : This instruction returns a long integer which represents the number of milliseconds from the last power-on. This instruction allows to execute no-locking waits. At the start-up of the SUPERVISOR, TIME is equal to zero and increases up to 2^{31} . Then, it passed to -2^{31} and increases to 0. This cycle is about 24 days long.

Remarks : If the SUPERVISOR is used more than 24 days, you can use the TIMER instruction to suppress the crossing of 2^{31} to -2^{31} .

Example : `Tempo&=Time+5000 'loads 5s delay`
`WAIT (INP(Start)=On) Or (Time>Time&)`
`'if the start input is not activate in the 5s,`
`'the program continues`

See also : [TIMES](#), [TIMER](#)

8-14-144- TIMER – Wide time base

Syntax : **TIMER**

Description : This instruction returns a real which represents the number of milliseconds from the last power-on. This instruction allows to execute no-locking waits. At the start-up of the SUPERVISOR, TIMER is equal to zero and increases with a step equal to 0.001(ms).

Example : `Timer!=Timer+5.25 'loads 5.25 delay`
`WAIT (INP(Start)=On) Or (Timer>Time!)`
`'if the start input is not activate in the 5.25s,`
`'the program continues`

See also : [TIMES](#), [TIME](#), [DATES](#)

8-14-145- TIMES - Current hour

Syntax : **TIMES**

Description : This instruction returns a 8 chars string with hh:mm:ss form, where hh are the hours (00-23), mm are the minutes (00-59) and ss are the seconds (00-59).

See also : [TIME](#), [TIMER](#), [DATES](#)

8-14-146- TX485 – Modify RS485 output state

Syntax : **TX485**(<Number>)=<Expression>
Accepted types : Expression : Integer
Description : This function enable RS485 port output for a specified number of characters. If number is 0 then output is disabled.
Remarks : <Number> is number used to open communication port with the OPEN function. In RS485 mode all sent characters are also received.
Example : `TX485 (#1) =10`

8-14-147- UCASE\$ - Uppercase

Syntax : **UCASE\$**(<Expression>)
Accepted types : Expression : Char string
Description : This function returns a string, in which all the letters of the argument have been converted in uppercases.
Remarks : The argument <Expression> must be a char string. Only the lowercases letters are converted in uppercases ; the other letters are not modified.
Example : `a$="Sensor1"`
`b$=UCASE$(a$) 'Result : b$="SENSOR1"`
See also : [LCASE\\$](#)

8-14-148- VAL – Convert a string in numeric

Syntax : **VAL**(<Expression>)
Accepted types : Expression : Char string
Description : This function returns the numerical value of the string <Expression>.
Remarks : The argument <Expression> is a char string which can be interpreted as a numerical value. The VAL function stops reading the string when the first character is not known. VAL doesn't know as well the spaces, tabulations and line jumps. The VAL function always returns a real data type.
Example : `a$="10"`
`b!=VAL(a$) 'Result b!=10`
See also : [STR\\$](#)

8-14-149- VERSION – Operating system version

Syntax : `<Variable>=VERSION`
Accepted type : Variable : chaîne de caractères
Description : This function return a string with the version of the operating system.

8-14-150- VLINE – Draw a vertical line

Syntax : **VLINE**(X1,Y1,Y2,color)
Units : X1, Y1, Y2 : pixel


Limits : X1 : 1 to 240
 Y1, Y2 : 1 to 128

Accepted types : X1, Y1, Y2 : byte.
 Colour : Bit

Description : This instruction draws a vertical line with its start point in X1, Y1 and its end point in X1, Y2 on the operator panel S640.

Remarks : Colour defines the colour of the line : black (0) or white (1)

Example : `VLINE(10,5,25,0)`



8-14-151- WAIT EVENT – Event waiting

Syntax : `WAIT EVENT <Name>`

Description : This instruction allows to the system to wait until an event is received. The execution of this instruction launches the execution of the next task.

Remarks : In the WAIT EVENT instruction, the following instructions are not executed if the event is not received. This instruction provides a passive wait for event.

Example : `WHILE Ready=False DO END WHILE` *'Active waiting*
'This program is similar to :
`WAIT EVENT Ready` *'Passive waiting*

See also : [SIGNAL](#), [DIFFUSE](#), [WAIT STATE](#), [DELAY](#)

8-14-152- WAIT KEY – Key waiting

Syntax : `WAIT KEY`

Description : This function waits for a key pressed on the operator panel and record its code in the KEY variable. The execution of this instruction launches the execution of the next task.

Example : `WAIT KEY`
`IF KEY=@F1 THEN GOTO ...`
`IF KEY=@F2 THEN GOTO ...`
`...`

8-14-153- WAIT – Condition waiting

Syntax : `WAIT <Condition>`

Description : This instruction allows to the system to wait for a condition. The execution of this instruction launches the execution of the next task.

Remarks : The WAIT instruction, the following instructions are not executed if the <Condition> is false. This instruction provides a passive wait for a condition. The STATE keyword is optional.

Example :

```
WHILE INP(Sensor)=Off DO END WHILE 'Active waiting
`this program is similar to :
WAIT INP(Sensor)=On 'Passive waiting
```

See also : [WAIT EVENT, DELAY](#)

8-14-154- WATCHDOG – Watchdog

Syntax 1 : WATCHDOG = ON / OFF

Syntax 2 : WATCHDOG

Description : This function allows to the user to read or write the watchdog relay state.

Remarks : The watchdog state under power-on is OFF. Then, it must be set to ON when the program starts.

Example :

```
WATCHDOG=ON.
WAIT WATCHDOG=OFF
```

8-14-155- WHILE – While...Do...End While

Syntax :

```
WHILE <Condition> DO
    {<Instructions>}
END WHILE
```

Description : This instruction allows to the system to execute a list of instructions in a loop as long as the given condition is true. The execution of this instruction launches the execution of the next task.

Remarks : In the WHILE ... DO ... END WHILE instruction, <Instruction>are not executed if the condition is false.

Example :

```
a%=0
WHILE a%<=100
    PRINT #1,a%
    a%=a%*2
END WHILE
```

See also : [REPEAT](#)

8-14-156- XOR – Exclusive OR operator

Syntax : <Expression1> XOR <Expression2>

Accepted types : Expression1, Expression2 : Bit, Byte, Integer

Description : This function makes a Exclusive Or between the expressions.

Remarks : <Expression1> and <Expression2> must represent a bit, a byte or an integer. <Expression1> and <Expression2> must have the same data type. This function returns the data type of <Expression1>.

Example :

```
IF A% XOR 0FF00h THEN ...
```

See also : [AND, OR, NOT, IF](#)

9- CANopen

9-1- Definition

9-1-1- Introduction

The CAN bus (Controller Area Network) appeared in the middle of the 80ies as an answer for the data transmission in the automotive fields. This kind of bus can have transmission speeds up to 1 Mb/s.

The CAN specifications are defining 3 layers among the ISO/OSI model: the physical one, the data linking one and the application one. The physical layer defines the data transmission mode regarding the transmission support. The data linking layer is the nucleus of the CAN protocol because it deals with the frame to send, the arbitration, the defaults detection, etc. The last layer is also called CAL (CAN Application Layer). It is a general description of the language for the CAN networks which offers many communication services.

CANopen is a type of network based on the serial bus system and the application layer CAL. CANopen offers only part of the communication services that CAL has at its disposal. Those are the necessary advantages that need small performances computer, without storage capability.

So the CANopen is an application layer standardised by the CIA (CAN In Automation) specifications: DS-201...DS-207

The network manager permits an easier network initialisation. The network can be extended with all the components the user wants to.

The CAN bus is a multi-master bus. The sent messages are identified, instead of the connected modules as in the other field-buses. The network elements are allowed to send their message each time the bus is free. Bus conflicts are solved with a priority level given to messages. The CAN bus emits messages divided among 2032 priority levels. All the network elements have the same rights, so this communication is possible only without master bus.

Each element is deciding itself when it has data to send. However it is possible to send data with another element. This demand is made with the distant frame.

The CANopen specifications (DS-201...DS-207) define the technical and functional characteristics needed by any device to be plugged in the network. The CANopen bus makes a distinction from the server devices and the client devices.

9-1-2- CANopen communication

The CANopen communication profile permits to specify information for data exchange in real time and parameters. The CANopen uses optimised services following the data types:

↳ PDO (Process Data Object)

- ⇒ Data exchange in real time
- ⇒ High priority identifier
- ⇒ Synchronous or asynchronous transmission
- ⇒ 8 bytes (one message) maximum
- ⇒ Pre-defined format

↳ SDO (Service Data Object)

- ⇒ Access to the objects dictionary of a device
- ⇒ Low priority identifier

- ⇒ Asynchronous transmission
- ⇒ Data distributed in many telegrams
- ⇒ Data addressed with an index

The characteristics diffused on the CAN bus are received and evaluated by all the connected devices. Each service of a CAN device is configured by a COBID (Communication Object Identifier). The COBID is an identifier which characterises the message. It tells to a device if the message must be taken in account. For each service (PDO or SDO), it is necessary to specify a COBID during the emission (sending a message) and a reception COBID (receiving a message). For the first SDO server, the COBID is fix and can not be modified remotely. Moreover, it is calculated from the NodeID. The NodeID is the parameter which characterises the device and permits the unique access to it.

PDO (Process Data Object)

It is a data exchange arbitrated between 2 modules. The PDO can transfer in turn some synchronisation or controlled events to realise the message sending request. With the controlled events mode, the load of the bus can be very reduced. A device can therefore realise a high performance with a low transfer rate.

The data exchange with the PDO uses the CAN advantages:

- ↳ Sending messages can be done from an asynchronous event (controlled event)
- ↳ Sending messages can be done from the reception of a synchronisation event.
- ↳ Recovery from a remote frame.

SDO (Service Data Object)

It is a data exchange point to point. A device is asking for an access in the objects list of a SDO. This one sends back an information corresponding to the type of request made by the caller. Each SDO can be either client and / or server. A server SDO can not send a request to another SDO, but it can answer any request from another client SDO. Unlike the PDOs, the SDOs must follow a particular communication protocol . The frame to send must have 8 bytes :

- ↳ Domain Protocol (Byte 0) : it defines the command (Upload, Download,...)
- ↳ Index on 16 bits (Bytes 1 et 2) : It defines the objects dictionary address.
- ↳ Sub-index on 8 bits (Octet 3) : It defines the element of the selected object in the dictionary
- ↳ Parameter (Octet 4 à 7) : It defines the value of the parameter read or written.

The network manager has a simplified mode to start the network up. The network configuration is not necessary in all the cases. The default configuration of the parameters may be enough. If the user wants to optimise the CANopen network or increase its functionalities, he can the modify himself these parameters. In the CANopen networks, each device has the same rights and the data exchange is directly regulated between each participant device.

The profile of a device defines the necessary parameters for a communication. The contents of this profile is specified by the constructor. Devices with the same profile are directly interchangeable. Most of the parameters are described by the constructor. The profile has empty places too which are for the future functionality extensions.


In most of the master/slave buses, the efficiency of the master determinates the comportment of the whole network. Moreover, slaves can not communicate directly one with the other. All these characteristics are increasing the transmission errors. CANopen suppress all of these drawbacks. The timing comportment can be specified individually for each respective task of the participant

devices. Like that, the whole communication system does not need to have more efficiency if only some of the devices need so. Moreover, an automatic task can be separated for each of the participant devices. So the performances of the network manager can be used in an optimised way and can increase at any time by adding new participant devices.

The variables mapping used during the PDO type exchanges permits to use in an optimal way the current bandwidth of the bus. CANopen determinates default values of all the parameters.


9-1-3- Network configuration

The CanOpen network is made of several devices, each of them can be master and slave. They are identified in the network by an arbitrary number, called Node-Id. This parameter must be unique: two different devices of the Can Open network can not have the same Node-Id. This Node-Id is very important, it is the real identity card of the peripheral on the Can Open network.



Example of CanOpen network configuration

The wiring is as follows:



Wiring of a Can Open network

Warning: Do not forget the ending resistors at each end of the Can Open network. For the SERAD products (SCAN, DIALOG and SUPERVISOR), the resistor is validated if the jumper JP1 is present. If it is not, the resistor is un-validated.

For the other products, see the notice.

9-1-4- Type of send messages

There are two main kinds of messages sent on the Can Open network:

- The SDO are transmitting data
- The PDO are transmitting events

9-2- SUPERVISOR CANopen bus

9-2-1- Presentation - SCAN board

The SCAN co-processor board is included in the SUPERVISOR. It owns three local tables of 254 data each, for these 3 data formats: 8 bits, 16 bits, 32 bits.

These tables can be read and written by the SUPERVISOR without going into the Can Open network, with the instructions *CanLocal*.

The different parameters and the data tables are stored in a two-dimensions array, called **dictionary**.

Each data or parameter is defined by an address index, and a sub-index address.

The SCAN bus can communicate with another device of the network by different ways. It can let data at other devices disposal by writing them in its local table: any other peripheral can then read and write this local table. It is the way used for example to communicate between an intelligent operator terminal Dialog 80 or 640.


The SCAN bus can also read and write a local table of another device. This operation is then done with the instructions *CanRemote*.

9-2-2- Characteristics

- ↳ A SDO default server to set the parameters of the remote board by a supervisor.
- ↳ A SDO client to access to variables and peripheral parameters such as displays, PLC, PC boards.
- ↳ 8 PDO in emission to drive the outputs of the I/Os modules or signal an event to SUPERVISOR.
- ↳ 8 PDO in reception to receive the inputs of the I/Os modules or signal an event to SUPERVISOR.
- ↳ An array of 254 variables « 8 bits non signed » with read and write access for SDO.
- ↳ An array of 254 variables « 16 bits non signed » with read and write access for SDO.
- ↳ An array of 254 variables « 32 bits non signed » with read and write access for SDO.

Erreur! Signet non défini. Direct access functions to the bus CAN to send and receive specific messages such as the functions NMT et DBT.

9-2-3- Connections




Use a cable with 2 twisted shielded pairs and a general shielding (type LiY.CY.CY or equivalent) :

- one pair for CAN_L and CAN_H
- one pair for the GND

Link the shieldings to the terminals

Example with 2 MCS 32 EX and 1 SUPERVISOR in a Can Open network :



Warning

At each end of the Can Open network do not forget a 120 Ω ending resistor between CAN_H and CAN_L (for a Dialog 80, Dialog 640, Supervisor 640 or SCAN board, the installation of the jumper JP1 can validate this resistor.

For example, in the previous configuration, we have :

SUPERVISOR 640 : Jumper JP1 ON

SCAN board n°2 : Jumper JP1 OFF

SCAN board n°3 : Jumper JP1 ON

Maximal transmission speed regarding the length of the Can Open network

Maximal transmission speed


Network length

10K to 125 kBauds	500 m
250 kBauds	250 m
500 kBauds	100 m
800 kBauds	50 m
1 Mbauds	25 m

9-2-4- Test and diagnostic of the Can Open network

From the SPL software, activate the debug mode and then double-click on the SCAN board.

VIEW page



Card : visualisation of the communication errors number in the board and its state

3 different states:

STOPPED mode : the CANOpen bus waits for a StartCan instruction

STARTED mode : the CANOpen bus is ready to communicate

ACTIVE mode: the CANOpen bus is communicating

Can : visualisation of the transmission and reception number in free protocol

Server SDO : visualisation of the sent request and correct answers.


Client SDO : visualisation of the sent correct answers and request

Tx PDO : visualisation of the sent PDO number (sub-total per PDO number)

Rx PDO : visualisation of the received PDO number (sub-total per PDO number)

Clear : click here to clear all the counters of this page

DEBUG page :



This page can validate very easily the good comportment of two SCAN boards inside of a Can Open network.

The procedure is as follows:

On the local board, stop the tasks

Go to the debug menu of the SCAN board

Fill in its Node-Id, the transmission speed and the distant card Node-Id.

For the distant card, there are two different cases :

There is no task in the SUPERVISOR

You have to create one, to start the CANOpen bus, in automatic mode, called INIT for example:

Prog

Delay 2000

StartCan (CardName, Speed, Node-Id)

Halt INIT

End Prog

There are already tasks in the SUPERVISOR

In the automatic task, add at the beginning :

Prog

Delay 2000

```
StartCan (CardName, Speed, Node-Id)
Halt INIT
...
End Prog
```

Warning: be sure that there is only one task in automatic mode, otherwise pass the others in manual mode.

In both cases, compile and transfer the program

Validate the test by clicking on “START” in the local card. The percentage of errors will tell you very quickly if the Can Open bus is right on a hardware point of view for these two SUPERVISOR.

NB : The errors percentage is calculated with the values printed in the “View” page. Therefore it may be useful to clear these values from time to time.

9-2-5- Dictionary

The dictionary contains the different parameters and variables of the board. They are directly accessible for the SUPERVISOR with the functions **CANSETUP**. The variables tables are accessible with the functions **CANLOCAL**. To access to the other CANopen peripheral parameters, you have to use the functions **CANREMOTE**.

Index	Sub-idx	Nom	Type	Attr.	Défaut	Description
1000	0	Device type	32 bits non signé	ro	403	type d'appareil
1001	0	Error register	32 bits non signé	ro	0	registre d'erreur interne
1002	0	Manufacturer Status Register	32 bits non signé	ro	0	registre d'état spécifique au constructeur
1003	0	predefined error field	8 bits non signé	ro	1	nombre d'erreurs apparues
	1	actual error	32 bits non signé	ro	0	dernière erreur apparue
1004	0	number of PDO's supported	32 bits non signé	ro	00080008h	Nombre de PDO supporté
	1	Number of synchronous PDO	32 bits non signé	ro	0	Nombre de PDO synchrone supporté
	2	Number of asynchronous PDO	32 bits non signé	ro	00080008h	Nombre de PDO asynchrone supporté
100B	0	Node ID	32 bits non signé	ro	aucune	
100F	0	Number of SDO's supported	32 bits non signé	ro	00010001h	Nombre de SDO supporté
1200	0	Number of elements	8 bits non signé	ro	2	paramètre du 1er SDO serveur
	1	SDO receive COB-Id	32 bits non signé	ro	600h+node-ID	COB-ID de réception du 1er SDO serveur
	2	SDO transmit COB-ID	32 bits non signé	ro	580h+node-ID	COB-ID d'envoi du 1er SDO serveur
	3	node ID of the SDO client	8 bits non signé	rw	none	Node ID du SDO client
1280	0	Number of elements	8 bits non signé	ro	2	paramètre du 1er SDO client
	1	SDO transmit COB-ID	32 bits non signé	ro	aucune	COB-ID de réception du 1er SDO client
	2	SDO receive COB-Id	32 bits non signé	ro	aucune	COB-ID d'envoi du 1er SDO client
	3	node ID of the SDO server	8 bits non signé	rw	none	Node ID du SDO serveur
1400	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 1er PDO
	1	COB-ID	32 bits non signé	rw	200h + Node Id	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1401	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 2ème PDO
	1	COB-ID	32 bits non signé	rw	300h + Node Id	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1402	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 3ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1403	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 4ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1404	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 5ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1405	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 6ème PDO

	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1406	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 7ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1407	0	Number of elements	8 bits non signé	rw	2	paramètre de réception du 8ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de la réception
1800	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 1er PDO
	1	COB-ID	32 bits non signé	rw	180h + Node Id	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1801	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 2ème PDO
	1	COB-ID	32 bits non signé	rw	280h + Node Id	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1802	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 3ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1803	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 4ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1804	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 5ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1805	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 6ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1806	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 7ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
1807	0	Number of elements	8 bits non signé	rw	2	paramètre d'émission du 8ème PDO
	1	COB-ID	32 bits non signé	rw	aucune	COB-ID utilisé par le PDO
	2	Transmission type	8 bits non signé	rw	254	Type de l'émission
7180	from 1 to FEh	Read 32 bits variables	32 bits signé	ro	aucune	
7200	from 1 to FEh	Read 8 bits variables	8 bits non signé	ro	aucune	

7280	from 1 to FEh	Read 16 bits variables	16 bits non signés	ro	aucune	
8180	from 1 to FEh	Write 32 bits variable	32 bits signé	wo	aucune	
8200	from 1 to FEh	Write 8 bits variable	8 bits non signé	wo	aucune	
8280	from 1 to FEh	Write 16 bits variable	16 bits non signés	wo	aucune	

9-3- Instructions list

9-3-1- List of the CANopen instructions

A) Read and write the dictionary

CANSETUP#	Read or write a parameter (byte)
CANSETUP%	Read or write a parameter (word)
CANSETUP&	Read or write a parameter (long integer)

B) Modification of local variables

CANLOCAL#	Read or write a local variable (byte)
CANLOCAL%	Read or write a local variable (word)
CANLOCAL&	Read or write a local variable (long integer)

C) Modification of remote variables

CANREMOTE#	Read or write a remote variable (byte)
CANREMOTE%	Read or write a remote variable (word)
CANREMOTE&	Read or write a remote variable (long integer)

D) Instructions in mode PDO

CAN	Read or write data
CANEVENT	Test of a message arrival
PDOEVENT	Test of a PDO arrival
PDO	Read or write data by a PDO
SETUPCAN	configuration of a message

E) Control instructions

CANERROR	Faults detection
CANERRORCOUNTER	Controls and erases the communication errors
STOPCAN	Starts the CANopen module
STARTCAN	Stops the CANopen module

F) Instructions in mode PDO

SDOEVENT	Allow to know if a writing has been done
SDOINDEX	Allow to know the index of the dictionary's object
SDOSUBINDEX	Allow to know the sub-index of the dictionary's object

9-3-2- CAN – Read and write a message

Syntax 1 : **CAN**(<Board>, <Data>)

Syntax 2 : <Variable> = **CAN**(<Board>)

Accepted types : <Data>, <Variable> : Characters string

Description : This function reads or send a message.

Remark : <Board> must be a CANopen board. You have to tell the parameters of the reception COBID to receive the message.

9-3-3- CANERROR – Faults detection

Syntax : <Variable> = **CANERROR**(<Board>)

Accepted types : <Variable> : Boolean

Description : This function tells if a default occurred.

Remark : <Board> must be CANopen board.

9-3-4- CANERRORCOUNTER – Controls and erases the communication errors

Syntax 1 : <Variable> = **CANERRORCOUNTER** (<Board>)

Syntax 2 : **CANERRORCOUNTER**(<Board>) = 0

Limits : <Variable> : from 0000h to FFFFh

Accepted types : <Variable> : integer

Description : The syntax 1 tells the number of errors which had occurred since the counter has been reset. The second resets the errors counter.

Remark : <Board> must be CANopen board.

9-3-5- CANEVENT – Test a message arrival

Syntax : <Variable> = **CANEVENT** (<Board>)

Accepted types : <Variable> : Boolean

Description : This function permits to know if a message has been receipted.

Remark : <Board> must be a CANopen board. You have to tell the parameters of the reception COBID to receive the message.

9-3-6- CANLOCAL – Read or write a local variable

Syntax 1 : **CANLOCAL#** (<Board>, <Index>, <Expression>)

Syntax 2 : <Variable> = **CANLOCAL#** (<Board>, <Index>)

Syntax 3 : **CANLOCAL%** (<Board>, <Index>, <Expression>)

Syntax 4 : <Variable> = **CANLOCAL%** (<Board>, <Index>)

Syntax 5 : **CANLOCAL&** (<Board>, <Index>, <Expression>)

Syntax 6 : <Variable> = **CANLOCAL&** (<Board>, <Index>)

Limits : <Index> : from 0000h to FFFFh

Syntax 1 and 2 : <Variable>, <Expression> : from 00h to FFh

Syntax 3 and 4 : <Variable>, <Expression> : from 0000h to FFFFh

Syntax 5 and 6 : <Variable>, <Expression> : +/- 7FFFFFFFh

Accepted types : Syntax 1 and 2 : <Expression>, <Variable> : Byte
Syntax 3 and 4 : <Expression>, <Variable> : Integer
Syntax 5 and 6 : <Expression>, <Variable> : Long integer

Description : This function can read or write a local variable of the CANopen board dictionary of the SUPERVISOR. The syntax 1 and 2 are giving an access to a table of 8 bits non-signed variables. The syntax 3 and 4 are giving an access to a table of 16 bits non-signed variables. The syntax 5 and 6 are giving an access to a table of 32 bits signed variables.

Remark : <Board> must be a CANopen board. <Index> must refer to a local variable of the dictionary.

9-3-7- CANSETUP – Read or write a parameter

Syntax 1 : **CANSETUP#** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 2 : <Variable> = **CANSETUP#** (<Board>, <Index>, <Sub-Index>)

Syntax 3 : **CANSETUP%** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 4 : <Variable> = **CANSETUP%** (<Board>, <Index>, <Sub-Index>)

Syntax 5 : **CANSETUP&** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 6 : <Variable> = **CANSETUP&** (<Board>, <Index>, <Sub-Index>)

Limits : <Index> : from 0000h to FFFFh
<Sub-index> : from 00h to FFh
Syntax 1 and 2 : <Variable>, <Expression> : from 00h to FFh
Syntax 3 and 4 : <Variable>, <Expression> : from 0000h to FFFFh
Syntax 5 and 6 : <Variable>, <Expression> : +/- 7FFFFFFFh

Accepted types : Syntax 1 and 2 : <Expression>, <Variable> : byte
Syntax 3 and 4 : <Expression>, <Variable> : Integer
Syntax 5 and 6 : <Expression>, <Variable> : Long integer

Description : This function reads or writes data in the SUPERVISOR CANopen board dictionary.

Remark : <Board> must be a CANopen board. <Index> and <Sub-Index> must refer to elements of the dictionary.

9-3-8- CANREMOTE – Read or write a remote variable

Syntax 1 : **CANREMOTE#** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 2 : <Variable> = **CANREMOTE#** (<Board>, <Index>, <Sub-Index>)

Syntax 3 : **CANREMOTE%** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 4 : <Variable> = **CANREMOTE%** (<Board>, <Index>, <Sub-Index>)

Syntax 5 : **CANREMOTE&** (<Board>, <Index>, <Sub-Index>, <Expression>)

Syntax 6 : <Variable> = **CANREMOTE&** (<Board>, <Index>, <Sub-Index>)

Limits : <Index> : from 0000h to FFFFh
<Sub-index> : from 00h to FFh
Syntax 1 and 2 : <Variable>, <Expression> : from 00h to FFh

Syntax 3 and 4 : <Variable>, <Expression> : from 0000h to FFFFh
Syntax 5 and 6 : <Variable>, <Expression> : +/- 7FFFFFFFh
Accepted types : Syntax 1 and 2 : <Expression>, <Variable> : Byte
Syntax 3 and 4 : <Expression>, <Variable> : Integer
Syntax 5 and 6 : <Expression>, <Variable> : Long integer
Description : This function reads or writes a remote variable in the dictionary of the SUPERVISOR CANopen board.
Remarks : <Board> must be a CANopen board. <Index> and <Sub-Index> must refer to an element of the remote dictionary. You have to tell the SDO client and server parameters of the board before sending any remote variable reading or writing.

9-3-9- PDO – Read or write data from a PDO

Syntax 1 : **PDO** (<Board>, <NumPDO>, <Data>)
Syntax 2 : <Variable> = **PDO** (<Board>, <NumPDO>)
Limits : <NumPDO> : from 01h to 08h
<Data>, <Variable> : characters string
Accepted types : <NumPDO> : Byte
<Data>, <Variable> : characters string
Description : This function reads or writes a PDO.
Remarks : <Board> must be a CANopen board. You have to tell transmission parameters of the PDO to receive a PDO.

9-3-10- PDOEVENT – Test a PDO arrival

Syntax : <Variable> = **PDOEVENT** (<Board>, <NumPDO>)
Limits : <NumPDO> : from 01h to 08h
Accepted types : <Variable>, <NumPDO> : Byte
Description : This function tells if a request of a PDO is effective.
Remark : <Board> must be a CANopen board. You have to tell the transmission parameters of the PDO to receive a PDO.

9-3-11- SDOEVENT – Event SDO

Syntax : <Variable bit> = **SDOEvent**(<Can Card>)
Description : This function allow to know if a writting by SPO has been made in the CAN card. The reading of the bit, reset it.

9-3-12- SDOINDEX – Index SDO

Syntax : <Variable integer> = **SDOIndex**(<Can Card>)
Description : This function allow to know the index of the dictionary's object who has been wrotten.

9-3-13- SDOSUBINDEX – Sub-index SDO

Syntax : <Variable octet> = SDOSubIndex(<Can Card>)
Description : This function allow to know the sub-index of the dictionary's object who has been wrotten.

9-3-14- SETUPCAN – Configuration of a message

Syntax : **SETUPCAN** (<Board>, <TX COBID>, <RX COBID>)
Accepted types : <TX COBID>, <RX COBID> : Long integer
Description : This function configures the reception and transmission COBID before sending a message.
Remark : <Board> must be a CANopen board.

9-3-15- STARTCAN – Start a CANopen board

Syntax : **STARTCAN** (<Board>, <Node ID>, <Freq>)
Limits : <Node ID> : from 01h to FFh
<Freq> : from 1 to 8
Accepted types : <Node ID>, <Freq> : Byte
Description : This function links the CANopen board to the network.
Remark : <Board> must be CANopen board.

9-3-16- STOPCAN – Stop a CANopen board

Syntax : **STOPCAN** (<Board>)
Description : This function puts the corresponding board out of the CANopen network.
Remark : <Board> must be CANopen board.

9-4- Examples

9-4-1- CANopen kink between two SUPERVISOR

The communication configuration between two SUPERVISOR consists of giving a NodeID number to each SUPERVISOR. Then a communication with SDO is possible when those are configured. You can also exchange events with PDO.

The default COBID of the servers are 600h+NodeID in reception and 580h+NodeID in emission. The default COBID of the first PDO are 200h+NodeID for the reception and 180h+NodeID for the emission. You configures the clients in accordance with that.

↳ Initialisation of the SUPERVISOR 1

```
'Start the board at 500KBits/s on the node 1
StartCan(Can1,1,5)
'COBID ClientSDO Rx SUPERVISOR1= COBID ServerSDO Tx SUPERVISOR2
CanSetup&(Can1,1280h,1,582h)
'COBID ClientSDO Tx SUPERVISOR1= COBID ServerSDO Rx SUPERVISOR2
```

```
CanSetup&(Can1,1280h,2,602h)
'COBID TxPDO1 = COBID RxPDO2
CanSetup&(Can1,1800h,1,202h)
```

↳ Initialisation of the SUPERVISOR 2

```
'Start the board at 500KBits/s on the node 2
StartCan(Can2,2,5)
'COBID ClientSDO Rx SUPERVISOR2= COBID ServerSDO Tx SUPERVISOR1
CanSetup&(Can2,1280h,1,581h)
'COBID ClientSDO Tx SUPERVISOR2= COBID ServerSDO Rx SUPERVISOR1
CanSetup&(Can2,1280h,2,601h)
'COBID TxPDO2 = COBID RxPDO1
CanSetup&(Can2,1800h,1,201h)
```

When this initialisation is over the SUPERVISOR can exchange data and events. In this example, the SUPERVISOR 2 sends positioning commands to the X axis of the SUPERVISOR 1. The SUPERVISOR 1 receives the order by a PDO and tells the end of the command by sending a PDO. The position to reach is read in the variable 5 of the table “read 32 bits variables” of the SUPERVISOR 2. The SUPERVISOR 1 also makes the X axis position available in the variable 1 of its table “write 32 bits variable”.

```
Wait PDOEvent(Can1,1)           'Waits for the PDO which signals the message
O$=PDO(Can1,1)                 'Reads the PDO
Ordre#=Asc(Left$(O$,1))       'Decoding the command
Pos&=CanRemote&(Can1,7180h,5)  'Reads the position
If Ordre#=1 Then Stta(X=Pos&)  'Execution in absolute
If Ordre#=2 Then Sttr(X=Pos&)  'Execution in relative
...
Repeat
  P&=RealToLong(Pos_S(X))      'Read the position
  CanLocal&(Can1,1,P&)         'Updates the position
Until Move_S(X)=0
O$=Chr(0)                      'Answer
PDO(Can1,1,O$)                 'Acquits the command
```

The SUPERVISOR 2 sends its commands, reads the X axis position in the variable 1 of the table “read 32 bits variables” and send positions in the variable 5 of the table “write 32 bits variables”.

```
CanLocal&(Can2,5,10.25)        'Writes the position
O$=Chr(1)                     'Sends a command for absolute motion
PDO(Can2,1,O$)                 'Sends the PDO
Repeat
  P&=CanRemote&(Can2,7180h,1)  'Reads the position
  ...
Until PDOEvent(Can2,1)        'Until the end of motion
```

9-4-2- CANopen linking between a SUPERVISOR and an I/Os module

The communication configuration between a SUPERVISOR and an I/Os module consists of giving a NodeID number to each of them. In general cases the NodeID of an I/Os device is configured with switches. Then a communication with SDO and PDO is possible.

The default COBID of the servers are 600h+NodeID in reception and 580h+NodeID in emission. The default COBID of the first PDO are 200h+NodeID for the reception and 180h+NodeID for the emission. You configure the clients in accordance with that.

↳ Initialisation of the SUPERVISOR

```
'Start the board at 500KBits/s on the node 1
StartCan(Can1,1,5)
'COBID ClientSDO Rx SUPERVISOR= COBID ServerSDO Tx I/O
CanSetup&(Can1,1280h,1,582h)
'COBID ClientSDO Tx SUPERVISOR= COBID ServerSDO Rx I/O
CanSetup&(Can1,1280h,2,602h)
'COBID TxPDO SUPERVISOR = COBID RxPDO I/O
CanSetup&(Can1,1800h,1,202h)
'COBID RxPDO SUPERVISOR = COBID TxPDO I/O
CanSetup&(Can1,1400h,1,182h)
```

The I/Os devices need the sending of the message « NMT Start » so they can be operational. To send this message you use the general CAN functions:

```
SetupCan(Can1, 0, 0) ' Use the 1e COBID 0 to access to the NMT server
Nmt$=Chr$(1)+Chr$(2) ' The module NodeID is 2.
Can(Can1,Nmt$)
```

Read and write I/Os by SDO can be like that:

```
A#=CanRemote#(Can1,6000h,1) 'Read inputs 1 to 8
A#=CanRemote#(Can1,6000h,2) 'Read inputs 9 to 16
CanRemote#(Can1,6200h,1,01000100b) 'Updates outputs 3 and 7
```

It is possible to receive inputs states and to modify outputs states with the PDO. The contents of the PDO is depending on the mapping defined by the construction.

```
Wait PDOEvent(Can1,1) 'Waits for a change on the inputs
E$=PDO(Can1,1) 'Reads the PDO
E1#=ASC(MID$(E$,1,1)) 'Reads the first inputs bloc
If E1#>3 Then ... 'Uses the 3rd input
S$=Chr$(00010011b) 'Writes outputs 1, 2 and 5
PDO(Can1,1,S$) 'Sends the PDO
```


10- REMOTE CONTROL

10-1- Connections

The remote control allows by a simple phone link to remotely control a SUPERVISOR with SPL software. The remote control is composed of an integrated dialler and two modems linked by a phone link.

- Structure

The different parts are linked as shown :




- RS 232 link between the modem 1 and the SUPERVISOR

9 points SUBD pin assignment :

Pin	Supervisor	Modem
1		CD
2	RXD	RXD
3	TXD	TXD
4		DTR
5	GND	GND
6		DSR
7		RTS
8	CTS	CTS
9		

Use a shielded cable with shield connected at each end.

Linking :



- RS 232 link between the modem 2 and the PC

This link between the modem and the PC is made with the cable provided with the modem.

10-2- Link establishment

- **Setting up the modem 1 connected to the SUPERVISOR**

The set-up of the modem connected to the SUPERVISOR is made by connecting this modem to a PC. A terminal software is used to send commands to the modem.

This set-up have to following objectives :

- Initialising the modem
- Defining the number of ringing before the modem pick up to allow an automatic establishment of the link.
- Removing all hardware and software flow controls.
- Storing this configuration into the non-volatile memory of the modem.
- Selecting these parameters in the non-volatile memory as parameter to be used at power on.

Example :

Parameters for an « 3Com Us Robotics Sportster » modem type :

-Command : AT&F0

Meaning : Using default factory settings.

-Command : ATS0=3

Meaning : Automatic pick up after 3 ringing.

-Command : AT&H0

Meaning : Disable the flow control when sending

-Command : AT&I0

Meaning : Disable the flow control when receiving

-Command : AT&W0

Meaning : Store current parameters into the non-volatile memory bank #0

-Command : ATY0

Meaning : Selecting these parameters in the non-volatile memory as parameter to be used at power on.

When the modem take these commands into account it answers « OK » .

Parameters for an « Wertermo TD31 or TD32 » modem type :

-Command : AT&F

Meaning : Using default factory settings.

-Command : ATS0=3

Meaning : Automatic pick up after 3 ringing.

-Command : AT&C1

Meaning : Activate DCD when connected

-Command : AT&K0

Meaning : Disable the flow control

-Command : AT&W0

Meaning : Store current parameters into the non-volatile memory bank #0

-Command : AT&Y0

Meaning : Selecting these parameters in the non-volatile memory as parameter to be used at power on.

When the modem take these commands into account it answers « OK » .

- **Setting up the modem 2 connected to the PC**

The setting up of the modem connected to the PC is done by modifying the information in the « Modem » part of the SUPERVISOR.INI file that is in the Windows directory (C:\Windows or C:\Winnt for example).

This set-up have to following objectives :

- Initialising the modem
- Remove handling of the DSR and DTR signals to avoid automatic hang-up when the communication port is closed.
- Defining the way the calls are made and how to hang-up the line.
- Defining the messages sent by the modem.

Example :

Parameters for an « 3Com Us Robotics Sportster » modem type :

- Parameter : Init1

Value : ATZ

Meaning : Using default factory settings.

- Parameter : Init1TimeOut

Value : 5

Meaning : Maximal waiting delay in 1/10 before the modem answer.

- Parameter : Init2

Value : AT&D0&S0

Meaning : Remove the DTR and DSR handling

- Parameter : Init2TimeOut

Value : 5

Meaning : Maximal waiting delay in 1/10 before the modem answer.

- Parameter : Dial

Value : ATDT for vocal dial. ATDP for a pulse dial

Meaning : Selecting the way to call.

- Parameter : DialTimeOut

Value : 600

Meaning : Maximal waiting delay in 1/10 before the modem connection.

- Parameter : Ok

Value : OK

Meaning : Modem answer if the command have been handled correctly.

- Parameter : Connect

Value : CONNECT

Meaning : Modem answer when connecting.

- Parameter : Busy

Value : BUSY

Meaning : Modem answer if the line is busy.

- Parameter : Hangup

Value : ATH

Meaning : Selecting the way to hang-up.

- Parameter : HangupOk

Value : NO CARRIER

Meaning : Modem answer when hanging-up

- Parameter : CommandTimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the modem going to the command mode.

- Parameter : HangupTimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the hanging up.

All missing parameter is automatically set to the default values indicated on the first using.

Parameters for an « Westermo TD31 or TD32 » modem type :

-Parameter : Init1

Value : ATZ

Meaning : Using default factory settings.

- Parameter : Init1TimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the modem answer.

- Parameter : Init2

Value : AT&F&K0

Meaning : Remove the DTR and DSR handling

- Parameter : Init2TimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the modem answer.

- Parameter : Dial

Value : ATDT for vocal dial. ATDP for a pulse dial

Meaning : Selecting the way to call.

- Parameter : DialTimeOut

Value : 600

Meaning : Maximal waiting delay in 1/10 before the modem connection.

- Parameter : Ok

Value : OK

Meaning : Modem answer if the command have been handled correctly.

- Parameter : Connect

Value : CONNECT

Meaning : Modem answer when connecting.

- Parameter : Busy

Value : BUSY

Meaning : Modem answer if the line is busy.

- Parameter : Hangup

Value : ATH

Meaning : Selecting the way to hang-up.

- Parameter : HangupOk

Value : NO CARRIER

Meaning : Modem answer when hanging-up

- Parameter : CommandTimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the modem going to the command mode.

- Parameter : HangupTimeOut

Value : 20

Meaning : Maximal waiting delay in 1/10 before the hanging up.

The dialler expect that the modem is setup to send an echo for all sent command and to receive a text message as answer. If not the communication is unable. It's possible to be sure to start with a good set-up for the modem by using the factory settings as default parameters.

A terminal software is used to send commands to the modem.

Parameters for an « 3Com Us Robotics Sportster » modem type :

- Command : AT&F

Meaning : Using default factory settings.

- Command : AT&W0

Meaning : Store current parameters into the non-volatile memory bank #0

- Command : ATY0

Meaning : Selecting these parameters in the non-volatile memory as parameter to be used at power on.

Parameters for an « Wertermo TD31 or TD32 » modem type :

- Command : AT&F

Meaning : Using default factory settings.

- Command : AT&W0

Meaning : Store current parameters into the non-volatile memory bank #0

- Command : AT&Y0


Meaning : Selecting these parameters in the non-volatile memory as parameter to be used at power on.

ATTENTION :

- For Westermo modem , it's also recommended to let the Dips configuration as default (all OFF).

• **Call :**

By using the phone dialler integrated in the SPL software, we can establish and interrupt the phone link. The phone dialler is accessible form the Communication menu / Remote control.



After entering the phone number, click on «Dial» button to establish the link. The «Hang up » button allows to interrupt the link.

These actions are possible only if the SPL software is not using the same link in debug mode for example. During the connection and disconnection the communication port is not available for the rest of the SPL application.

When the link is established, we can use all the SPL functions including :

- Send and receive the configuration
- Send and receive the variables
- Send the tasks
- Start the tasks
- Stop the tasks
- Access to debug tools : Hyper-terminal, Scope, Trace, Manual mode.

10-3- List of the validated modems

- **3 Com / US Robotics :**
 - Sportster Voice 33600 Fax Modem
 - Sportster 56 K Fax Modem
- **Westermo :**
 - TD 31
 - TD 32

11- APPENDIX

11-1- Execution errors messages

ERROR N°1 to ERROR N°10 :

The errors from 1 to 10 indicate that a card is not well declared or a declared card in the configuration is away or has been replaced by an other type. The number following the E indicates the slot. For example E6 indicates that the card in the slot 6 is not well declared. The system doesn't use the parameters and doesn't start user tasks.

ERROR N°20 :

The error 20 indicates that the data in the saved memory have been corrupted and it is necessary to reload the configuration and the saved variables. The system doesn't use the parameters and doesn't start user tasks.

ERROR N°21 :

The error 21 appears under SUPERVISOR power-on if a parameter of the configuration is wrong. The parameters must be marked and send before starting once again the SUPERVISOR. The system doesn't start the user tasks.

ERROR N°23 :

The error 23 indicates that there are no user tasks in the SUPERVISOR.

ERROR N°30 :

When a user program makes a divide by zero error n°30 is displayed.

ERROR N°31 :

This error is due to an infinite recursive call of a subprogram and indicates a stack overflow.

ERROR N°32 :

This error is generated when a floating point overflow is made by a number too high.

ERROR N°34 :

When an invalid floating point operation has been detected this error is generated. It is produced with the REALTOLONG function if the real number is too big to be stored in long integer.



ERROR N°35 :

This error is generated by an arithmetical overflow in a calculus. This is produced when the result of an operation is too great to be stocked in the provided variable receiving it.



ERROR N°36 :

This error is generated because an index of save variable's table is out of limites.



ERROR N°37 :

This error is generated because an index of not save variable's table is out of limites.



ERROR N°520 :

This error is generated because it's unable to access to internal global bus. The internal bus is bad defect.



ERROR N°530 :

This error is generated because it's unable to access to internal global bus. The internal bus is bad defect.

These last five errors are generated only during user program execution. When an error is detected, all the task are stopped, the error message is displayed on the SUPERVISOR screen, the watchdog is opened and all the servo axis are in a open loop state.

11-2- Compiler error messages

↵ Find <Type1> <Text1> : <Type2> <Text2> Expected

An identifier <Text1> of type <Type1> has been found at the time of the compilation instead of an identifier <Text2> of type <Type2>.

↵ L or H expected

To change an integer in Byte we must use ".L" or ".H".

↵ <Text> unexpected : Prog name expected

The program name must be an identifier no defined previously.

↵ Prog bloc already defined

More than one PROG ... END PROG block is defined in the task.

↵ <Text> unexpected : PROG or SUB expected

A block begins by PROG or SUB. An instruction has been added outwards a block.

↵ No defined PROG

The current block was not finished before end of source file.

↳ **Undefined Label**

An unknown label has been used in a Goto instruction.

↳ **Undefined Sub**

An unknown subprogram identifier has been used in a Call instruction.

↳ **Undefined Event**

An event generated by Signal is waited by any task or a task waits for an event which will be never generated.

↳ **Undefined Prog**

An unknown task identifier has been used in the Run, Halt, Suspend or Continue instruction.

↳ **SRV15 Card Expected**

To use axis card home input, in the parameter InpHome_p, home input name must be the same of axis card input.

↳ **Instruction expected**

An instruction is expected.

↳ **Buzzer : Bit constant expected**

The Buzzer instruction must be followed by a type bit constant.

↳ **Goto or Call instruction expected**

A Call or Goto instruction is expected in a Case

↳ **Invalid exit instruction**

A Exit Sub instruction must be used only in a subprogram.

↳ **<Text> Expected**

The FOR loop counter variable must be also used in the Next instruction.

↳ **If : Instruction expected**

An instruction is expected after an If.

↳ **Else : Instruction expected**

An instruction is expected after an Else.

↳ **SERIAL1: or SERIAL2: Expected**

In Open instruction, the name of the communication port is either SERIAL1: or SERIAL2:.

↳ **POS, VEL, ACC or DEC expected**

The TRAJ instruction accepts only POS, VEL, ACC or DEC as parameter.

↳ **Undefined variable**

The variable contents is used before being defined by an affectation.

↳ **String expression expected**

A type string expression is expected.

↳ **Bit expression expected**

A type bit expression is expected.

↳ **Comment bloc : Unexpected end of file.**

A comments bloc begins by '{{'

↳ **Comment bloc : Unexpected char**

An other character as '{' has been found.

↳ **String constant : Unexpected end of file.**

A string constant must finish with quotation marks.

↳ **Comment bloc : Unexpected end of line**

A comment bloc finishes by '}'

↳ **Bad hex number**

An hexadecimal number uses the characters 0 to 9 and A to F

↳ **Bad binary number**

A binary number uses the characters 0 to 1

↳ **Not an hex value**

An hexadecimal number uses the characters 0 to 9 and A to F

↳ **Not a binary value**

A binary number uses the characters 0 to 1

↳ **Not a decimal value**

A decimal number uses the characters 0 to 9

↳ **Real constant : Unexpected end of line**

A real constant must finish by a number after the decimal point.

↳ **<Text> unexpected : Char from 0 to 9 expected**

A real or decimal number uses the characters 0 to 9

↳ **System constant : Unexpected end of file**

A no complete system constant has been found.

↳ **<Text> unexpected : System constant expected**

A system constant is expected.

↳ **Number : Unexpected end of file**

A number finishes by a number

↳ **<Text> unexpected : Number from 0 to 9 expected**

A number finishes by a number

↳ **'<Character>' unexpected**

A no-awaited character has been found.

Index

A

ABS.....	90
Active waiting.....	60, 61
Addition.....	87
Affect/Equal.....	89
AND.....	90
ARCCOS.....	90
ARCSIN.....	90
ARCTAN.....	91
Arithmetical.....	82
ASC.....	91

B

Backlight.....	76
BACKLIGHT.....	91
Basic task structure.....	51
BEEP.....	92
BOX.....	92
Buzzer.....	76
BUZZER.....	92

C

CALL.....	93
CAN.....	138
CANERROR.....	138
CANERRORCOUNTER.....	138
CANEVENT.....	138
CANLOCAL.....	138
CANopen communication.....	127
CANopen kink between two MCS.....	141
CANopen linking between a MCS and an I/Os module.....	143
CANREMOTE.....	139
CANSETUP.....	139
CARIN.....	93
CAROUT.....	93
CASE.....	93
Char string.....	83
Characteristics.....	130
CHR\$.....	94
CLEARCOUNTER.....	94
CLEARFLASH.....	95
CLEARIN.....	94
CLEAROUT.....	94
Clock sub-menu.....	80
CLOSE.....	95
Close a communication port.....	70
CLS.....	95
Communication.....	86
Communication menu.....	28
Compiler error messages.....	153
Connections.....	131, 144
Contacts coils timers and counters.....	65
CONTINUE.....	95, 96
Conversion.....	86
Convert data types.....	48

COS	96
COUNTER_S	95
Counters	62
CRC	97
CURSOR	96
CVI	97
CVIR	97
CVL	96
CVLR	96
D	
DATE\$	97
Debug menu	22
DELAY	97, 98
Description	45
Dialog 640	76
Dictionary	134
Different	88
DIFFUSE	98
DIV	98
Division	87
E	
Edit	75, 76
EDIT	98
EDIT\$	99
END	99
Environmental consideration	11
Event task structure	56
Events	61
Events handling	60
Example RTU Modbus driver	70
Execution errors messages	152
EXIT SUB	99
EXP	99
Exponent	90
F	
Flash Security and other functions	86
FLASHOK	100
FLASHTORAM	100
Folders	16
FONT	100, 101
FOR	100
FORMAT\$	101
FRAC	101
Free contact and coil	67
G	
General explication	77
GETDATE	101
GETEVENT	102
GETTIME	102
Global constants	46
Global variables	46
GOTO	102
Greater	89
Greater or equal	89

H

HALT.....	102
Help menu	33
HLINE	103

I

ICALL.....	103
IF 103, 104	
INKEY.....	104
INP.....	104
INPB.....	104
INPUT.....	105
INPUT\$.....	105
Inputs reading.....	59
INPW.....	105
Installation procedure	15
INSTR.....	105
INT.....	106
Introduction.....	68, 127

J

JUMP.....	106
-----------	-----

K

KEY.....	106
Keyboard	75
KEYDELAY.....	107
KEYREPEAT	107

L

LCASE\$.....	107
LED.....	107
Leds.....	76
Left shift	88
LEFT\$.....	107
LEN.....	108
Link establishment.....	145
List of the CANopen instructions	137
List of the validated modems.....	151
Local variables.....	47
LOCATE	108
LOG.....	108
Logical	83
LONGTOINTEGER	108
Loops.....	83
Lower.....	88
Lower or equal.....	88
LTRIM\$.....	108

M

Main menu.....	77
Management of task	50
Manual sub-menu for digital inputs	79
Mathematical	82
Memory plan of MCS32 Ex.....	45
Memory sub-menu.....	80
MID\$.....	109
MKI\$.....	110

MKIR\$.....	110
MKL\$	110
MKLR\$.....	110
MOD	109
MODIFYEVENT.....	109
Multiplication.....	87
Multitask principles	49

N

Network configuration.....	129
NOT	111
Numeric notations.....	49

O

OPEN.....	111
Opening a communication port	68
Options menu	31
OR	111
OUT	112
OUTB.....	112
OUTEMPTY.....	112
Outputs reading.....	59
Outputs writing.....	59

P

Parameters sub-menu.....	78
Passive waiting.....	60
PDO.....	140
PDOEVENT	140
PIXEL.....	112
PLC.....	84
PLCINP.....	113
PLCINPB	113
PLCINPNE.....	113
PLCINPPE.....	114
PLCINPW	114
PLCOUT	114
PLCOUTB.....	115
PLCOUTW.....	115
PLCREADINPUTS	115
PLCWRITEOUTPUTS.....	115
POWERFAIL	115
Presentation	65
Presentation - SCAN board.....	130
PRINT	116
PROG	116
Program.....	82
Project menu	18

R

RAMOK.....	116
RAMTOFLASH.....	116
Reading data	69
READKEY	117
REALTOBYTE.....	117
REALTOINTEGER	117
REALTOLONG	117
REPEAT	118
RESTART	118

Right shift.....	89
RIGHT\$.....	118
RS485 treatment	70
RTRIM\$	118
RUN	119

S

Safety.....	11
Screen	74
SDOEVENT	140
SDOINDEX.....	140
SDOSUBINDEX	141
SEEK	119
SETDATE	119
SETINP.....	119
SETOUT	119
SETTIME	120
SETUPCAN	141
SETUPCOUNTER.....	120
SGN	120
SIGNAL.....	121
SIN.....	120
SPACE\$.....	121
SQR	121
State test.....	60
STATUS.....	121
STOPCAN	141
STR\$.....	121
STRING\$	122
SUB	122
Substraction.....	87
SUSPEND	122
System bits	67

T

TAN.....	123
Task architecture	67
Task handling	85
Task priority	50
Tasks sub-menu	81
Test.....	83
Test and diagnostic of the Can Open network.....	132
TIME	123
TIME\$	123
TIMER.....	123
TX485	124
Type of send messages	130

U

UCASE\$	124
---------------	-----

V

VAL.....	124
Variables sub-menu.....	79
VERSION.....	124
VLIN	124

W

WAIT.....	125, 126
-----------	----------

WAIT EVENT 125
WAIT KEY 125
WATCHDOG 126
WHILE 126
Writing data 69

X

XOR 126